

[Manuals.plus](#) /

› [Empava](#) /

› Empava 24-Inch Single Gas Wall Oven (Model 24WO09) User Manual

Empava 24WO09

Empava 24-Inch Single Gas Wall Oven (Model 24WO09) User Manual

Model: 24WO09

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Empava 24-inch Single Gas Wall Oven. Please read all instructions carefully before installation and use. Retain this manual for future reference.



Front view of the Empava 24-inch Single Gas Wall Oven, showcasing its stainless steel finish and control panel.

SAFETY INFORMATION

WARNING: For your safety, the information in this manual must be followed to minimize the risk of fire or explosion, or to prevent property damage, personal injury, or death.

- This appliance must be installed by a qualified installer in accordance with local codes and the National Fuel Gas Code ANSI Z223.1/NFPA 54.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Never use this appliance as a space heater to heat or warm the room. This could result in carbon monoxide poisoning and overheating of the oven.
- Ensure proper ventilation.
- Keep children away from the oven during operation.
- Do not line the oven walls, racks, or bottom with aluminum foil or any other material. This can trap heat, damage the oven, and pose a fire hazard.

PRODUCT OVERVIEW

The Empava 24-inch Single Gas Wall Oven features multiple cooking functions, including bake, broil, and rotisserie, enhanced by a convection fan for even heat distribution. It is equipped with mechanical controls and a digital timer for precise cooking.

Key Features:

- **Convection Fan:** Circulates heated air for fast preheating and uniform cooking.
- **Rotisserie Function:** 360° rotation for roasting.
- **Mechanical Controls:** Ergonomic knobs for temperature and function selection.
- **Digital Timer:** Up to 120 minutes, with automatic shut-off.
- **Capacity:** 2.3 cubic feet.
- **Rack Positions:** 5 adjustable rack positions.
- **Door:** Triple-layer tempered glass door for thermal insulation and safety.

Convection Rotisserie

All-round Three-dimensional Heating




Illustration of the convection rotisserie function, showing air circulation for even heating.

5 Cooking Functions

Meet all your daily needs



Bake



Broil



Convection



Rotisserie



Convection Rotisserie

Visual representation of the oven's five cooking functions: Bake, Broil, Convection, Rotisserie, and Convection Rotisserie.

SETUP AND INSTALLATION

This oven is pre-installed for Natural Gas (NG) use and includes a gas regulator. It cannot be converted to Liquid Propane (LP) gas. A US standard 120V power cord (electric ignitor) and a 15 Amp breaker are required.

Dimensions and Cutout:

- **Oven Dimensions (W x D x H):** 23.42 in. x 22.83 in. x 23.6 in.
- **Cutout Dimensions (W x D x H):** 22.24 in. x 22.64 in. x 23.42 in.

2.3 Cu.ft. Spacious Interior



Detailed diagram showing the external dimensions of the oven and the required cabinet cutout dimensions for installation.

Included Components:

- Grilling Rack
- Baking Tray
- Rotisserie Kit

Note: Installation should be performed by a qualified professional to ensure compliance with all local codes and safety standards.

Unboxing and Initial Setup Video:

Your browser does not support the video tag.


This video demonstrates the unboxing process and initial setup steps for the Empava 24-inch Gas Single Wall Oven (EMPV-24WO09).

OPERATING INSTRUCTIONS

Familiarize yourself with the control panel and oven functions before first use.

Control Panel:

- **Function Knob:** Select desired cooking mode (Bake, Broil, Convection, Rotisserie, Convection Rotisserie).
- **Temperature Knob:** Set the oven temperature from 250°F to 480°F.
- **Digital Display Timer:** Set cooking duration up to 120 minutes. The oven will automatically turn off when the timer expires.



Close-up of the oven's control panel, highlighting the LED digital display and ergonomic control knobs for function and temperature.

Cooking Functions:

1. **Bake:** Ideal for general baking. Place food on the baking tray or a suitable oven-safe dish on one of the 5 rack positions.
2. **Broil:** Use for grilling or browning food. Position food closer to the top heating element. Monitor closely to prevent burning.

3. **Convection:** Activates the convection fan to circulate hot air, reducing cooking time and ensuring even results. Suitable for most dishes.
4. **Rotisserie:** For roasting whole poultry or large cuts of meat. Secure the food onto the rotisserie spit and place it in the designated rotisserie position. The 360° rotation ensures even cooking.
5. **Convection Rotisserie:** Combines the rotisserie function with the convection fan for faster, more uniform roasting.

Oven Operation Video:

Your browser does not support the video tag.

This video provides a brief overview of the Empava 24-inch Gas Single Wall Oven in operation, demonstrating its features.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your oven.

Exterior Cleaning:

- Wipe stainless steel surfaces with a soft cloth and a mild detergent or stainless steel cleaner.
- Avoid abrasive cleaners or scouring pads, which can scratch the finish.

Interior Cleaning:

- Allow the oven to cool completely before cleaning.
- Remove racks and accessories. These can be washed in warm, soapy water.
- The enamel tank surface is designed for easy cleanup. Wipe spills and food residue with a damp cloth and mild detergent.
- For stubborn stains, use a non-abrasive oven cleaner specifically designed for gas ovens, following the product instructions carefully.



Image depicting the interior cleaning process of an oven, showing a person wiping down surfaces.

TROUBLESHOOTING

Before contacting customer service, review the following common issues and solutions.

Problem	Possible Cause	Solution
Oven not heating	No power, gas supply off, ignitor malfunction.	Check circuit breaker. Ensure gas valve is open. Contact a qualified technician if ignitor is suspected.

Problem	Possible Cause	Solution
Uneven cooking	Improper rack position, overloaded oven, convection fan issue.	Adjust rack position. Avoid overcrowding. Ensure convection fan is operating in convection modes.
Digital timer not working	Power interruption, incorrect setting.	Reset power to the oven. Refer to operating instructions for correct timer setting.
Gas odor	Gas leak.	IMMEDIATELY turn off gas supply. Do not operate any electrical switches. Open windows. Evacuate and call gas company or fire department.

SPECIFICATIONS

Brand	Empava
Model Number	24WO09
Size	24 Inch
Color	Stainless Steel
Fuel Type	Natural Gas (NG)
Heating Method	Convection
Capacity	2.3 cubic feet
Installation Type	Wall Mount
Voltage	120V
Wattage	100 watts
Item Dimensions (D x W x H)	22.83"D x 23.42"W x 23.6"H
Item Weight	70 Pounds
UPC	759740663395

WARRANTY INFORMATION

The Empava 24-inch Single Gas Wall Oven comes with a **2-year US-based manufacturer warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, please refer to the official Empava website or contact customer support.

CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to make a warranty claim, please contact Empava customer support.

- **Brand:** Empava

- **Online Support:** Visit the official Empava website for FAQs and contact information.
- **Documents:** A PDF version of the user manual is available for download: [User Manual \(PDF\)](#)



Empava is a registered trademark. All rights reserved.