**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**USHA 40800108000PN**

# USHA Thunderbolt 800-Watt Mixer Grinder Instruction Manual

Model: 40800108000PN

## Introduction

This manual provides essential information for the safe and efficient operation of your USHA Thunderbolt 800-Watt Mixer Grinder. Please read these instructions carefully before using the appliance for the first time and retain them for future reference.




Image: The USHA Thunderbolt 800-Watt Mixer Grinder main unit with three stainless steel jars and lids, showcasing its compact design.

## Important Safety Instructions

- Always ensure the appliance is placed on a stable, flat, and dry surface before operation.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Keep hands and utensils away from moving blades during operation to prevent injury. Always use the lid.
- Ensure the jar is securely locked onto the motor unit before switching on.
- Do not operate the mixer grinder continuously for more than 5 minutes. Allow a cooling period of 2-3 minutes before resuming.
- The appliance is equipped with an overload protection mechanism. If the motor stops due to overload, switch off the appliance, remove some contents, and press the reset button located at the bottom of the motor unit.
- Unplug the appliance from the power outlet when not in use, before cleaning, or when changing accessories.
- This appliance is for household use only. Do not use outdoors.

- Keep out of reach of children.

## Setup and First Use

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for storage or future transport.
2. **Initial Cleaning:** Wash all jars, lids, and blades with warm soapy water, rinse thoroughly, and dry completely before first use. Wipe the main motor unit with a damp cloth.
3. **Placement:** Place the mixer grinder on a clean, dry, and stable surface. The super suction feet at the base will help secure the unit during operation.
4. **Power Connection:** Ensure the power cord is free from damage. Plug the mixer grinder into a standard 230V AC power outlet.




Image: A close-up view of the mixer grinder's base, highlighting the 3-speed control knob with whip option and the super suction feet for stability.

## Operating Instructions

The USHA Thunderbolt Mixer Grinder comes with three stainless steel jars for various grinding needs:

- **1.5 Litre Wet Grinding Jar:** Ideal for making batters, purees, and milkshakes.
- **1.0 Litre Multipurpose Jar:** Suitable for dry grinding spices, nuts, and wet grinding smaller quantities.
- **0.5 Litre Grinding Jar:** Designed for grinding small quantities of dry spices, chutneys, and pastes.




Image: The three heavy-gauge stainless steel jars with flow breakers, including the 1.5L wet jar, 1L multipurpose jar, and 500ml grinding jar.

## General Usage Steps:

1. **Prepare Ingredients:** Cut ingredients into small pieces for easier grinding. Do not overfill the jar; ensure contents are below the blade level.
2. **Attach Jar:** Place the desired jar onto the motor unit and twist gently until it locks securely into position.
3. **Secure Lid:** Place the lid firmly on the jar. Ensure it is properly seated to prevent spillage during operation.
4. **Select Speed:** Turn the knob to the desired speed setting (1, 2, or 3). For quick bursts, use the "Whip" option by turning the knob counter-clockwise and holding it. Release to stop.

5. **Monitor Grinding:** Observe the consistency through the lid. If needed, stop the appliance, open the lid, and scrape down the sides with a spatula before resuming.
6. **Switch Off:** After achieving the desired consistency, turn the knob to the "OFF" position. Wait for the blades to stop completely before removing the jar.
7. **Remove Jar:** Gently twist the jar counter-clockwise and lift it off the motor unit.

**Note:** The mixer grinder features a high torque and high-speed 800-watt copper motor for efficient grinding. Always follow the recommended operating times to prevent overheating.

## Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your mixer grinder.

- **Motor Unit:** Disconnect from power. Wipe the main motor unit with a soft, damp cloth. Do not use abrasive cleaners or immerse in water.
- **Jars and Lids:** After each use, immediately rinse the jars, lids, and blades to prevent food from drying and sticking. Wash with warm soapy water using a brush for the blades. Rinse thoroughly and dry completely.
- **Blades:** Handle blades with extreme care as they are sharp.
- **Storage:** Store the mixer grinder and its accessories in a clean, dry place when not in use.
- **Dishwasher Safety:** The jars, lids, and blades are **NOT** dishwasher safe. Hand wash only.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Motor not starting. | • Not plugged in.<br>• Overload protector tripped.<br>• Jar not properly locked. | • Check power connection.<br>• Press the reset button at the bottom of the motor unit.<br>• Ensure the jar is securely locked onto the motor unit. |
| Lid comes off during operation. | • Lid not secured properly.<br>• Jar overfilled. | • Ensure the lid is pressed down firmly before starting.<br>• Reduce the quantity of ingredients. |
| Burning smell from motor. | • Overloading.<br>• Continuous operation for too long. | • Reduce load.<br>• Allow motor to cool down. Do not operate continuously for more than 5 minutes. |
| Ineffective grinding. | • Insufficient liquid (for wet grinding).<br>• Ingredients too large.<br>• Blades are dull (rare for new product). | • Add more liquid.<br>• Cut ingredients into smaller pieces.<br>• Contact customer support if blades seem dull. |

If the problem persists after attempting these solutions, please contact customer support.

## Specifications

| | |
|---|---|
| **Brand** | USHA |

| | |
|---|---|
| **Model Number** | 40800108000PN |
| **Wattage** | 800 Watts |
| **Motor Type** | 100% Copper Motor, High Torque and High Speed |
| **Voltage** | 230 Volts |
| **Number of Jars** | 3 (1.5L Wet, 1.0L Multipurpose, 0.5L Grinding) |
| **Jar Material** | Heavy Gauge Stainless Steel with Flow Breakers |
| **Blade Material** | Stainless Steel |
| **Body Material** | ABS Plastic (Shock Proof) |
| **Speed Settings** | 3 Speed with Whip Option |
| **Control Type** | Knob |
| **Safety Features** | Overload Protection, Super Suction Feet |
| **Product Dimensions (D x W x H)** | 18D x 37W x 30H Centimeters |
| **Item Weight** | 4500 Grams |
| **Country of Origin** | India |

## Warranty and Support

Your USHA Thunderbolt Mixer Grinder is covered by a comprehensive warranty:

- **Motor Warranty:** 5 years from the date of purchase.
- **Product Warranty:** 2 years from the date of purchase.

For warranty claims, service requests, or any product-related queries, please contact USHA customer support:

- **Toll-Free Number:** 1800 1033 111
- **Manufacturer:** Usha International Limited, Registered Office: Surya Kiran Building, 19 K.G. Marg, New Delhi-110 001.

Please keep your purchase receipt or invoice as proof of purchase for warranty validation.

© 2026 USHA International Limited. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0835JGDBB**

More documents and user manuals: **https://manuals.plus/**