

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ZENY](#) /

› [ZENY 58-inch L-Shaped Reversible Desk Instruction Manual](#)

## ZENY G8

# ZENY 58-inch L-Shaped Reversible Desk Instruction Manual

Model: G8

## INTRODUCTION

---

Thank you for choosing the ZENY 58-inch L-Shaped Reversible Desk. This manual provides detailed instructions for assembly, usage, maintenance, and troubleshooting to ensure optimal performance and longevity of your desk. Please read this manual thoroughly before assembly and retain it for future reference.

## SAFETY INFORMATION

---

- Always assemble the desk on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and retighten as needed.
- Do not overload the desk. The maximum weight capacity is 500 pounds (226 kg).
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Use caution when moving the assembled desk to avoid injury or damage.
- Adjustable foot pads are included to ensure stability on uneven floors. Ensure they are properly adjusted.

## PACKAGE CONTENTS

---

Before beginning assembly, verify that all components and hardware are present and undamaged. The package includes all necessary tools for assembly.

- Desk panels (L-shaped sections)
- Steel frame components (legs, support bars)
- Assembly hardware (screws, bolts, washers)
- Adjustable foot pads
- Assembly tools (e.g., Allen wrench)

## SETUP AND ASSEMBLY

---

Follow these steps carefully for proper assembly. It is recommended to have two people for assembly.

### **Step 1: Unpack and Identify Parts**

Carefully remove all contents from the packaging. Lay out all desk panels, frame components, and hardware on a clean, soft surface. Refer to the included parts list to identify each piece.

### **Step 2: Assemble the Frame**

Attach the steel frame components according to the diagrams in your specific instruction leaflet. Ensure all connections are finger-tightened initially.

### **Step 3: Attach Desk Panels**

Carefully place the desk panels onto the assembled frame. Align the pre-drilled holes in the panels with the holes in the frame. Secure the panels using the provided screws. Once all panels are in place, fully tighten all screws and bolts.

### **Step 4: Configure Reversible Setup**

The desk features a reversible design, allowing you to switch the long and short sides to suit your room layout or preference. This configuration can be adjusted during assembly by orienting the L-shaped sections as desired. The image below illustrates the two-way setup options.



Image: Two-way setup options for the L-shaped desk, demonstrating how the long and short sides can be reversed.

### **Step 5: Install Adjustable Foot Pads**

Screw the adjustable foot pads into the bottom of each leg. Adjust them as needed to level the desk and prevent wobbling on uneven surfaces. These pads also protect your floor from scratches.

## TWO-WAY SETUP

Switch the long and short side according to your habits



Image: Details of the desk's construction, including table thickness, adjustable leg pads, and sturdy frame.

### OPERATING INSTRUCTIONS

The ZENY L-Shaped Desk is designed for versatile use in home offices, gaming setups, or study areas. Its spacious surface accommodates multiple monitors, laptops, and other office essentials.

- **Workspace Utilization:** Arrange your computer, peripherals, and documents to maximize the L-shaped layout. The corner design optimizes space utilization.
- **Reversible Configuration:** As mentioned in the setup, the desk can be configured with the longer section on either the left or right side, adapting to your specific room and workflow needs.
- **Stability:** Ensure the adjustable foot pads are correctly set to maintain desk stability, especially when placing heavy equipment.



Image: The ZENY L-Shaped Desk configured as a home office workstation.

## MAINTENANCE

---

Proper care will extend the life and appearance of your desk.

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the engineered wood desktop.
- **Hardware Check:** Periodically inspect all screws and bolts to ensure they remain tight. Retighten if necessary to maintain structural integrity.
- **Avoid Extreme Conditions:** Do not expose the desk to extreme temperatures or humidity, as this may cause warping or damage to the materials.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Desk is wobbly	Uneven floor; loose fasteners	Adjust the foot pads to level the desk. Check and tighten all screws and bolts.
Parts do not align during assembly	Incorrect orientation of parts; fasteners not fully loosened	Review the assembly diagrams carefully. Ensure all fasteners are loose enough to allow for adjustment before tightening.
Missing hardware	Packaging error	Contact customer support for replacement parts.

## SPECIFICATIONS

---

Feature	Detail
Brand	ZENY
Model Number	G8
Shape	L-Shape
Product Dimensions (D x W x H)	44.2" x 58" x 29"
Color	Black
Style	Modern
Base Material	Metal (Steel)
Top Material Type	Engineered Wood
Special Feature	Reversible
Item Weight	44 Pounds
Maximum Weight Recommendation	500 Pounds
Assembly Required	Yes (Tools included)

## WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the documentation included with your purchase or contact ZENY customer service directly. Keep your purchase receipt for warranty claims.

Contact information can typically be found on the manufacturer's website or on the product packaging.