

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [iClimb](#) /

› [iClimb Ultralight Compact Camping Folding Table IC701 Instruction Manual](#)

iClimb IC701

iClimb Ultralight Compact Camping Folding Table IC701 Instruction Manual

Model: IC701 | Brand: iClimb

INTRODUCTION

Thank you for choosing the iClimb Ultralight Compact Camping Folding Table. This manual provides essential information for the safe and efficient use of your new table. Please read it thoroughly before assembly and operation.



Image: The iClimb Ultralight Compact Camping Folding Table in its assembled state, alongside its compact carry bag.

SETUP INSTRUCTIONS

Follow these steps to assemble your iClimb Ultralight Compact Camping Folding Table:

- 1. Unpack Components:** Remove the table top, base frame, and carry bag from the packaging.
- 2. Expand Base Frame:** Carefully unfold the base frame until it is fully extended. Ensure the freely rotating poles snap securely into the base. Listen for a click to confirm they are fully engaged.
- 3. Attach Tabletop:** Align the tabletop slats with the connectors on the base frame. Gently press down until the tabletop securely attaches to all four corners of the frame.
- 4. Verify Stability:** Once assembled, ensure the table is stable on a flat surface before placing items on it.

EASY TO SET UP



Image: Visual guide demonstrating the four steps to set up the iClimb folding table.

OPERATING INSTRUCTIONS

The iClimb Ultralight Compact Camping Folding Table is designed for versatile use in various outdoor settings. Its features ensure convenience and durability:

- **Lightweight and Portable:** Constructed from aerospace-grade aluminum alloy, the table weighs only 2.2 lbs, making it easy to transport.
- **Durable Surface:** The aluminum tabletop is waterproof, corrosion-resistant, and easy to clean. It can withstand


temperatures suitable for placing a stove.

- **Stable Design:** Sturdy joints and anti-slip feet prevent the table from folding, bending, or slipping on various terrains. The unique hinged connection design enhances longevity.
- **Optimal Size:** With a surface area of 16.1 x 13.58 inches and a height of 11.4 inches, it is suitable for holding drinks, snacks, or small equipment.

New design Unique hinged connection

Similar tables

Material: PP



iClimb new design
Material: Nylon



Image: The iClimb table in use, holding a cooking pot and beverage, highlighting its utility for outdoor meals.

MAINTENANCE

To ensure the longevity and optimal performance of your iClimb Ultralight Compact Camping Folding Table, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the table with a damp cloth after each use to remove dirt, food residue, or spills. For stubborn stains, a mild soap solution can be used, followed by rinsing and drying.
- **Drying:** Ensure the table is completely dry before folding and storing it to prevent corrosion, especially on metal components.
- **Storage:** Store the table in its provided carry bag in a dry, cool place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect all joints, hinges, and feet for any signs of wear or damage. Address any issues promptly to maintain stability and safety.

TROUBLESHOOTING

If you encounter any issues with your iClimb Ultralight Compact Camping Folding Table, refer to the following common solutions:

- **Table Feels Unstable:**
 - Ensure the base frame's poles are fully snapped into their sockets. A distinct "click" indicates proper engagement.
 - Verify that the tabletop is securely attached to all four corners of the base frame.
 - Place the table on a flat, even surface. Uneven ground can affect stability.
- **Difficulty Folding/Unfolding:**
 - Check for any obstructions in the hinged connections or frame joints.
 - Ensure no dirt or debris is lodged in the folding mechanisms.

SPECIFICATIONS

Brand	iClimb
Model Number	IC701
Product Dimensions (Small)	16.1"D x 13.58"W x 11.4"H (41cm D x 34.5cm W x 29cm H)
Item Weight	2.2 Pounds (1.0 kg)
Maximum Weight Recommendation	66 Pounds (30 kg)
Material Type	Aerospace-grade Aluminum Alloy (6061) and Nylon
Color	Black
Frame Joint Type	Hinged
Included Components	Table Top, Base Frame, Carry Bag



Image: Detailed specifications including dimensions, materials, and weight for both small and large table sizes.

WARRANTY AND SUPPORT

iClimb offers a limited lifetime warranty against manufacturer defects for this product. For warranty claims or support inquiries, please contact iClimb customer service through the official channels.

For additional information or to view other iClimb products, please visit the [iClimb Store](#).


© 2025 iClimb. All rights reserved.

Related Documents - IC701



[iClimb Alu. Camping Table IC701 & IC702 Instruction Manual](#)

Official instruction manual for the iClimb Alu. Camping Table models IC701 and IC702. Learn how to assemble and use your portable camping table.

	<p>iClimb IC606 Camping Chair Assembly Instructions</p> <p>Step-by-step guide for assembling the iClimb IC606 ultralight compact camping chair, including diagrams and important tips for easy setup.</p>
	<p>iClimb IC607 Camping Chair Assembly Instructions</p> <p>Step-by-step guide on how to assemble the iClimb IC607 ultralight compact camping chair, including setting up the frame and attaching the fabric.</p>
	<p>iClimb Sun Shield Tarp IC102 Assembly Instructions</p> <p>Learn how to easily set up your iClimb Sun Shield Tarp IC102 for camping or outdoor events. This guide provides step-by-step instructions for assembling the tarp.</p>

Documents - iClimb – IC701



[iClimb Alu. Camping Table IC701 & IC702 Instruction Manual](#)

Official instruction manual for the iClimb Alu. Camping Table models IC701 and IC702. Learn how to assemble and use your portable camping table.

lang: score:29 filesize: 1.87 M page_count: 1 document date: 2023-06-15