



Manuals.plus /

› Move2Play /

› Move2Play Kids Karaoke Microphone (Model Motown103) Instruction Manual

## Move2Play Motown103

# Move2Play Kids Karaoke Microphone (Model Motown103) Instruction Manual

Your Guide to Fun and Music

## 1. INTRODUCTION

---

Thank you for choosing the Move2Play Kids Karaoke Microphone. This device combines a microphone with a Bluetooth speaker, allowing for interactive singing experiences. It features pre-loaded songs, voice effects, and the ability to connect to external music sources via Bluetooth. Please read this manual carefully to ensure proper use and enjoyment of your new karaoke microphone.



Image 1.1: The Move2Play Kids Karaoke Microphone, showcasing its design and key features.

## 2. PRODUCT FEATURES

- **Bluetooth Connectivity:** Connects wirelessly to smartphones and other Bluetooth-enabled devices to play any song from your favorite music apps (e.g., Spotify, Apple Music, YouTube).
- **Pre-Loaded Songs:** Includes 30 famous Motown songs by artists such as Stevie Wonder, Jackson 5, and Marvin Gaye.
- **Quality Sound:** Equipped with precision stereo acoustic speakers for high volume and clear sound.
- **Voice Effects:** Features 4 distinct voice effects: high pitch, low pitch, chipmunk, and echo control for

varied vocal styles.

- **Long Battery Life:** Rechargeable lithium-ion battery provides over 8 hours of singing time on less than 2 hours of charge.

### 3. WHAT'S IN THE BOX

---

- 1 x Move2Play Kids Karaoke Microphone
- 1 x USB Charging Cable
- 1 x Headphone Connector

### 4. SETUP

---

#### 4.1 Initial Charging

Before first use, fully charge the microphone. Connect the provided USB charging cable to the charging port located at the bottom of the microphone and plug the other end into a compatible USB power source (e.g., computer, USB wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged.

#### 4.2 Powering On/Off

To power on the microphone, press and hold the power button (usually a circular button with a power symbol) located on the control panel until you hear an audible prompt. To power off, press and hold the same button until the device shuts down.

# EASY TO USE



INCLUDES  
USB CHARGER



8 HOUR  
PLAY TIME



HIGH VOLUME  
QUALITY SOUND



4 VOICE EFFECTS



Image 4.1: The microphone's control panel and features, including the power button and volume sliders.

## 5. OPERATING INSTRUCTIONS

### 5.1 Volume Control

The microphone features individual sliders for adjusting microphone volume, echo effect, and music volume. Adjust these sliders to achieve your desired sound balance.

- **Mic Volume:** Controls the loudness of your voice through the microphone.
- **Echo Control:** Adjusts the intensity of the echo effect applied to your voice.
- **Music Volume:** Controls the volume of the background music (pre-loaded or Bluetooth connected).

### 5.2 Voice Effects

Press the 'Voice FX' button (or similar labeled button) to cycle through the 4 available voice effects: high pitch, low pitch, chipmunk, and standard echo. Experiment with these to add variety to your singing.

### 5.3 Pre-Loaded Songs

The microphone comes with 30 pre-loaded Motown songs. Use the 'Previous' and 'Next' track buttons (often labeled with ◀◀ and ▶▶ symbols) to navigate through the song list. Press the 'Play/Pause' button (▶▶|■) to start or pause playback.



PRE-LOADED WITH

# 30 hit songs

- Stevie Wonder
- Marvin Gaye
- Jackson Five
- And More!

---

1. ABC, 123
2. Ain't No Mountain High Enough
3. Heard It Through The Grapevine
4. My Girl
5. I Want You Back
6. Signed Sealed Delivered, I'm Yours
7. Stop In The Name Of Love
8. Just My Imagination
9. Tracks Of My Tears
10. Sugar Pie Honeybunch ...and more!

*Image 5.1: Example of pre-loaded songs available on the microphone.*

## 5.4 Bluetooth Connection

To connect your microphone to a Bluetooth device:

1. Ensure the microphone is powered on and in Bluetooth pairing mode (indicated by an audible prompt or blinking light).
2. On your smartphone or tablet, go to Bluetooth settings and search for available devices.
3. Select "Motown Magic" (or similar device name) from the list to pair.
4. Once connected, you can play music from any app on your device, and the audio will stream through the microphone's speaker.



Image 5.2: Visual guide for connecting the microphone to various music apps via Bluetooth.

### 5.5 Light Effects

The microphone features integrated LED lights that can be activated or changed using a dedicated light button (often labeled with a lightbulb icon). Press this button to cycle through different light modes or turn them off.

### 5.6 Official Product Videos

*Video 5.1: A demonstration of the Move2Play Karaoke Microphone's features and sound quality.*

*Video 5.2: An explainer video detailing the functions and benefits of the Motown Microphone.*

*Video 5.3: A comprehensive overview of the Motown Explainer Video, highlighting its various capabilities.*

## 6. MAINTENANCE

To ensure the longevity of your Move2Play Kids Karaoke Microphone, follow these maintenance guidelines:

- **Cleaning:** Wipe the microphone with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the microphone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Avoid fully depleting the battery frequently. Charge it regularly to maintain battery health.

## 7. TROUBLESHOOTING

If you encounter any issues with your microphone, please refer to the following common solutions:

Problem	Possible Solution
Microphone does not turn on.	Ensure the battery is charged. Connect to the USB charging cable and allow it to charge for at least 30 minutes before attempting to power on again.
No sound from the microphone.	Check the microphone volume slider and ensure it is not set to minimum. Verify that the device is powered on and not muted.
Cannot connect via Bluetooth.	Ensure Bluetooth is enabled on your device and the microphone is in pairing mode. Try restarting both the microphone and your Bluetooth device. Make sure no other devices are currently connected to the microphone.
Music is too loud/quiet.	Adjust the 'Music' volume slider on the microphone. If connected via Bluetooth, also check the volume on your connected device.
Voice effects are not working.	Press the 'Voice FX' button to cycle through the effects. Ensure the microphone volume is adequate for the effects to be noticeable.

## 8. SPECIFICATIONS

- **Model Name:** Motown103
- **Brand:** Move2Play
- **Microphone Form Factor:** Handheld
- **Connectivity Technology:** Bluetooth
- **Power Source:** Battery Powered (1 Lithium Ion battery included)
- **Material:** Aluminum
- **Item Weight:** 14.4 ounces
- **Product Dimensions:** 6 x 6 x 6 inches
- **Manufacturer Recommended Age:** 3 years and up
- **Release Date:** February 20, 2020

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Move2Play directly through their official

website or customer service channels. Keep your proof of purchase for any warranty claims.