

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Garmin](#) /
- › [Garmin Approach S62 Premium Golf GPS Watch User Manual](#)

Garmin 010-02200-00

Garmin Approach S62 Premium Golf GPS Watch User Manual

Model: 010-02200-00

1. INTRODUCTION AND OVERVIEW

Welcome to the user manual for your Garmin Approach S62 Premium Golf GPS Watch. This guide provides detailed instructions on setting up, operating, maintaining, and troubleshooting your device. The Approach S62 is designed to enhance your golf game with advanced GPS capabilities, a built-in virtual caddie, and comprehensive tracking features.



Figure 1.1: Front view of the Garmin Approach S62 Golf GPS Watch.



Figure 1.2: Side view of the Garmin Approach S62 Golf GPS Watch.

2. SETUP

2.1 Initial Charging

Before first use, fully charge your Approach S62 watch. Use the provided charging/data cable and connect it to a USB power source. The watch display will indicate charging status.

2.2 Powering On and Basic Setup

Press and hold the power button to turn on the watch. Follow the on-screen prompts to select your language, units of measure, and other initial settings. For optimal performance, ensure the watch's software is up to date.

2.3 Pairing with Garmin Golf App

To unlock full features and track your game statistics, pair your watch with the Garmin Golf app on your compatible smartphone. Download the app from your device's app store and follow the pairing instructions within the app.




Figure 2.1: The Garmin Approach S62 features multiple customizable watch faces.

3. OPERATING THE WATCH

3.1 Basic Navigation

The Approach S62 features a large 1.3-inch color touchscreen display for easy navigation. Swipe left or right to scroll through widgets and features. Use the physical buttons on the side for quick access to golf mode, menu options, and back functions.



Figure 3.1: Watch face displaying daily steps and last round score.

3.2 Golf Features

The watch comes preloaded with over 41,000 full-color CourseView maps from around the world. It automatically detects your location and displays relevant course information.



Figure 3.2: Golf course view on the watch display.

Virtual Caddie

The Virtual Caddie suggests clubs based on your typical hitting distance, factoring in wind speed and direction. It also indicates where you should aim on the map for optimal shot placement.

BUILT FOR GOLF

We've got your game with Approach S62, a premium GPS golf watch that puts critical information from more than 42,000 full-color course maps worldwide on your wrist.



Figure 3.3: Virtual Caddie suggesting club and aim.

Green View and PinPointer

The Green View feature allows you to see the true shape of the green and manually position the pin for accurate distances. The PinPointer feature tells you the direction to the pin when you have a blind shot, ensuring you always know where to aim.




GOES BEYOND THE COURSE

Whether you just got done with a game and find yourself in the clubhouse or you want to hit the town, Approach S62 is great for everyday wear.

Figure 3.4: Green View feature for precise pin positioning.

Shot Tracking and Scorekeeping

AutoShot game tracking automatically detects shot distances. Pair with Approach CT10 club tracking sensors (sold separately) for more detailed tracking. The watch also allows for easy scorekeeping directly on the display.




QUICKFIT BANDS

If you like to change watch bands as often as you change your course, no problem. Choose from interchangeable QuickFit bands.

Figure 3.5: AutoShot game tracking in action.

3.3 Activity Tracking and Smart Features

Beyond golf, the Approach S62 offers preloaded activity profiles for running, cycling, swimming, and more. It also provides smart notifications for calls, texts, and alerts when paired with your smartphone. Garmin Pay allows for contactless payments.



42,000+ PRELOADED COURSES

Your watch comes preloaded with more than 42,000 full-color CourseView maps of golf courses from around the world. Download updates for the course you play most often.

Figure 3.6: Garmin Pay for contactless payments.

Your browser does not support the video tag.

Video 3.1: Official Garmin video showcasing the Approach S62's features including mapping and full-color screen.

4. MAINTENANCE

4.1 Cleaning the Watch

Regularly clean your watch with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the display or ceramic bezel.

4.2 Battery Care

The Approach S62 offers up to 20 hours of battery life in GPS mode and 14 days in smartwatch mode. To prolong battery life, avoid extreme temperatures and fully charge the device before long periods of inactivity.

5. TROUBLESHOOTING

5.1 GPS Signal Issues

If your watch is having trouble acquiring a GPS signal, ensure you are in an open area with a clear view of the sky. Syncing the watch with the Garmin Golf app can also help update satellite data for faster acquisition.

5.2 Display Not Responding

If the touchscreen is unresponsive, try restarting the device by holding down the power button until the watch powers off, then power it back on. If the issue persists, perform a factory reset (refer to the full user manual for instructions).

6. SPECIFICATIONS

Feature	Detail
Model Name	Approach S62
Model Number	010-02200-00
Display Size	1.3 inches
Display Type	Color touchscreen
Bezel Material	Ceramic
Battery Life (GPS Mode)	Up to 20 hours
Battery Life (Smartwatch Mode)	Up to 14 days
Preloaded Courses	Over 41,000 worldwide
Weight	2.08 ounces
Connectivity	Wi-Fi, Bluetooth, ANT+

7. WARRANTY AND SUPPORT

7.1 Warranty Information

The Garmin Approach S62 comes with a 1-year limited warranty. For detailed warranty terms and conditions, please refer to the official Garmin website or the documentation included with your product.

7.2 Customer Support

For further assistance, technical support, or service inquiries, please visit the [Garmin Store](#) or consult the official [User Manual \(PDF\)](#).

