



[Manuals.plus](#) /

> [Disney](#) /

> Disney Lady Cuddleez Plush Instruction Manual - Model 412344170118

Disney 412344170118

Disney Lady Cuddleez Plush Instruction Manual

Model: Lady Cuddleez Plush (412344170118)

[Introduction](#)

[Features](#)

[Safety](#)

[Setup](#)

[Usage](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Support](#)

1. INTRODUCTION

Welcome to the instruction manual for your new Disney Lady Cuddleez Plush. This plush toy is designed for comfort and companionship, featuring a super-soft texture and the beloved character Lady from Disney's *Lady and the Tramp*. Please read this manual carefully to ensure proper care and enjoyment of your product.



Image 1.1: The Disney Lady Cuddleez Plush. This large, soft plush toy is designed for cuddling and comfort, featuring embroidered details and a soft collar.

2. PRODUCT FEATURES

- **Soft Material:** Constructed from plush and vinyl materials for a super-soft, huggable texture.
- **Detailed Design:** Features embroidered facial details, a soft collar, and floppy ears, accurately representing the character Lady.
- **Comfort Size:** Large 25-inch size, ideal for use as a pillow or a comforting cuddle pal.
- **Durable Construction:** Designed for lasting enjoyment.

3. SAFETY INFORMATION

Please observe the following safety guidelines:

- **Age Recommendation:** Suitable for children aged 36 months (3 years) and older.

- **Material Safety:** Made with child-safe plush and vinyl materials.
- **No Small Parts:** This plush toy does not contain small, detachable parts that could pose a choking hazard.
- **Supervision:** Adult supervision is recommended for very young children during play.

4. SETUP

Your Disney Lady Cuddleez Plush requires minimal setup.

1. **Unboxing:** Carefully remove the plush from its packaging.
2. **Fluffing:** Gently pat and reshape the plush to restore its full volume and softness after being compressed during shipping.
3. **Initial Inspection:** Before first use, inspect the plush for any signs of damage or loose stitching. If any issues are found, please contact customer support.

5. USAGE

The Disney Lady Cuddleez Plush is designed for comfort and imaginative play.

- **Cuddling:** Enjoy its soft texture for comforting hugs.
- **Pillow:** Utilize its large size as a soft pillow for naps or relaxation.
- **Playtime:** Engage in imaginative play, recreating scenes from *Lady and the Tramp* or inventing new adventures.
- **Decoration:** Display the plush as a charming decorative item in a bedroom or play area.

6. MAINTENANCE AND CARE

To keep your Lady Cuddleez Plush in optimal condition, follow these care instructions:

- **Spot Cleaning:** For minor spills or dirt, use a damp cloth with mild soap to gently spot clean the affected area. Blot dry with a clean towel.
- **Hand Washing (Recommended):** If a deeper clean is needed, hand wash the plush in cool water with a small amount of mild detergent. Gently squeeze out excess water.
- **Drying:** Air dry thoroughly. Do not machine wash or tumble dry, as this may damage the plush material and shape. Avoid direct sunlight to prevent fading.
- **Avoid Harsh Chemicals:** Do not use bleach or strong cleaning agents.

7. TROUBLESHOOTING

Issue	Possible Cause	Solution
Plush appears flattened or lumpy.	Compression during shipping or prolonged use.	Gently pat and fluff the plush by hand to redistribute the filling.
Stains are difficult to remove.	Type of stain or delayed cleaning.	Attempt spot cleaning with a specialized fabric cleaner suitable for plush toys. If unsuccessful, consider professional cleaning.
Loose stitching or minor damage.	Wear and tear or manufacturing defect.	For minor issues, carefully mend with needle and thread. For significant damage or manufacturing defects, contact Disney customer support.

8. SPECIFICATIONS

Attribute	Detail
Brand	Disney
Model Name	Lady Cuddleez Plush
Model Number	412344170118
UPC	196243003615
Size	Large (Approximately 25 Inches)
Material Type	Plush, Vinyl
Color	Multicolored (Brown, Cream, Blue)
Manufacturer Minimum Age	36 Months
Assembly Required	No
Batteries Required	No

9. WARRANTY AND SUPPORT

For any questions, concerns, or issues regarding your Disney Lady Cuddleez Plush, please contact Disney customer support. Information regarding specific warranty details may be available through the point of purchase or on the official Disney website.

You can visit the official Disney Store for more information: [Disney Store on Amazon](#)

