

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Elk Home](#) /

› [Elk Home Beverly Hills 6-Light Chandelier Instruction Manual - Model 30146/6](#)

Elk Home 30146/6

Elk Home Beverly Hills 6-Light Chandelier Instruction Manual

Model: 30146/6 | Brand: Elk Home

INTRODUCTION

Thank you for purchasing the Elk Home Beverly Hills 6-Light Chandelier. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions thoroughly before beginning installation and retain them for future reference. Proper installation and care will ensure the longevity and optimal performance of your chandelier.

SAFETY INFORMATION

WARNING: Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installation or servicing. Consult a qualified electrician if you are unsure about the installation process.

- Ensure all electrical connections comply with local codes and ordinances, as well as the National Electric Code (NEC).
- This fixture is designed for indoor use only.
- Do not exceed the maximum wattage specified for the bulbs.
- Handle glass components with care to prevent breakage.
- This product may contain chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm. Wash hands after handling.

PACKAGE CONTENTS

Carefully unpack the fixture and check that all components are present and undamaged. Retain all packaging materials until you are certain the fixture is fully assembled and operational.

- Chandelier Frame (Satin Brass Finish)
- White Feathered Glass Shades (6 pieces)
- Mounting Hardware Kit (includes canopy, mounting plate, screws, wire nuts)
- Instruction Manual

Note: Six (6) B10 Candelabra Base (E12) bulbs are required and are **not included** with this fixture. Maximum 60 watts per bulb.

SETUP AND INSTALLATION

Professional installation by a qualified electrician is highly recommended for safety and proper function.

1. **Prepare for Installation:** Turn off the electrical power at the main fuse box or circuit breaker. Clear the work area and gather necessary tools (screwdriver, wire strippers, ladder, etc.).
2. **Mounting Plate Installation:** Attach the mounting plate to the junction box in the ceiling using the provided screws. Ensure it is securely fastened.
3. **Adjust Height (if applicable):** The chandelier features an adjustable height. Determine the desired hanging length and adjust the chain accordingly.
4. **Electrical Connections:** Connect the fixture's wires to the corresponding house wires.
 - Connect the black (or smooth) fixture wire to the black (hot) house wire.
 - Connect the white (or ribbed) fixture wire to the white (neutral) house wire.
 - Connect the bare copper (ground) fixture wire to the green or bare copper (ground) house wire.

Secure connections with wire nuts and wrap with electrical tape for added safety.

5. **Canopy Installation:** Carefully push the wiring into the junction box and secure the canopy to the mounting plate using the provided hardware.
6. **Install Glass Shades:** Gently attach each white feathered glass shade to its respective socket on the chandelier frame. Ensure they are secure but do not overtighten.
7. **Install Bulbs:** Screw in six (6) B10 Candelabra Base (E12) bulbs (not included) into the sockets. Do not exceed 60 watts per bulb.
8. **Restore Power:** Once installation is complete and all components are secure, restore power at the main fuse box or circuit breaker.



Image: The Elk Home Beverly Hills 6-Light Chandelier, featuring a satin brass finish and six white feathered glass shades, suspended from a ceiling mount.

OPERATING INSTRUCTIONS

This chandelier is designed for simple operation via a standard wall switch. It is also compatible with dimmer switches for adjustable light output.

- **Turning On/Off:** Use the connected wall switch to turn the chandelier on or off.
- **Dimming Function:** If connected to a compatible dimmer switch (sold separately), adjust the dimmer to control the brightness of the light. Ensure that the bulbs used are also dimmable.
- **Bulb Replacement:** Before replacing bulbs, ensure the power is turned off at the circuit breaker. Allow bulbs to cool completely. Unscrew old bulbs and screw in new B10 Candelabra Base (E12) bulbs, not exceeding 60 watts each.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your chandelier.

- **Cleaning:** Turn off power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish. For glass shades, a slightly damp cloth can be used, followed by a dry cloth.
- **Inspections:** Periodically check all connections and mounting hardware to ensure they remain secure.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|-------------------------|--|--|
| Light does not turn on. | <ul style="list-style-type: none">• Power is off at the circuit breaker.• Loose wire connections.• Faulty bulb(s).• Faulty wall switch. | <ul style="list-style-type: none">• Check the circuit breaker and ensure power is on.• Verify all wire connections are secure (ensure power is off first).• Replace bulb(s) with new ones.• Test the wall switch or consult an electrician. |
| Light flickers. | <ul style="list-style-type: none">• Loose bulb.• Loose wire connection.• Incompatible dimmer switch or bulb. | <ul style="list-style-type: none">• Tighten bulb(s).• Check wire connections (ensure power is off first).• Ensure dimmer switch and bulbs are compatible. |

SPECIFICATIONS

| | |
|-------------------------------|---|
| Model Number | 30146/6 |
| Dimensions (L x W x H) | 30" x 30" x 22" |
| Weight | 13 Pounds |
| Number of Lights | 6 |
| Bulb Type | B10 Candelabra Base (E12) |
| Max Wattage per Bulb | 60 Watts |
| Voltage | 120 Volts |
| Material | Steel (Frame), Glass (Shades) |
| Finish | Satin Brass |
| Indoor/Outdoor Usage | Indoor |
| Assembly Required | Yes |
| Dimmable | Yes (with compatible dimmer and bulbs) |
| Light Source Type | Incandescent (LED bulb compatible) |
| Color Temperature | 2700 Kelvin (typical for incandescent, depends on bulb) |
| Light Output | Up to 800 Lumens (depending on bulb choice) |

WARRANTY

This Elk Home product is covered by a **1-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper installation, accident, misuse, abuse, or normal wear and tear. For warranty claims, please retain your proof of purchase.

SUPPORT

If you have any questions regarding the installation, operation, or maintenance of your Elk Home Beverly Hills Chandelier,

please contact your retailer or the manufacturer directly. Please have your model number (30146/6) and proof of purchase available when seeking support.

For more information about Elk Home products, you may visit the official Elk Home website or the retailer's product page.

- **Elk Home Store:** [Visit Elk Home Store on Amazon](#)
- **Product Page:** [View Product on Amazon](#)