

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [VIVOHOME](#) /

› VIVOHOME Metal Frame Full Steel Swing Stand (Model VH653) Instruction Manual

## VIVOHOME VH653

# VIVOHOME Metal Frame Full Steel Swing Stand

Model: VH653

Brand: VIVOHOME

## 1. SAFETY INFORMATION

Read and understand all instructions before assembly and use. Failure to follow these instructions may result in serious injury.

- **Maximum Weight Capacity:** This swing stand is designed to hold up to **440 lbs (200 kg)**. Do not exceed this weight limit.
- **Age Recommendation:** Suitable for users over 3 years old. Adult supervision is recommended at all times.
- **Secure Installation:** Always use the provided metal ground pegs to firmly secure the swing stand to the ground. This prevents tipping and ensures stability during use.
- **Level Surface:** Install the swing stand on a flat, level surface to ensure proper balance and prevent instability.
- **Clearance:** Ensure adequate clearance around the swing stand to prevent collisions with obstacles or other individuals.
- **Regular Inspection:** Before each use, inspect all components for wear, damage, or loose connections. Do not use if any part is damaged or missing.
- **Weather Conditions:** Avoid using the swing stand during strong winds, heavy rain, or other adverse weather conditions.


## 2. PACKAGE CONTENTS

Verify that all parts are present before beginning assembly. If any parts are missing or damaged, contact VIVOHOME customer support.

- 16 pieces of steel tubing (various lengths and shapes for the A-frame structure)
- 4 Metal Ground Pegs
- All necessary screws, nuts, and washers
- Assembly tools (e.g., hex keys, wrenches)
- Instruction Manual

# Sturdy Structure

Made of durable powder-coated steel poles



## A-Frame Design

Provide great stability and safety



**Structural Stability**  
Stable bases and safe



**Strong Material**  
Steel tubing frames

Image: Overview of the VIVOHOME Metal Frame Full Steel Swing Stand with a saucer swing attached, highlighting its sturdy A-frame design and structural stability.

## 3. ASSEMBLY INSTRUCTIONS

Assembly typically requires two people and takes approximately 15 minutes. No additional tools beyond those provided are generally needed, except possibly a hammer for ground pegs.

### 3.1 Step-by-Step Assembly

- 1. Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all components against the package contents list.
- 2. Assemble the Top Bar:** Connect the central top bar sections. Ensure the connection points are secure and the U-shaped hooks for hanging swings are correctly oriented.
- 3. Attach A-Frame Legs:** Connect the leg sections to the top bar, forming the A-frame structure. Ensure all bolts are tightened securely. The A-frame design provides a stable base.
- 4. Install Crossbars:** Attach the horizontal crossbars between the A-frame legs to enhance structural rigidity.
- 5. Secure with Ground Pegs:** Once the frame is fully assembled and positioned in its desired location, insert the

four metal ground pegs into the designated holes at the base of each leg. Drive them firmly into the ground using a hammer to ensure maximum stability and prevent movement.

6. **Attach Your Swing:** Use the provided metal hooks or lanyards to securely attach your desired swing (not included) to the U-shaped hooks on the top bar. Ensure the connections are tight and the swing hangs freely.

## Strong Material

Anti-rust, anti-corrosion, and anti-wear



Image: The swing stand in use with two children on a saucer swing, illustrating the 440 lbs weight capacity and the inclusion of four metal ground pegs for enhanced stability.




Image: A detailed view showing how the metal ground pegs are inserted into the ground, providing a secure anchor for the swing stand.

### 3.2 Assembly Video Guide

For a visual guide on the assembly process, please watch the official VIVOHOME video below:

Your browser does not support the video tag.

Video: Official VIVOHOME assembly guide for the Metal Frame Full Steel Swing Stand, demonstrating the step-by-step installation process.

## 4. OPERATION

The VIVOHOME Metal Frame Full Steel Swing Stand is designed to accommodate various types of swings, including saucer swings, disc swings, and yoga ropes. Ensure your chosen swing is compatible with the stand's connection points and weight capacity.

- **Before Each Use:** Always perform a quick safety check. Ensure all bolts are tight, ground pegs are secure, and the swing attachment points are not worn or damaged.
- **Proper Use:** Encourage users to swing safely, avoiding excessive force or movements that could destabilize the stand.
- **Weight Distribution:** For multi-person swings, ensure weight is distributed evenly and does not exceed the 440 lbs capacity.

Swing Chair



Mesh Swing



Disc Swing



Yoga Rope



## Multiple Applications

Suitable for various types of swing and yoga rope

Image: Illustration of the swing stand's versatility, demonstrating its compatibility with various swing types such as swing chairs, mesh swings, disc swings, and yoga ropes.

## 5. MAINTENANCE

Regular maintenance will extend the life of your VIVOHOME swing stand and ensure continued safety.

- **Cleaning:** Clean the steel frame periodically with a damp cloth and mild soap. Avoid abrasive cleaners that could damage the powder-coated finish.
- **Hardware Check:** Annually, or more frequently with heavy use, check all nuts, bolts, and connections for tightness. Retighten as necessary.
- **Rust Prevention:** The frame features a powder-coated paint for anti-rust, anti-corrosion, and anti-wear performance. If scratches or chips occur, touch up with rust-inhibiting paint to prevent corrosion.
- **Ground Pegs:** Periodically check that ground pegs remain firmly in place. Re-secure if they become loose.
- **Storage:** If storing the swing stand for extended periods, especially during winter, disassemble it and store in a dry, protected area to prolong its lifespan.

## 6. TROUBLESHOOTING

### 6.1 Common Issues and Solutions

- **Issue:** Holes do not align during assembly.  
**Solution:** Ensure you are using the correct pieces for each step as per the instructions. Sometimes, slight adjustments or gentle force may be needed to align holes. If misalignment is significant, contact customer support for replacement parts.
- **Issue:** Swing stand feels wobbly or unstable.  
**Solution:** Verify that all bolts are securely tightened. Ensure the stand is placed on a completely level surface. Confirm that the metal ground pegs are fully driven into the ground.
- **Issue:** Missing hardware or parts.  
**Solution:** Double-check the packaging thoroughly. If parts are genuinely missing, contact VIVOHOME customer support immediately for assistance.

## 7. SPECIFICATIONS

Feature	Detail
Brand	VIVOHOME
Model Number	VH653
Material	Alloy Steel (Powder Coated)
Color	Blue & Green
Product Dimensions (D x W x H)	61.5"D x 83"W x 71"H
Item Weight	25 Pounds
Maximum Weight Recommendation	440 Pounds (200 kg)
Required Assembly	Yes
UPC	885469881182

# Product Specification

Package Dimension: 48.8\*6.7\*5.1 Inch

Package Weight: 27.72 lbs.




Image: Diagram illustrating the key dimensions of the swing stand, including height (71"), top width (65"), and base width (83").

## 8. WARRANTY & SUPPORT

VIVOHOME is committed to providing quality products and customer satisfaction. For specific warranty information, returns, or technical support, please refer to the official VIVOHOME website or contact their customer service directly.

- **Online Support:** Visit the official VIVOHOME website for FAQs, product registration, and support resources.
- **Contact Customer Service:** Refer to your purchase documentation or the VIVOHOME website for contact details (phone, email).
- **Proof of Purchase:** Keep your proof of purchase (receipt or order number) for any warranty claims or support inquiries.

For more information about VIVOHOME and their product range, you can visit their brand store:

[VIVOHOME Brand Store](#)

© 2026 VIVOHOME. All rights reserved.

This manual is for informational purposes only.