

[Manuals.plus](#) /

› [DigiKuber](#) /

› DigiKuber SMW Smart Spy Camera Watch User Manual

DigiKuber SMW

DigiKuber SMW Smart Spy Camera Watch User Manual

Model: SMW

INTRODUCTION

The DigiKuber SMW Smart Spy Camera Watch is a versatile wearable device designed for discreet video and audio recording, combined with comprehensive fitness tracking functionalities. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance.

SETUP

1. Charging the Device

Before first use, fully charge your Smart Spy Camera Watch. The device features a wireless USB charging head integrated into the strap, eliminating the need for a separate charging cable. Simply remove the watch strap to reveal the USB charging interface.

- Connect the integrated USB charging head to any universal 5V USB power source, such as a computer USB port, a wall adapter, or a power bank.
- The watch has a 260mAh lithium battery. A full charge provides approximately 10 days of standby time, 1.5 hours of video recording, or 2.5-3 hours of audio recording.

Supports High-Speed TF Card Memory Expansion

Max Support 64GB Class 10 TF Card



Memory Size	8GB	16GB	32GB	64GB
Video Storage	1 Hour	2 Hours	5 Hours	9 Hours

Note: FAT 32 Format is required. It is recommended to purchase a Class 10 High-Speed TF card. Using a low-speed card may invalidate the storage file. Don't use a low-speed or a poor quality memory card on this device.

Figure 1: Charging the Digikuber SMW Smart Spy Camera Watch. Remove the strap to access the integrated USB charger. The image also shows the 260mAh battery capacity and estimated usage times.

2. Inserting the TF Card

The device supports memory expansion via a TF (MicroSD) card. A Class 10 high-speed TF card is recommended for optimal performance, with support for up to 64GB capacity.

- Locate the TF card slot, which is accessible by detaching the bracelet.
- Insert a FAT32 formatted TF card into the slot. Using a low-speed or poor-quality memory card may lead to recording issues or data corruption.



Remove the watch strap
You can see the USB charger of the watch

Large Capacity Battery

Wireless USB charging head, no charging cable required.
Universal 5V USB charging head, general mobile phone charging head and computer USB charging interface can be used as the charging head of this watch.

Standby: 10 days

Video recording: 1.5 hours

Audio recording: 2.5-3 hours



260mAh Lithium Battery

Figure 2: TF Card Slot and Memory Expansion. The watch supports up to 64GB Class 10 TF cards. A table indicates video storage duration based on card size.

3. App Installation and Pairing

To utilize the full range of fitness tracking features and data synchronization, install the companion mobile application.

- Download the **"WellGo"** app from the Apple App Store (for iOS 9.0 and later) or Google Play Store (for Android 4.3 OS and later).
- Enable Bluetooth on your smartphone.
- Open the **"WellGo"** app and follow the on-screen instructions to pair your DigiKuber SMW Smart Spy Camera Watch via Bluetooth 4.0 BLE.



APP : WellGo (Google Play Store & iOS APP Store)

Figure 3: The "WellGo" App Interface. This image displays the smartphone application used to manage and view data from the Smart Spy Camera Watch.

OPERATING INSTRUCTIONS

1. Basic Device Operation

The watch features an OLED high-sensitivity touch screen for navigation and an independent button for recording functions.

- **Touch Screen:** Swipe and tap to navigate through watch faces, fitness data, and settings.
- **Recording Button:** A dedicated, discreet button is used to initiate and stop video and audio recordings.

2. Video Recording

The DigiKuber SMW can record 1080P video. The camera lens is discreetly located under the touch screen, utilizing a patented innovative design.

- To start video recording, press the independent recording button.

- Press the button again to stop recording and save the file to the inserted TF card.

1080P VIDEO RECORDER

With 32GB Memory Card



Figure 4: 1080P Video Recorder. This image highlights the hidden camera lens and the device's capability to record in 1080P, including a 32GB memory card.

3. Audio Recording

In addition to video, the device supports high-quality voice recording.

- Refer to the device's on-screen menu or app settings for specific instructions on initiating audio-only recording.
- Files are saved to the TF card.

4. Fitness Tracker Functions

The Smart Spy Camera Watch doubles as a comprehensive fitness tracker.

- **Activity Tracking:** Monitors steps, distance, and calories burned.
- **Heart Rate Monitor:** Provides real-time heart rate data.
- **Multi-Sports Mode:** Track various activities with dedicated modes.

- **Smart Notifications:** Receive alerts for calls, messages, emails, and social media from your paired smartphone.
- **Additional Features:** Includes alarm clock, calendar, timer, stopwatch, music controller, and a 'Find My Phone' function.



Figure 5: Full Functional Fitness Tracker. This image illustrates the various fitness tracking capabilities of the watch, including heart rate, calorie count, distance, and multi-sport modes.

5. Data Transfer

Recorded files and fitness data can be transferred from the device.

- **For Recorded Files:** Detach the bracelet to access the USB port. Connect the watch to a computer to transfer video and audio files from the TF card. (Note: Direct data transfer via USB is primarily for Android smartphones).
- **For Fitness Data:** Fitness data is synchronized to your smartphone via Bluetooth 4.0 BLE using the "WellGo" app.

DETACHABLE BRACELET



Figure 6: Detachable Bracelet for USB Port and TF Card Slot. This diagram shows how to detach the bracelet to access the USB port for charging and data transfer, and the TF card slot.

MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the watch in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **TF Card:** Periodically back up important recordings from the TF card to a computer. Ensure the TF card is properly formatted (FAT32) and is a Class 10 high-speed card to prevent data loss or recording errors.

TROUBLESHOOTING

- **Device Not Turning On:** Ensure the device is fully charged. Connect it to a power source and check for charging indicators.

- **Recording Issues (Video/Audio):**
 - Check if a TF card is properly inserted and has sufficient free space.
 - Ensure the TF card is formatted to FAT32 and is a Class 10 high-speed card. Low-speed or poor-quality cards can cause recording failures.
 - Verify the battery level; low battery can prevent recording.
- **App Connectivity Problems:**
 - Ensure Bluetooth is enabled on your smartphone and the watch.
 - Make sure the "WellGo" app is installed and updated to the latest version.
 - Check if your smartphone's operating system (iOS 9.0+ or Android 4.3+) is compatible.
 - Try restarting both the watch and your smartphone.
- **Inaccurate Fitness Data:** Ensure the watch is worn snugly on your wrist. Calibrate the device through the "WellGo" app if available.

SPECIFICATIONS

Feature	Detail
Brand	DigiKuber
Model Name	SMW
Connectivity Technology	Bluetooth 4.0 BLE
Special Features	Video Recording, Audio Recording, Fitness Tracker, Heart Rate Monitor, Email/Messages/Call/SNS Notification, Alarm Clock, Calendar, Timer, Stopwatch, Music Controller, Find My Phone
Indoor/Outdoor Use	Outdoor
Compatible Devices	Apple iPhone (iOS 9.0+), Samsung Android Devices (Android 4.3+), Huawei, SONY, LG G5, etc.
Power Source	Battery Powered (260mAh Lithium Battery)
Recommended Uses	Video Recording, Voice Recording, Sport Fitness Tracking
Storage	Max 64GB Class 10 TF Card (FAT32 format required)
Video Recording Time	Approx. 1.5 hours
Audio Recording Time	Approx. 2.5-3 hours
Standby Time	Approx. 10 days

WARRANTY AND SUPPORT

Specific warranty information for the DigiKuber SMW Smart Spy Camera Watch is not provided in the product details. Please refer

to the retailer or manufacturer's official website for warranty terms and conditions.

For technical support or further assistance, please contact DigiKuber customer service through their official channels, typically found on their website or product packaging.

© 2023 DigiKuber. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question