Intex Easy Set 15ft x 42in

INTEX Easy Set 15ft x 42in Inflatable Above-Ground Swimming Pool Instruction Manual

---

INTRODUCTION

This manual provides essential instructions for the safe and efficient setup, operation, and maintenance of your INTEX Easy Set 15ft x 42in Inflatable Above-Ground Swimming Pool. Please read all instructions carefully before installation and use to ensure proper function and safety.

IMPORTANT SAFETY INFORMATION

Dedicated To The Safe Use Of All Of Its Products. While All Accidents Cannot Be Prevented, Practicing Good Safety Habits, Setting And Following Rules, Carefully Reading Instruction Manuals, And Vigilant Supervision Can Greatly Reduce The Likelihood Of Injury As Well As Reduce Injury Severity. Please Take The Time To Review The Following Information, And Make Use Of The Link Provided, To Assist In Keeping You And Your Family Safe From Injury.

PACKAGE CONTENTS

Your INTEX Easy Set Pool package includes the following components:

- 15-foot by 42-inch Inflatable Pool Liner
- Intex Krystal Clear 1000-gallon per hour Filter Pump (Model 28637EG) with 1 cartridge
- Pool Ladder
- Ground Cloth
- Pool Cover

Figure 1: Complete INTEX Easy Set Pool package including pool, pump, and accessories.

Figure 2: Close-up view of the Intex Krystal Clear Filter Pump.

Figure 3: Included pool ladder for safe entry and exit.

SITE PREPARATION

Proper site preparation is crucial for the stability and longevity of your pool. The pool must be set up on a completely level surface. An uneven surface can lead to the pool collapsing or water pooling unevenly, which can cause damage and safety hazards. Ensure the area is free of sharp objects, debris, and excessive vegetation.

A 15-foot pool requires approximately 17 to 18 feet of total space for proper setup, allowing for the pool's footprint and surrounding access.

SETUP INSTRUCTIONS

Follow these steps for quick and easy assembly:

1. **Unpacking and Laying Out:** Carefully unpack the pool liner and accessories. Lay the ground cloth on your prepared level surface. Then, spread the pool liner over the ground cloth, ensuring the drain plug is positioned away from your house or any structures that could be damaged by draining water.

Figure 4: Laying out the pool liner on the ground cloth.

2. **Inflating the Top Ring:** Locate the inflation valve on the top ring of the pool. Use an air pump (not included) to inflate the top ring until it is firm but not over-inflated.

Figure 5: Inflating the top ring of the pool.

Video 1: A quick overview of the Intex Easy Set Pool setup process.

3. **Filling with Water:** Begin filling the pool with water. As the water level rises, the top ring will float, and the pool walls will rise. Smooth out any wrinkles on the bottom of the pool as it fills. Fill the pool to approximately 80% capacity, which is about 3,736 gallons.

Figure 6: Filling the pool with water and smoothing the liner.

4. **Filter Pump Connection:** Connect the Intex Krystal Clear Filter Pump according to the instructions provided in the pump's manual. Ensure all hoses are securely attached to the pool's inlet and outlet fittings.

INTEX®

15 FT POOL SIZE

EASY SET® POOL

Pool Size
15' x 42" (4.57 m. x 106 cm.)

Water Depth
36" (91 cm.)

Water Capacity
3,736 gal. (14,142 L)

Figure 7: Filter pump connected to the pool.

Figure 8: Close-up of the Hydro Aeration Technology outlet, improving water circulation.

OPERATING THE FILTER PUMP

The Krystal Clear Filter Pump is designed to circulate and filter your pool water, enhancing clarity and hygiene. It features Hydro Aeration Technology for improved circulation and water clarity.

- **Daily Operation:** Run the filter pump for 2-10 hours daily, depending on pool usage and water condition. Refer to the pump's specific manual for detailed operating instructions and timer settings.
- **Water Flow:** Ensure the pump is always running when the pool is in use to maintain proper filtration and water movement.

MAINTENANCE

Regular maintenance is essential to keep your pool clean and safe.

- **Water Quality:** Regularly test your pool water for pH and chlorine levels. Adjust chemicals as needed to maintain proper balance. Incorrect chemical levels can damage the pool liner over time.
- **Filter Cartridge:** The filter pump uses a replaceable cartridge. Check and clean the filter cartridge regularly (e.g., every few days) by rinsing it with a garden hose. Replace the cartridge every 2-4 weeks, or more frequently if the water is heavily used or dirty.

- **Pool Cover:** Use the included pool cover when the pool is not in use to prevent debris from entering the water and to reduce evaporation.

Figure 9: Pool cover in place to protect the pool when not in use.

TROUBLESHOOTING

Here are some common issues and their potential solutions:

- **Water Leaks:** Inspect the pool liner for any punctures or tears. Small holes can often be repaired with a vinyl repair kit (sold separately). Check the top inflatable ring for air leaks, as deflation can affect pool stability.
- **Pump Not Circulating Water:** Ensure the pump is plugged in and receiving power. Check that the filter cartridge is clean and not clogged. Verify that all hoses are securely connected and free of kinks.
- **Cloudy Water:** This often indicates insufficient filtration or improper chemical balance. Increase pump running time, clean or replace the filter cartridge, and test/adjust water chemistry.

SPECIFICATIONS

Feature	Specification

Brand	Intex
Pool Size	15 ft (diameter) x 42 in (height)
Water Capacity (80% full)	3,736 Gallons (14,142 L)
Material	Durable 3-ply Vinyl
Filter Pump Flow Rate	1,000 Gallons per hour (3,785 L/hr)
System Flow Rate	750 Gallons per hour (2,839 L/hr)
Maximum Occupancy	8 people
Assembly Time	Approximately 15 minutes (ready for water)

WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please refer to the contact details provided in your product packaging or visit the official Intex website. Keep your model number (B083G1S2JS) handy when contacting support.

Related Documents - Easy Set 15ft x 42in

[INTEX Easy Set Pool Owner's Manual: Setup, Safety, and Maintenance Guide](#)
Comprehensive owner's manual for INTEX Easy Set Pools (6' - 18' models). Includes essential safety rules, setup instructions, maintenance tips, troubleshooting, and warranty information for safe and enjoyable pool use.

[Intex Frame Pool Set Family User Manual - Models 260x160x65cm and Others](#)
Comprehensive user manual for Intex Frame Pool Set Family models, including setup instructions, maintenance guidelines, troubleshooting tips, and warranty information for safe and enjoyable pool use.

[Intex Prism Frame Oval Pool 503x274x122 cm - Model 55213 | Product Information & Safety](#)
Find essential product details and safety warnings for the Intex Prism Frame Oval Pool (Model 55213). Includes dimensions, capacity, included accessories, manufacturer contact, and important usage guidelines.

[Intex Above-Ground Pool FAQ and Winterizing Guide](#)
Comprehensive FAQ for Intex above-ground pools, covering Hydro Aeration system benefits, liner materials, essential winterization steps, proper storage techniques, and GFCI safety information for optimal pool care.

[Intex Krystal Clear Sand Filter Pump SF90110-1 Owner's Manual](#)
Comprehensive owner's manual for the Intex Krystal Clear Sand Filter Pump, Model SF90110-1. Includes setup instructions, operating procedures, maintenance tips, troubleshooting guide, and safety information for above-ground swimming pools.

[Intex Metal Frame Pool Owner's Manual](#)
Comprehensive owner's manual for Intex Metal Frame Pools (8'-24' models), covering safety rules, setup instructions, maintenance, troubleshooting, and warranty information.