

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Skullcandy](#) /

› [Skullcandy Stash Mini Power Bank - Black User Manual](#)

Skullcandy S7PMZ-M003

Skullcandy Stash Mini Power Bank - Black User Manual

Model: S7PMZ-M003 | Brand: Skullcandy

1. INTRODUCTION AND OVERVIEW

The Skullcandy Stash Mini Power Bank is a compact and lightweight portable charger designed to extend the battery life of your electronic devices. With a 5000 mAh capacity, it provides reliable power on the go, ensuring your devices stay charged when you need them most. Its versatile design includes both USB-A and USB-C ports, offering flexible charging options for a wide range of compatible devices.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- Skullcandy Stash Mini Power Bank
- USB-A to dual Micro USB / USB-C Splitter Cable
- User Manual (this document)



Image: Skullcandy Stash Mini Power Bank and its included USB-A to dual Micro USB / USB-C splitter cable.

3. SETUP

3.1 Initial Charging of the Power Bank

Before first use, it is recommended to fully charge your Skullcandy Stash Mini Power Bank. This ensures optimal performance and battery longevity.

1. Connect the provided USB-A to dual Micro USB / USB-C splitter cable to a compatible USB power adapter

(not included).

2. Insert the USB-C end of the splitter cable into the USB-C input port on the power bank, or the Micro USB end into the Micro USB input port.
3. Plug the USB power adapter into a wall outlet.
4. The power percentage display on the power bank will illuminate, indicating the current charge level. The numbers will increase as the power bank charges.
5. Once the display shows 100%, the power bank is fully charged and ready for use.



Image: The Skullcandy Stash Mini Power Bank showing a full 100% charge on its digital display.

4. OPERATING INSTRUCTIONS

4.1 Charging External Devices

The Skullcandy Stash Mini Power Bank can charge various devices using its output ports.

1. Identify the appropriate charging cable for your device. You can use the provided USB-A to dual Micro USB / USB-C splitter cable or your device's original charging cable.
2. Connect the USB-A end of your device's cable (or the USB-A end of the splitter cable) to the USB-A output port on the power bank. Alternatively, connect a USB-C to USB-C cable to the USB-C output port on the power bank.
3. Connect the other end of the cable to your device's charging port.
4. The power bank will automatically begin charging your device. The digital display will show the remaining battery percentage of the power bank.



Image: The power bank connected and charging multiple devices at once.

5. FEATURES

- **Compact and Lightweight:** Designed for portability, easily fitting into pockets, bags, or purses.
- **5000 mAh Battery Capacity:** Provides up to 24 hours of extended battery life for your devices.
- **Flexible Charging Options:** Equipped with one USB-A charging port and one USB-C charging port for broad device compatibility.
- **Power Percentage Display:** A clear digital display shows the exact remaining battery percentage of the power bank.
- **Included Splitter Cable:** Comes with a USB-A to dual Micro USB / USB-C splitter cable for convenience.
- **Durable Construction:** Built to withstand daily use and travel.



Image: A detailed view of the power bank's input/output ports.

6. MAINTENANCE

To ensure the longevity and optimal performance of your Skullcandy Stash Mini Power Bank, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the power bank. Avoid liquid cleaners or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Moisture:** Do not expose the power bank to water or excessive humidity.
- **Regular Charging:** If not used for extended periods, charge the power bank at least once every three months to maintain battery health.
- **Handle with Care:** Avoid dropping or subjecting the power bank to strong impacts.

7. TROUBLESHOOTING

If you encounter issues with your Skullcandy Stash Mini Power Bank, refer to the following common troubleshooting steps:

- **Power Bank Not Charging:**

- Ensure the charging cable is securely connected to both the power bank's input port and the power adapter.
- Verify that the power adapter is functioning correctly and the wall outlet has power.
- Try using a different charging cable or power adapter.

- **Device Not Charging from Power Bank:**

- Check if the power bank has sufficient charge (refer to the digital display).
- Ensure the charging cable is securely connected to both the power bank's output port and your device.
- Try using a different output port on the power bank.
- Test with a different charging cable or device to rule out cable/device issues.

- **Slow Charging:**

- Ensure you are using a high-quality charging cable and a compatible power adapter for optimal charging speeds.
- Some devices may limit charging speed to protect their battery.

- **Digital Display Not Working:**

- Press the power button firmly to activate the display.
- If the power bank is completely depleted, the display may not light up until it receives some charge.

8. SPECIFICATIONS

Product Dimensions	4 x 2.51 x 0.5 inches
Item Weight	4 ounces
Item Model Number	S7PMZ-M003
Battery Type	1 Lithium Polymer batteries (included)
Battery Capacity	5000 Milliamp Hours
Connector Type	USB Type A, USB Type C
Color	Black
Special Feature	Slim
Manufacturer	Skullcandy

9. WARRANTY AND SUPPORT

The Skullcandy Stash Mini Power Bank comes with a 1-year US warranty, ensuring peace of mind for your purchase. For warranty claims, technical support, or any product-related inquiries, please visit the official Skullcandy website or contact their customer service directly.

For further assistance, please refer to the contact information provided on the official Skullcandy website:

www.skullcandy.com/support