

INNOKIN SNS02536

Innokin Kroma R 80W Vape Starter Kit User Manual

Model: SNS02536

INTRODUCTION

Welcome to the user manual for your new Innokin Kroma R 80W Vape Starter Kit. This powerful and compact device is designed to provide an exceptional vaping experience, supporting both Direct-to-Lung (DTL) and Mouth-to-Lung (MTL) vaping styles. Crafted from premium quality zinc alloy with an ergonomic design, the Kroma R fits comfortably in your hand. Please read this manual thoroughly to ensure proper use, maintenance, and safety.

PRODUCT OVERVIEW

Key Features

- Compact and stylish design with premium zinc alloy construction.
- Ergonomic grip for comfortable handling.
- Powered by a single 18650 battery (battery not included).
- Maximum power output of 80W.
- Multiple work modes: Variable Wattage (VW), Variable Voltage (VV), Boost (Soft/Normal/Hard), Bypass, and Curve modes.
- 2A Micro-USB quick charge capability.
- Integrated safety protections for secure operation.
- Compatible with the included 2ml Zlide Tank and optional Innokin Ajax Tank.

Package Contents

- 1 x Innokin Kroma R Mod
- 1 x Innokin Zlide Tank (2ml)
- 1 x USB Charging Cable
- 1 x User Manual (this document)
- (Note: 18650 battery is not included and must be purchased separately.)





Image 1: The Innokin Kroma R 80W Vape Starter Kit, showcasing its sleek silver finish, ergonomic design, and the attached Zlide tank.

SETUP GUIDE

1. Battery Installation

1. Locate the battery door at the bottom of the Kroma R mod.
2. Push the lock mechanism to open the spring-loaded battery door.
3. Insert a fully charged 18650 battery into the battery compartment, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Close the battery door firmly until it clicks into place.

2. Tank Installation

1. Screw the Zlide Tank onto the 510 connector at the top of the Kroma R mod. Turn clockwise until it is finger-tight. Do not overtighten.

3. E-liquid Filling (Zlide Tank)

1. To access the fill port, push the top cap of the Zlide Tank sideways at the indicated arrow. This will reveal the filling slot.
2. Insert the nozzle of your e-liquid bottle into the filling slot and gently squeeze to fill the tank. Do not overfill beyond the maximum fill line.
3. Once filled, push the top cap back into place until it clicks securely.
4. After filling, allow the tank to stand upright for at least 5 minutes to ensure the coil is fully saturated with e-liquid. This prevents dry hits and extends coil life.

OPERATING INSTRUCTIONS

Power On/Off

- To turn the device on or off, rapidly press the fire button (the large side button) three times within two seconds. The screen will display "Innokin" or "System Off".

Adjusting Wattage/Voltage

- Use the '+' and '-' adjustment buttons located below the screen to increase or decrease the wattage or voltage, depending on the selected mode.

Mode Selection

- To enter the mode selection menu, press and hold both the '+' and '-' adjustment buttons simultaneously.
- Navigate through the available modes (VW, VV, Boost, Bypass, Curve) using the '+' and '-' buttons.
- Press the fire button to confirm your selection.
- **VW (Variable Wattage):** Adjust power output in watts.
- **VV (Variable Voltage):** Adjust power output in volts.
- **Boost:** Provides an initial power boost (Soft, Normal, Hard) for a stronger initial hit.
- **Bypass:** Delivers direct battery output, mimicking a mechanical mod (use with caution and knowledge of Ohm's Law).
- **Curve:** Allows custom power output over time for a personalized vaping experience.

Vaping

- Once the device is on and the tank is filled, press and hold the fire button while inhaling from the mouthpiece. Release the button when you finish inhaling.

MAINTENANCE

Cleaning Your Device

- Regularly wipe down the Kroma R mod with a soft, dry cloth to remove dust and e-liquid residue.
- For the tank, disassemble it and rinse components (excluding the coil) with warm water. Ensure all parts are completely dry before reassembly.

Coil Replacement (Zlide Tank)

- When you notice a burnt taste, reduced vapor production, or diminished flavor, it's time to replace the coil.
- Unscrew the tank from the mod.
- Unscrew the base of the tank.
- Pull out the old coil from the base.
- Insert a new Innokin Z-Coil into the base, ensuring it is seated firmly.
- Reassemble the tank and fill with e-liquid, allowing 5 minutes for saturation before use.

Charging the Battery

- Connect the micro-USB cable to the charging port on the Kroma R mod and the other end to a suitable USB power source (e.g., wall adapter, computer USB port).
- The screen will indicate charging status.
- For optimal battery life and safety, it is recommended to charge 18650 batteries using an external dedicated battery charger.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not turning on	Battery low or not inserted correctly; device off.	Charge battery or reinsert correctly; press fire button 3 times rapidly to turn on.
No vapor production	Coil not installed; coil burnt out; tank empty; low wattage.	Ensure coil is installed; replace coil; refill tank; increase wattage.
Burnt taste	Coil burnt out; insufficient e-liquid saturation; wattage too high.	Replace coil; ensure coil is saturated before use; lower wattage.
Leaking from tank	Coil not seated properly; O-rings damaged; overfilling; cracked glass.	Re-seat coil; check/replace O-rings; do not overfill; replace glass if cracked.

SPECIFICATIONS

Product Dimensions	5.7 x 42.5 x 14.5 cm
Item Weight	370 g (0.37 Kilograms)
Wattage Range	Up to 80 watts
Tank Volume	2 Millilitres
Battery Type	Single 18650 (not included)
Charging	Micro-USB, 2A Quick Charge
Material	Zinc Alloy
Color	Silver
Model Number	SNS02536

IMPORTANT SAFETY INFORMATION

LEGAL DISCLAIMER: The following warning only applies when the product is used with nicotine-containing e-liquid, this product contains nicotine which is a highly addictive substance. Keep this product out of the reach of children. Size of cartridge (not exceeding 2ml).

General Safety Precautions

- Do not use the device if it is damaged or has been submerged in water.
- Use only genuine Innokin coils and accessories.
- Do not expose the device to extreme temperatures or direct sunlight.
- Keep the device and e-liquids out of reach of children and pets.
- Always use high-quality, authentic 18650 batteries from reputable manufacturers.
- Never leave charging devices unattended, especially overnight.
- Dispose of batteries and electronic components responsibly according to local regulations.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included in your product packaging or visit the official Innokin website. If you encounter any issues not covered in this manual, please contact Innokin customer service for assistance.

