

[manuals.plus](#) /

- › [Donner](#) /
- › [Donner DLP-124S LP Electric Guitar Beginner Kit User Manual](#)

Donner DLP-124S

Donner DLP-124S LP Electric Guitar Beginner Kit User Manual

Model: DLP-124S

INTRODUCTION

Welcome to the world of music with your new Donner DLP-124S LP Electric Guitar Beginner Kit. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your instrument. Designed for beginners, this kit offers a complete package to start your musical journey.



Image: The Donner DLP-124S LP Electric Guitar in Sunburst finish, accompanied by its gig bag, guitar strap, and instrument cable.

**CLASSIC
DELICATE
AND
WORK**

*Vintage White Binding
Purfling Strip*




Image: A close-up view of the guitar body, highlighting the vintage white binding and purfling strip, indicative of its classic design and craftsmanship.

SETUP AND INITIAL PREPARATION

1. Unboxing and Inspection

Carefully remove all components from the packaging. Inspect the guitar and accessories for any signs of damage. The kit

includes:

- Donner DLP-124S LP Electric Guitar
- Gig Bag
- Guitar Strap
- Instrument Cable (6.35mm jack plug)
- Hex Wrench (for truss rod adjustments, if needed)




Image: A visual representation of the included accessories: gig bag, guitar cable, guitar strap, and a finger/thumb rest.

2. Attaching the Guitar Strap

Locate the two strap buttons on the guitar body. Securely attach the guitar strap to these buttons. Ensure the strap is firmly attached before playing.

3. Connecting to an Amplifier

Insert one end of the instrument cable into the guitar's output jack (located on the side of the body). Connect the other end to your amplifier's input jack.

4. Tuning the Guitar

Before playing, tune your guitar. Standard tuning from thickest to thinnest string is E-A-D-G-B-e. Use an electronic tuner for accuracy. Turn the tuning pegs slowly to adjust the pitch of each string.

OPERATING YOUR GUITAR

1. Humbucker Pickups

Your Donner DLP-124S is equipped with two Donner 202S humbucker pickups. These pickups are designed to reduce noise and hum, providing a richer and more powerful, balanced tone suitable for various music genres including rock, blues, and more.

DONNER 202S

H-H PICKUPS



- *Richer and Powerful*
- *Balanced Tone*
- *Full Intermediate Frequency*




Image: A detailed view of the Donner 202S Humbucker Pickups, highlighting their design for rich and powerful sound.

2. Controls: Volume, Tone, and Pickup Switch

The guitar features a 3-way pickup selector switch, a master volume knob, and two tone knobs to shape your sound.

- **Volume Knob:** Controls the overall output volume of the guitar.
- **Tone Knobs:** Adjust the treble frequencies for each pickup. One tone knob typically controls the neck pickup, and the other controls the bridge pickup.

- **3-Way Pickup Switch:** Selects which pickup(s) are active.
 - **Up Position (Rhythm):** Activates the neck pickup, producing a warmer, mellower tone.
 - **Middle Position:** Activates both neck and bridge pickups, offering a balanced sound.
 - **Down Position (Treble):** Activates the bridge pickup, producing a brighter, sharper tone.



Image: A close-up of the guitar's control knobs and the 3-way pickup switch, labeled for Volume, Tone, and Pickup Selection (Rhythm/Treble).

3. Playing Techniques

Experiment with different pickup selections and knob settings to discover a wide range of tones. Practice basic chords, scales, and strumming patterns. Online resources and guitar lessons can further enhance your playing skills.

MAINTENANCE AND CARE

1. Cleaning Your Guitar

After each use, wipe down the strings and body with a soft, dry cloth to remove sweat and oils. For the body, a guitar-specific polish can be used occasionally. Clean the fretboard with a suitable fretboard conditioner to prevent drying and cracking, especially if it appears dry.

2. String Replacement

Strings should be replaced regularly, typically every 1-3 months depending on usage, or when they sound dull or show signs of corrosion. Your guitar comes with Nickel Steel strings. When replacing, change one string at a time to maintain neck tension.

3. Environmental Considerations

Store your guitar in its gig bag when not in use to protect it from dust, humidity changes, and accidental damage. Avoid exposing the guitar to extreme temperatures or sudden changes in humidity, as this can affect the wood and playability.

4. Action and Intonation

The "action" (string height) and "intonation" (accuracy of notes across the fretboard) are factory-set. Over time, or with changes in climate, these may require adjustment. For precise adjustments, especially for the truss rod, it is recommended to consult a qualified guitar technician.

TROUBLESHOOTING COMMON ISSUES

- Buzzing Strings:** This can be caused by low action, uneven frets, or improper technique. Check string height at the bridge and nut. If frets are uneven, professional attention may be required.
- Poor Intonation:** If notes sound out of tune as you move up the fretboard, the intonation may need adjustment at the bridge saddles. This is best done by a technician.
- No Sound from Amplifier:** Ensure the instrument cable is securely connected to both the guitar and amplifier. Check the amplifier's power and volume settings. Test with a different cable or amplifier if possible.
- Stiff Tuning Pegs:** New tuning pegs can sometimes be stiff. Regular use typically loosens them. If they remain excessively stiff, a small amount of lubricant designed for guitar hardware may be applied, or consider professional inspection.
- Noisy Pickups:** While humbuckers reduce noise, some ambient electrical interference can still occur. Ensure proper grounding of your amplifier and power outlets.

SPECIFICATIONS

Feature	Detail
Model Number	DLP-124S
Body Material	Poplar Wood

Feature	Detail
Neck Material	Okoume Wood
Fretboard Material	Laurel Wood
Number of Frets	22 (Copper-nickel)
Scale Length	648 mm
Pickup Configuration	H-H (Humbucker-Humbucker)
String Material	Nickel Steel
Bridge System	Fixed
Connector Type	6.35mm jack plug
Color	Sunburst
Dimensions	40.75 x 16.93 x 4.72 inches
Item Weight	13.05 pounds

PRODUCT INFORMATION

39 INCH




Image: A diagram illustrating key product information and material components of the 39-inch Donner electric guitar, including Maple, Laurel Wood, Nickel, H-H pickups, and Basswood.

WARRANTY AND SUPPORT

Warranty Information

Donner products typically come with a warranty. Please refer to the official Donner website or your purchase

documentation for specific warranty terms and conditions.

Customer Support

For further assistance, technical support, or inquiries, please visit the official Donner store or contact their customer service.


[Visit the Donner Store on Amazon](#)

You can also find a User Guide (PDF) for additional information:

[Download User Guide \(PDF\)](#)

© 2025 Donner. All rights reserved.

Related Documents - DLP-124S

	<p>Donner Electric Guitar User Manual: Setup, Tuning, and Maintenance Guide</p> <p>Comprehensive user manual for Donner electric guitars, featuring the 'Create Your Music Moment' theme. Covers setup, string replacement, tuning, intonation, and maintenance. Includes safety guidelines. Visit donnermusic.com for more.</p>
	<p>Donner HUSH-I Silent Guitar User Manual - Setup, Tuning, and Specifications</p> <p>Comprehensive user manual for the Donner HUSH-I Silent Guitar. Learn about setup, assembly, tuning, string changing, power supply, specifications, and FCC compliance.</p>
	<p>Donner HUSH-X User Manual</p> <p>User manual for the Donner HUSH-X electric guitar, providing instructions on assembly, adjustments, maintenance, and specifications.</p>
	<p>Donner HUSH-X PRO User Manual: Create Your Music Moment</p> <p>Comprehensive user manual for the Donner HUSH-X PRO multi-effects electric guitar. Learn about setup, features, operation, and maintenance to create your perfect music moment.</p>
	<p>Donner HUSH-X Guitar User Manual</p> <p>Comprehensive user manual for the Donner HUSH-X Guitar, covering setup, maintenance, and specifications. Learn how to assemble the stand, adjust the neck, replace strings, and understand the interface module and power supply.</p>
	<p>Donner HUSH-I Silent Guitar User Manual</p> <p>Comprehensive user manual for the Donner HUSH-I Silent Guitar, covering setup, operation, maintenance, and specifications. Learn how to assemble the stand, tune the guitar, change strings, and use the gig bag.</p>

