

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [HONEY JOY](#) /

› [HONEY JOY 6-in-1 Inflatable Water Slide & Bouncer Park User Manual \(Model B083JSTS9Y\)](#)

HONEY JOY B083JSTS9Y

HONEY JOY 6-in-1 Inflatable Water Slide & Bouncer Park User Manual

Brand: HONEY JOY | Model: B083JSTS9Y

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the HONEY JOY 6-in-1 Inflatable Water Slide and Bouncer Park. This versatile play structure is designed to provide hours of fun for children aged 3-10 years. It integrates multiple activities including double water slides with heightened rails, a climbing wall with a buffer platform, an 8-inch deep splash pool, water cannons, and a basketball rim. The product is constructed from durable 840D Oxford fabric for enhanced wear and tear resistance, ensuring a safe and enjoyable experience.

This manual provides essential information for the safe and proper setup, operation, and maintenance of your inflatable water park. Please read all instructions carefully before use.



Figure 1: Overview of the HONEY JOY 6-in-1 Inflatable Water Slide and Bouncer Park.

2. SETUP INSTRUCTIONS

Proper setup is crucial for safety and optimal performance. Follow these steps carefully:

1. **Unpack and Unroll:** Take the inflatable water slide out of its carrying bag and unroll it completely on a flat, clear grassy area. Ensure there are no sharp objects underneath or nearby.
2. **Connect Blower:** Connect the air blower to the air outlet tube of the inflatable. Tie off the air outlet securely around the blower nozzle.
3. **Inflate:** Plug in the 480W air blower (included) and turn it on. The water park should inflate within approximately 5 minutes. Note: This water bounce house requires constant air to stay inflated, so it is normal for air to escape from several parts.
4. **Secure to Ground:** Use the 8 bouncer stakes provided to secure the inflatable firmly to the ground for stability.

5. **Connect Water Hose:** Attach your garden hose to the water tube connection points on the inflatable. Ensure all connections are tight to prevent leaks.
6. **Activate Water Features:** Turn on the water supply to activate the water cannons, sprinklers, and water flow for the slides.



Figure 2: Connecting the 480W air blower for inflation.

Package Accessories



1 x Air Blower



1 x Carrying Bag



1 x Hose Assembly Kit



8 x Bouncer Stake



1 x Inflatable Basketball



4 x Repair Patch



Figure 3: Included accessories for setup and play.

Setup Video Guide

Your browser does not support the video tag. This video demonstrates the setup process for the HONEY JOY Inflatable Water Slide, showing how to unroll, connect the blower, inflate, and secure the unit. It also highlights the water features.

Video 1: HONEY JOY Inflatable Water Slide Setup Overview.

3. OPERATING INSTRUCTIONS

Ensure children are supervised at all times while using the water park.

- **Sliding:** Children can enjoy the double slides. Ensure they slide feet-first and one at a time to prevent collisions.
- **Climbing Wall:** The climbing wall features handles and footholds for easy ascent. A buffer platform is provided at the top for safety before sliding.

- **Splash Pool:** The 8-inch deep splash pool is suitable for younger children. Always monitor water levels and ensure children are comfortable.
- **Water Cannons & Basketball Rim:** Engage in interactive play with the water cannons and practice shooting hoops with the inflatable basketball.



Double Water Slides



Climbing Wall



Basketball Rim



Water Cannon



Figure 4: Various play features of the water park.



Figure 5: Children enjoying the water park features.

4. MAINTENANCE

Regular maintenance ensures the longevity and safety of your inflatable water park.

- **Drying:** Always ensure the water slide is completely dry before rolling and storing it in the carry bag. This prevents mold and mildew growth.
- **Cleaning:** Clean the surface with mild soap and water. Avoid harsh chemicals that could damage the fabric.
- **Repair Patches:** In case of small punctures, use the provided repair patches. Clean the area around the puncture, apply the patch firmly, and allow it to cure completely before re-inflating.
- **Storage:** Store the dry, deflated water park in its carrying bag in a cool, dry place away from direct sunlight and extreme temperatures.

420D + 840D Oxford Fabric



Waterproof



Tear-resistant



Not Easy to Fade



Double Stitch Seams



Safety Netting



Supportive Handle



Hose Fastener

Figure 6: Durable Oxford fabric and construction details.

5. TROUBLESHOOTING

Here are some common issues and their solutions:

- **Inflatable not fully firm:** This water bounce house requires constant air to stay inflated. It is normal for some air to escape from seams or other parts. Ensure the blower is continuously running and the air outlet tube is securely tied.
- **Water features not working:** Check that the garden hose is properly connected and the water supply is turned on. Ensure there are no kinks in the hose.
- **Blower not working:** Check the power connection and ensure the blower's switch is in the 'ON' position. Avoid using the air blower outdoors on rainy days and keep the plug dry.
- **Small holes/leaks:** Use the provided repair patches to fix small punctures. Follow the instructions for patch application carefully.

6. SPECIFICATIONS

Feature	Detail
Overall Dimensions	157.5"L x 142"W x 100.5"H
Item Weight	48 Pounds
Recommended Age	3-10 years old
Maximum Weight Capacity (Inflatable Part)	350 lbs
Individual Weight Limit	116 lbs
Maximum Number of Kids	3
Blower Power	480W (120V/60Hz, UL certified)
Material	840D Oxford Fabric

Product Dimensions



Figure 7: Product dimensions and blower details.

7. WARRANTY AND SUPPORT

For detailed warranty information, product support, or to purchase replacement parts, please refer to the manufacturer's official website or contact HONEY JOY customer service directly. Keep your purchase receipt for warranty claims.