

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Dolphin](#) /
- › [Dolphin Nautilus CC Supreme Wi-Fi Automatic Robotic Pool Vacuum Cleaner Instruction Manual](#)

## Dolphin Nautilus CC Supreme

# Dolphin Nautilus CC Supreme Wi-Fi Automatic Robotic Pool Vacuum Cleaner Instruction Manual

Model: Nautilus CC Supreme

[Instructions](#)   [Maintenance](#)   [Overview](#)   [Setup](#)   [Operating](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## PRODUCT OVERVIEW

---

The Dolphin Nautilus CC Supreme is an automatic robotic pool vacuum cleaner designed for in-ground pools up to 50 feet. It features Wi-Fi connectivity for remote scheduling, dual drive for precise movement, waterline scrubbing, and active scrubbing brushes for comprehensive cleaning. Its top-load filter system ensures easy maintenance.



Figure 1: Dolphin Nautilus CC Supreme Robotic Pool Cleaner. This image shows the top-down view of the black and blue robotic pool cleaner with its handle and filter access visible.

## SETUP INSTRUCTIONS

---

- 1. Unpacking:** Carefully remove the Dolphin Nautilus CC Supreme from its packaging. Ensure all components, including the robotic cleaner, power supply unit, filter cartridges, user manual, quick start guide, and registration card, are present.
- 2. Power Supply Placement:** Place the power supply unit at least 12 feet (3.6 meters) from the edge of the pool. Ensure it is not exposed to direct sunlight or rain. The power supply is water-resistant, not waterproof.
- 3. Connect Power Supply:** Plug the power supply unit into a grounded electrical outlet.
- 4. Connect Cleaner to Power Supply:** Connect the floating cable from the robotic cleaner to the power supply unit. Ensure the connection is secure.
- 5. Place Cleaner in Pool:** Gently lower the robotic cleaner into the pool. Allow it to sink to the bottom. Ensure there are no air bubbles trapped inside the cleaner.
- 6. Wi-Fi Setup (Optional):**
  - Download the MyDolphin™ Plus app from your smartphone's app store.
  - Follow the in-app instructions to connect your Dolphin Nautilus CC Supreme to your home Wi-Fi network. This allows for remote control and scheduling.

# PRODUCT ANATOMY

## Nautilus CC Supreme

### Easy-Access Top Load Filter

Open the top, pull the filter basket out and rinse

### Lightweight

Easy lifting and handling

### Ergonomic Handle

Easy lift handle for better grip of robot

### Dual Drive

Strategic, agile movement navigates around obstacles easily



maytronics | Dolphin

Figure 2: Product Anatomy. This image highlights key components like the easy-access top-load filter, ergonomic handle, lightweight design, and dual drive system.

## OPERATING INSTRUCTIONS

The Dolphin Nautilus CC Supreme offers various cleaning modes and scheduling options for optimal pool maintenance.

### Cleaning Modes:

- **Floor Only:** Cleans only the pool floor.
- **Regular:** Cleans the pool floor, walls, and waterline. (Estimated cycle time: 2.5 hours)
- **Ultra Clean:** Provides an extra thorough cleaning of the floor, walls, and waterline.
- **Waterline:** Focuses specifically on cleaning the pool walls and waterline.

## Starting a Cleaning Cycle:

1. Ensure the cleaner is properly submerged in the pool and the power supply is connected.
2. Press the power button on the power supply unit or use the MyDolphin™ Plus app to start a cleaning cycle.
3. Select your preferred cleaning mode and cycle time (1.5 hours, 2.5 hours, or 3.5 hours) via the app.
4. The cleaner will automatically begin its cycle.

## Scheduling:

Use the MyDolphin™ Plus app to set a weekly cleaning schedule. You can choose to clean every day, every 2 days, or every 3 days. The cleaner will operate automatically according to your set schedule.

## Manual Drive:

For targeted cleaning, use the manual drive feature in the MyDolphin™ Plus app to steer the cleaner to specific areas of the pool.

Your browser does not support the video tag.

Video 1: Dolphin Nautilus CC Supreme Overview. This video demonstrates the robotic cleaner's features and operation in a pool environment, including its movement and cleaning capabilities.

## MAINTENANCE

---

Regular maintenance of your Dolphin Nautilus CC Supreme ensures optimal performance and longevity.

### Filter Cleaning:

1. **Remove Cleaner from Pool:** After each cleaning cycle, gently pull the cleaner out of the pool using the floating cable.
2. **Access Filters:** The Dolphin Nautilus CC Supreme features an easy-access top-load filter system. Open the top cover of the cleaner.
3. **Remove Filter Basket:** Pull out the filter panel or basket.
4. **Rinse Filters:** Rinse the filter cartridges thoroughly with a garden hose to remove all debris.
5. **Reinsert Filters:** Place the clean filter cartridges back into the cleaner and close the top cover.

# Easy-Access Top Load Filter



Open the top, pull the filter panel out, and rinse




Figure 3: Easy-Access Top Load Filter. This image shows the top of the cleaner open with the filter basket removed, illustrating the ease of access for cleaning.



Figure 4: Interchangeable Filters. This image displays various filter options, indicating the cleaner's adaptability to different debris levels.

## TROUBLESHOOTING

---

- **Cleaner Not Moving/Stuck:**

- Check if the filter basket is full and clean it if necessary.
- Ensure the power supply unit is properly connected and powered on.
- Verify that the floating cable is not tangled or obstructing movement.
- Inspect the brushes for any debris that might be causing obstruction.

- **Poor Cleaning Performance:**

- Clean the filter cartridges thoroughly.
- Ensure the pool water chemistry is balanced.

- Select the appropriate cleaning mode (e.g., "Ultra Clean" for heavy debris).
- **Wi-Fi Connection Issues:**
  - Ensure the power supply unit is within Wi-Fi range of your router.
  - Restart the power supply unit and your Wi-Fi router.
  - Re-pair the cleaner with the MyDolphin™ Plus app.

## SPECIFICATIONS

---

<b>Brand</b>	Dolphin
<b>Model Name</b>	Nautilus CC Supreme
<b>Item Model Number</b>	Nautilus 60 CC Supreme
<b>Power Source</b>	AC/DC
<b>Control Method</b>	App (Wi-Fi)
<b>Item Weight</b>	24.6 Pounds
<b>Product Dimensions</b>	23"L x 19.1"W x 13.8"H
<b>Material</b>	Plastic
<b>Color</b>	Black
<b>Special Feature</b>	Lightweight
<b>Installation Type</b>	Robotic
<b>UPC</b>	850015249051

## WARRANTY & SUPPORT

---

The Dolphin Nautilus CC Supreme comes with a Standard Manufacturer's Warranty. For detailed information regarding warranty coverage, terms, and conditions, please refer to the included Registration Card or contact Dolphin customer support.

For technical assistance, troubleshooting, or any product-related inquiries, please visit the official Dolphin website or contact their customer service department. Contact information can typically be found in the user manual or on the manufacturer's website.

