

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Motast](#) /
- › [Motast I07 Wireless Earbuds User Manual](#)

Motast I07

Motast I07 Wireless Earbuds User Manual

Model: I07 | Brand: Motast

INTRODUCTION

Thank you for choosing Motast I07 Wireless Earbuds. This manual provides essential information for setting up, operating, and maintaining your new earbuds. Please read it carefully to ensure optimal performance and longevity of your device.

PRODUCT OVERVIEW

The Motast I07 Wireless Earbuds are designed for a high-quality audio experience with convenience and durability. Key features include Bluetooth 5.0 connectivity, Hi-Fi stereo sound, noise cancelling microphone, deep bass, and IPX7 waterproofing.



Image: Motast I07 Wireless Earbuds and their charging case.

EXPERTLY TUNED DEEP BASS

Premium sound quality for music and crystal clear call with latest Bluetooth 5.1 system.



Image: Illustration highlighting the expertly tuned deep bass feature of the earbuds.

IP7 WATERPROOF

Resistant to sweat, water and rain.



Image: Earbuds shown with water droplets, indicating their IPX7 waterproof resistance to sweat, water, and rain.

SETUP

Pairing the Earbuds

The Motast I07 earbuds feature automatic pairing. Once removed from the charging case, they will attempt to connect to the last paired device. For initial pairing or if connection issues occur, follow these steps:

1. Ensure Bluetooth is turned off on your device (e.g., smartphone, tablet).
2. Remove both earbuds from the charging case. They will automatically power on and attempt to pair with each other.
3. Once paired with each other (indicated by a specific light pattern, usually one earbud's light flashing and the other off or solid), turn on Bluetooth on your device.
4. Search for "I07" in the list of available Bluetooth devices and select it to connect.
5. A voice prompt will confirm successful connection.

AUTO PAIRING

I07 connects with the last paired device when removed from the charging case.



Image: Earbuds in charging case, illustrating the auto-pairing feature with a smartphone and laptop.

Resetting the Earbuds

If the left and right earphones cannot be paired with each other or with your device, please reset them to factory settings:

1. Delete all Bluetooth device names of "I07" from your device's Bluetooth list.
2. Turn off the Bluetooth function on your device.
3. Hold the control buttons of both earbuds for 6 seconds simultaneously to initialize them.
4. Place both earbuds back into the charging case to ensure they have power, then close the charging case.
5. Take out both earbuds. Both earbuds will flash a blue light. When the two earbuds no longer flash simultaneously and the blue light remains solid, they are successfully paired with each other.
6. After that, turn on Bluetooth on your device and select "I07" to connect.

OPERATING INSTRUCTIONS

Touch Controls

The Motast I07 earbuds feature touch-sensitive controls for various functions:



Image: Diagram illustrating the touch control functions for calls, music, and voice assistant activation.

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.
- **Volume Up:** Triple tap the right earbud.
- **Volume Down:** Triple tap the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Activate Voice Assistant (Siri/Google Assistant):** Press and hold either earbud for 3 seconds.

Single Earbud Mode

Both the left and right earbuds can be used independently. Simply leave one earbud in the charging case if you only wish to use a single earbud.

CHARGING

To charge your Motast I07 Wireless Earbuds and their charging case:

- **Charging the Earbuds:** Place the earbuds into the charging case. The LED indicators on the earbuds will light

up to show they are charging. The digital display on the case will show the charging status of the earbuds.

- **Charging the Case:** Connect the charging case to a USB power source using the provided USB-C cable. The digital display on the case will show the battery percentage of the case.

A full charge provides approximately 6 hours of consistent playtime. The charging case holds multiple charges, extending the total usage time significantly.



Image: Graphic indicating 6 hours of consistent playtime for the earbuds.

MAINTENANCE

To ensure the longevity and optimal performance of your Motast I07 Wireless Earbuds:

- Clean the earbuds and charging case regularly with a soft, dry cloth.
- Avoid using abrasive cleaners or solvents.
- Keep the charging contacts on both the earbuds and the case clean and free of debris.
- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Avoid exposing the earbuds to extreme temperatures or direct sunlight for extended periods.

TROUBLESHOOTING

If you encounter issues with your Motast I07 Wireless Earbuds, try the following solutions:

- **Earbuds not pairing with each other:** Perform a factory reset as described in the "Resetting the Earbuds" section.
- **Earbuds not connecting to device:** Ensure Bluetooth is enabled on your device and the earbuds are in pairing mode. Try forgetting the device in your Bluetooth settings and re-pairing.
- **No sound from one earbud:** Place both earbuds back in the charging case, close it, then take them out again to re-establish the connection between them. If the issue persists, perform a factory reset.
- **Charging issues:** Ensure the charging contacts on both the earbuds and the case are clean. Check that the USB-C cable is securely connected to both the case and the power source.
- **Low volume or poor sound quality:** Ensure the earbuds are properly seated in your ears. Try adjusting the volume on your connected device. Clean any earwax or debris from the earbud nozzles.

SPECIFICATIONS

Detailed technical specifications for the Motast I07 Wireless Earbuds:

Feature	Specification
Model Name	I07
Brand	Motast
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.0
Wireless Communication Technology	Bluetooth
Water Resistance Level	IPX7 (Water Resistant)
Noise Control Features	Active Noise Cancellation
Control Type	Call Control, Remote
Earpiece Shape	Rounded tips (In Ear)
Audio Driver Type	Dynamic Driver
Item Weight	3.5 Grams (0.124 ounces)
Product Dimensions	1.18 x 1.18 x 0.79 inches
Battery Life	Up to 6 hours playtime per charge (earbuds)
Batteries Required	2 Lithium Polymer batteries
Compatible Devices	Laptops, Desktops, Tablets, Telephones, Smart Speakers, Televisions, Car Audio Systems, Cellphones

Feature	Specification
Special Features	Lightweight, Microphone Included, Noise Cancellation, USB connectivity, Universal, Sports-and-exercise, Water-resistant, Wireless

SECURED FIT & ULTRA LIGHT

Super Light-weight Design, fit comfortably in your ear



Image: Dimensions of the earbuds and charging case, highlighting their secured fit and ultra-light design.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Motast website. Keep your proof of purchase for warranty claims.