

NERF E9961

Nerf Elite 2.0 Phoenix CS-6 Motorized Blaster User Manual

Brand: NERF | Model: E9961

INTRODUCTION

Welcome to the world of Nerf Elite 2.0! The Nerf Elite 2.0 Phoenix CS-6 motorized blaster is designed for enhanced performance and customization, allowing you to adapt your blaster for any mission or battle. This manual provides essential information for setup, operation, and maintenance to ensure optimal performance and safety.

The Phoenix CS-6 features 5 tactical rails, a stock attachment point, and a barrel attachment point for extensive customization. It comes with a 6-dart clip and 12 Official Nerf darts, firing darts up to 90 feet (27 meters). Eyewear is recommended for safety.

WHAT'S IN THE BOX

- Nerf Elite 2.0 Phoenix CS-6 Blaster
- Removable Scope
- 6-Dart Clip
- 12 Official Nerf Darts
- Instructions Manual (this document)



Image: The Nerf Elite 2.0 Phoenix CS-6 blaster shown in its retail packaging, highlighting the included scope, 6-dart clip, and 12 darts.

SETUP

1. Battery Installation

The Nerf Elite 2.0 Phoenix CS-6 requires 4 AA batteries (not included) for its motorized blasting feature. To install batteries:

1. Locate the battery compartment on the blaster.
2. Using a Phillips head screwdriver (not included), unscrew the battery compartment cover.
3. Insert 4 AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the cover and secure it with the screw.

Important: Always use fresh batteries and replace all four batteries at the same time. Do not mix old and new batteries or different types of batteries.

2. Attaching Accessories

The Phoenix CS-6 blaster is designed for customization with its tactical rails, stock attachment point, and barrel attachment point.

- **Scope:** The included scope can be attached to the tactical rail on top of the blaster. Slide the scope onto the rail until it clicks into place.

- **Other Attachments:** Additional Nerf Elite 2.0 accessories (sold separately), such as stocks and barrel extensions, can be attached to their respective points for enhanced play.



Image: The back of the product box illustrates the various attachment points on the Nerf Elite 2.0 Phoenix CS-6 blaster, including tactical rails, stock, and barrel attachment points.

OPERATING INSTRUCTIONS

1. Loading the Darts

The Phoenix CS-6 uses a 6-dart clip. To load darts:

1. Insert the 12 Official Nerf Darts into the 6-dart clip, pushing them in until they are fully seated. Ensure the darts are inserted correctly to prevent jamming.
2. Insert the loaded clip into the blaster's magazine well until it clicks securely into place.



Image: The Nerf Elite 2.0 Phoenix CS-6 blaster is displayed alongside its 6-dart clip and 12 Official Nerf Darts, ready for loading.

2. Firing the Blaster

The Phoenix CS-6 is a motorized blaster, offering rapid-fire action.

1. Hold down the acceleration button (located below the trigger) to power up the motor. You will hear the motor whirring.
2. While holding the acceleration button, press the trigger to fire one dart at a time.
3. Release the acceleration button when you are finished firing or need to conserve battery life.

Safety Warning: Do not aim at eyes or face. Use of eyewear is recommended for players and people within range. Use only official NERF darts. Other darts may not meet safety standards. Do not modify darts or blaster.

Your browser does not support the video tag.

Video: An official demonstration of the Nerf Elite 2.0 Phoenix Blaster, showcasing its features and motorized firing mechanism.

MAINTENANCE

Proper maintenance will extend the life of your Nerf blaster:

- **Cleaning:** Wipe the blaster with a damp cloth to remove dirt and dust. Do not submerge the blaster in water or use harsh chemicals.
- **Dart Care:** Keep darts clean and free from debris. Bent or damaged darts may affect performance and cause jamming. Replace worn-out darts with Official Nerf Darts.
- **Storage:** Store the blaster and darts in a cool, dry place away from direct sunlight and extreme temperatures. Remove batteries if the blaster will not be used for an extended period.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Blaster not firing / Motor not spinning	Batteries are low or incorrectly installed. Dart jam.	Check battery polarity and replace all 4 AA batteries if needed. Ensure no darts are stuck in the barrel or clip mechanism. Clear any obstructions carefully.
Darts not firing far enough	Worn or damaged darts. Motor not fully powered up.	Use new, Official Nerf Darts. Ensure the acceleration button is held down completely before firing.
Clip not inserting/removing easily	Clip is not aligned correctly. Debris in the magazine well.	Ensure the clip is aligned with the magazine well and pushed firmly until it clicks. Check for and remove any debris from the magazine well.

SPECIFICATIONS







- **Product Dimensions:** 2.63 x 16 x 12.5 inches
- **Item Weight:** 1.54 pounds
- **Model Number:** E9961
- **Manufacturer:** Hasbro
- **Recommended Age:** 8 years and up
- **Batteries:** 4 AA batteries required (not included)
- **Release Date:** July 27, 2020

WARRANTY & SUPPORT

For detailed warranty information and further support, please refer to the official user manual PDF or contact Hasbro customer service.

[Download Official User Manual \(PDF\)](#)

Related Documents - E9961

	<p>Nerf N-Strike Elite Strongarm Blaster: User Guide</p> <p>Official instructions for the Nerf N-Strike Elite Strongarm toy blaster. Learn how to load darts, fire single shots, and use the slam-fire feature for rapid firing. Includes safety warnings and product details.</p>
	<p>Nerf Rough Cut 2X4 Elite Blaster User Manual</p> <p>User manual for the Nerf Rough Cut 2X4 Elite Blaster, detailing its features, operation, and safety precautions. Includes instructions for loading, single fire, and slam fire modes.</p>
	<p>Nerf Roblox Arsenal Pulse Laser Blaster Instructions</p> <p>Comprehensive guide on how to operate, load, fire, and clear jams for the Nerf Roblox Arsenal Pulse Laser motorized dart blaster. Includes safety warnings and battery information.</p>
	<p>Nerf Ultra One Blaster: Assembly, Loading, and Firing Instructions</p> <p>A comprehensive guide to assembling, loading, and operating the Nerf Ultra One Motorized Blaster, including important safety information and troubleshooting tips.</p>
	<p>NERF ULTRA DORADO Blaster: Instructions and Safety Guide</p> <p>Official instructions for the NERF ULTRA DORADO blaster, including loading, firing, safety warnings, and troubleshooting. Learn how to use your NERF ULTRA DORADO safely and effectively.</p>
	<p>Nerf Alpha Trooper CS-18 Plunger Replacement Guide</p> <p>A step-by-step guide from iFixit on how to replace the plunger in a Nerf Alpha Trooper CS-18 dart blaster. Includes tools needed and detailed disassembly instructions.</p>