

Xtreme R11

Xtreme TWS-R11 True Wireless Bluetooth Earbuds User Manual

Model: TWS-R11

1. INTRODUCTION

Thank you for choosing the Xtreme TWS-R11 True Wireless Bluetooth Earbuds. This manual provides detailed instructions to help you set up, operate, and maintain your earbuds for optimal performance. Please read this manual carefully before use and retain it for future reference.

2. PACKAGE CONTENTS

Upon unboxing, please ensure all items are present:

- Xtreme TWS-R11 True Wireless Earbuds (Left and Right)
- Charging Case
- Ear Cushions (various sizes)
- USB Charging Cable
- User Manual (this document)



Image 1: Xtreme TWS-R11 Earbuds and Charging Case in Retail Packaging. This image displays the earbuds and their charging case, along with the retail box, providing a visual representation of the product and its packaging.

3. PRODUCT OVERVIEW

The Xtreme TWS-R11 earbuds are designed for a comfortable and secure fit, offering true wireless stereo sound. They feature Bluetooth V5.0 for stable connectivity and a long battery backup with the included charging case.

Key Features:

- True Wireless Stereo (TWS) technology
- Bluetooth V5.0 for stable connection
- Up to 24 hours of combined battery life (earbuds + charging case)
- Ergonomic design for comfort and secure fit
- Independent earbud function for flexible use
- Touch control method



Image 2: Xtreme TWS-R11 Earbuds Retail Box Front and Back. This image shows the front and back of the product's retail packaging, highlighting design and some key specifications printed on the box.

4. SETUP

4.1. Charging the Earbuds and Case

1. **Initial Charge:** Before first use, fully charge the charging case and earbuds.
2. **Charging the Case:** Connect the USB charging cable to the charging port on the case and to a USB power source (e.g., computer, wall adapter). The indicator light on the case will show charging status.

3. **Charging the Earbuds:** Place the earbuds into their respective slots in the charging case. Ensure they are properly seated. The earbuds will automatically begin charging.
4. **Charging Time:** Approximately 1.5 hours for a full charge.

Note: A fully charged case can recharge the earbuds multiple times, extending their usage time significantly.

4.2. Pairing with a Bluetooth Device

1. **Power On:** Open the charging case. The earbuds will automatically power on and enter pairing mode. You may hear a voice prompt indicating "Pairing".
2. **Activate Bluetooth:** On your smartphone or other Bluetooth-enabled device, go to the Bluetooth settings and turn on Bluetooth.
3. **Search for Device:** In the list of available devices, look for "Xtreme TWS-R11" or "TWS-R11" and select it.
4. **Connection Confirmation:** Once successfully paired, you will hear a voice prompt like "Connected" from the earbuds.
5. **Single Earbud Use:** Either earbud can be used independently. Simply take one out of the case, and it will connect to the last paired device.

Note: If pairing fails, ensure the earbuds are charged and within range of your device. Try turning Bluetooth off and on again on your device, or reset the earbuds (refer to Troubleshooting section).

5. OPERATING INSTRUCTIONS

The Xtreme TWS-R11 earbuds feature touch controls for easy management of music and calls.

5.1. Power On/Off

- **Power On:** Open the charging case, or long-press the touch area on both earbuds for a few seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or long-press the touch area on both earbuds for several seconds until you hear a power-off prompt.

5.2. Music Playback

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Control:** *Specific volume control gestures are not detailed in product info, typically long press or triple tap. Refer to your device for volume control if not responsive.*

5.3. Call Management

- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Long press on either earbud during an incoming call.
- **Voice Assistant:** Triple tap on either earbud (if supported by your device).

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Xtreme TWS-R11 earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use

harsh chemicals or abrasive materials.

- **Ear Tips:** Remove ear tips and clean them with a mild soap solution if necessary, then rinse and dry thoroughly before reattaching.
- **Charging Contacts:** Ensure the charging contacts on both the earbuds and the case are clean and free of debris to ensure proper charging.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.
- **Water Resistance:** The product description mentions "Waterproof". While this indicates resistance to water, avoid submerging the earbuds in water or exposing them to heavy rain for extended periods. Always dry them thoroughly if they get wet.

7. TROUBLESHOOTING

If you encounter issues with your Xtreme TWS-R11 earbuds, refer to the following common solutions:

- **Earbuds not pairing with device:**
 - Ensure earbuds are charged and out of the charging case.
 - Turn off and on Bluetooth on your device.
 - Forget "Xtreme TWS-R11" from your device's Bluetooth list and try pairing again.
 - Ensure earbuds are within 10 meters (33 feet) of your device.
- **Only one earbud working:**
 - Place both earbuds back into the charging case, close the lid, wait a few seconds, then take them out again.
 - Ensure both earbuds are charged.
 - Try resetting the earbuds (specific reset procedure not provided, but often involves long-pressing touch areas while in case or out, or a button on the case).
- **Earbuds not charging:**
 - Ensure the charging cable is securely connected to both the case and the power source.
 - Check if the charging contacts on the earbuds and case are clean.
 - Try a different charging cable or power adapter.
- **Low volume or poor sound quality:**
 - Adjust the volume on both your device and the earbuds (if applicable).
 - Ensure ear tips are properly sealed in your ear canal. Try different sized ear tips.
 - Clean any earwax or debris from the earbud nozzles.

8. SPECIFICATIONS

Feature	Specification
Model	TWS-R11
Bluetooth Version	V5.0
Bluetooth Profiles	HSP, HFP, A2DP, AVRCP

Effective Distance	10m
Playback Time (Earbuds + Case)	Approx. 24 hours
Charging Time	Approx. 1.5 hours
Input (Earbuds)	DC5.0V 60mA
Input (Docking Case)	DC5.0V 500mA
Frequency Response	20Hz-20KHz
Sensitivity	94dB
Impedance	32Ω
Driver Unit	8mm magnetic driver
Control Method	Touch
Water Resistance Level	Waterproof
Material	Plastic

9. WARRANTY AND SUPPORT

Xtreme products are manufactured to high-quality standards. For warranty information, technical support, or service inquiries, please refer to the warranty card included with your purchase or contact Xtreme customer service directly. Please retain your proof of purchase for warranty claims. For further assistance, visit the official Xtreme website or contact their customer support channels.