

- Manuals.plus /
- › [Pets Alive](#) /
- › Pets Alive Fifi the Flossing Sloth (Model 9516) - Interactive Plush Toy Instruction Manual

Pets Alive 9516

Pets Alive Fifi the Flossing Sloth (Model 9516)

Interactive Plush Toy Instruction Manual

INTRODUCTION

The Pets Alive Fifi the Flossing Sloth is an interactive robotic plush toy designed to perform dance movements and play music. This manual provides essential information for the safe and proper use of your Fifi the Flossing Sloth.



Image: The Pets Alive Fifi the Flossing Sloth, a purple plush toy with large eyes and a tuft of purple hair, standing upright.

PACKAGE CONTENTS

- 1 x Fifi the Flossing Sloth interactive plush toy
- 1 x Instruction Manual
- Batteries (pre-installed or included for initial use)

SAFETY INFORMATION

- Recommended for ages 3 years and up.
- Adult supervision is recommended during play.
- Do not immerse the toy in water or other liquids.
- Keep away from open flames or heat sources.
- **Battery Safety:** Use only the specified battery type (4 x AA batteries). Do not mix old and new batteries. Do not mix

alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Remove batteries if the toy is not used for an extended period. Dispose of used batteries responsibly.

SETUP

Battery Installation

1. Locate the battery compartments on the bottom of Fifi's feet.
2. Using a screwdriver, open the battery compartment covers.
3. Insert 4 AA batteries, ensuring correct polarity (+/-).
4. Replace the covers and secure them with the screws.



Image: Close-up of the underside of Fifi the Flossing Sloth's feet, showing the battery compartments with screws.

Power On/Off Switch

The power switch is located on Fifi's back, under a fabric flap. Slide the switch to the 'ON' position to activate Fifi. Ensure it is not in 'DEMO' mode for full functionality.

OPERATING INSTRUCTIONS

Activating Fifi

Once powered on, press Fifi's nose to activate her. She will begin to perform her signature floss dance movements and play one of three epic songs.



Iconic Floss Movements



Hilarious Booty Wiggle

Image: Fifi the Flossing Sloth dancing, with motion lines indicating movement.

Dance Movements and Songs

Fifi performs floss-like movements, blinks her eyes, and wiggles her body to the rhythm of three different songs. Each press of her nose may initiate a new song or sequence of movements.



Image: Fifi the Flossing Sloth dancing on a white cube, with two children and an adult dancing alongside her in a room.

Official Product Videos

Your browser does not support the video tag.

Video: A 15-second video showcasing Fifi the Flossing Sloth's dance movements and features, provided by ZURU LLC.

Your browser does not support the video tag.

Video: A video from Zuru featuring both Pets Alive Frankie the Funky Flamingo and Fifi the Flossing Sloth, demonstrating their interactive features.

MAINTENANCE

Cleaning

To clean Fifi, gently wipe the surface with a damp cloth. Do not use harsh chemicals or abrasive cleaners. Do not submerge the toy in water.

Storage

Store Fifi in a cool, dry place away from direct sunlight when not in use. Remove batteries if storing for an extended period to prevent leakage.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Fifi does not turn on or respond.	Batteries are low or incorrectly installed.	Check battery polarity and replace with fresh AA batteries. Ensure the power switch is in the 'ON' position.
Fifi's movements are sluggish or inconsistent.	Low battery power.	Replace all batteries with fresh AA batteries.
Fifi only plays short sounds or limited movements.	Toy is in 'DEMO' mode.	Locate the power switch on Fifi's back and ensure it is set to 'ON' for full play mode, not 'DEMO'.

SPECIFICATIONS

Feature	Detail
Model Number	9516
Brand	Pets Alive (Zuru)
Dimensions (L x W x H)	11.4" x 5.51" x 11.42" (approx.)
Weight	600 Grams
Material Type	Cotton
Power Source	Battery Powered
Battery Type	4 x AA batteries (included)
Minimum Age	36 Months
Interactive Features	Dancing, 3 Songs, Blinking Eyes, Body Wiggle

WARRANTY AND SUPPORT

Return Policy

This product is eligible for a refund or replacement within 30 days of purchase, subject to the retailer's return policy.

Manufacturer Support

For further assistance or inquiries, please contact Zuru, the manufacturer of Pets Alive products. Refer to the product packaging or the official Zuru website for specific contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B083TKK6H5>

More documents and user manuals: **<https://manuals.plus/>**