

- Manuals.plus /
- › EUGAD /
- › EUGAD 0077ZZ L-Shaped Desk with Storage Shelves Instruction Manual

EUGAD 0077ZZ

EUGAD 0077ZZ L-Shaped Desk with Storage Shelves Instruction Manual

Model: 0077ZZ | Brand: EUGAD

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your EUGAD 0077ZZ L-shaped desk. Please read this manual thoroughly before assembly and use to ensure proper function and safety. Keep this manual for future reference.



SAFETY INFORMATION

Observe the following safety guidelines to prevent injury or damage to the product:

- The maximum load capacity for the tabletop is **40 kg (88 lbs)**.
- The maximum load capacity for each storage shelf is **20 kg (44 lbs)**.
- Ensure all screws and fasteners are securely tightened during assembly and periodically check for tightness during use.
- Do not stand or sit on the desk.
- Keep small parts away from children during assembly to avoid choking hazards.
- Use the adjustable floor protectors to ensure the desk is stable on uneven surfaces and to prevent scratches to your floor.

PACKAGE CONTENTS

Before beginning assembly, verify that all components and hardware are present. Refer to the separate assembly guide included in your package for a detailed list of parts and hardware. If any parts are missing or damaged, contact customer support immediately.



Figure 2: A screwdriver is typically included for assembly.

SETUP AND ASSEMBLY

The EUGAD 0077ZZ desk is designed for straightforward assembly. Follow the step-by-step instructions provided in the separate assembly manual included with your product. General steps include:

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify each part using the labels and the assembly guide.
2. **Assemble the Storage Unit:** Begin by assembling the four-compartment storage unit according to the instructions. Ensure all panels are correctly oriented and screws are tightened.
3. **Attach the Desk Frame:** Secure the steel leg frame to the main desktop panel.
4. **Connect Storage Unit to Desktop:** Attach the assembled storage unit to the underside of the desktop, ensuring a secure connection.

5. **Install Floor Protectors:** Screw in the adjustable floor protectors to the bottom of the steel legs. These can be rotated to level the desk on uneven floors.
6. **Final Tightening:** Once fully assembled, gently tighten all screws to ensure stability. Avoid overtightening.



Figure 3: Desk dimensions for planning placement. (Width: 116 cm, Depth: 75 cm, Height: 75 cm)



Figure 4: Key components: thickened board for durability, sturdy steel legs for stability, and adjustable floor protectors.

OPERATING INSTRUCTIONS

The EUGAD 0077ZZ L-shaped desk is designed to maximize your workspace efficiency. Its L-shaped configuration allows for optimal placement in room corners, utilizing space effectively.

- **Work Surface:** Use the spacious desktop for your computer, monitor, keyboard, and other work essentials.
- **Storage Shelves:** The integrated four-compartment storage unit provides ample space for books, documents, office supplies, and decorative items, helping to keep your workspace tidy and organized.
- **Versatile Use:** This desk is suitable for various applications, including an office workstation, a study desk, or a computer gaming desk.




Figure 5: The desk provides a functional workspace with integrated storage.

MAINTENANCE

To ensure the longevity and appearance of your EUGAD desk, follow these maintenance guidelines:

- **Cleaning:** The desk surface is water-repellent and scratch-resistant. Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Immediately wipe up any spills to prevent water damage, although the surface is water-resistant.
- **Regular Checks:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Avoid Excessive Weight:** Adhere to the specified load capacities for the tabletop and shelves to prevent structural damage.



Figure 6: The desk surface is easy to clean with a damp cloth.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Screws are not fully tightened. Uneven floor surface.	Check and tighten all assembly screws. Adjust the floor protectors on the bottom of the legs until the desk is stable.
Missing parts or damaged components.	Manufacturing error or shipping damage.	Refer to the "Warranty and Support" section and contact EUGAD customer service for assistance.
Difficulty assembling.	Instructions unclear or parts misidentified.	Review the assembly guide carefully. Ensure parts are correctly oriented. If issues persist, contact customer support.

SPECIFICATIONS

Model Number:	0077ZZ
Brand:	EUGAD
Overall Dimensions (L x W x H):	116 cm x 75 cm x 75 cm (45.7 in x 29.5 in x 29.5 in)
Tabletop Dimensions (L x W):	116 cm x 50 cm (45.7 in x 19.7 in)
Shelf Unit Dimensions (L x W x H):	80 cm x 30 cm x 63 cm (31.5 in x 11.8 in x 24.8 in)
Material:	E1 Grade Particleboard (Melamine Veneer), Alloy Steel Frame
Color:	White
Tabletop Load Capacity:	40 kg (88 lbs)

Shelf Load Capacity (per compartment):	20 kg (44 lbs)
Special Features:	Adjustable Height (via floor protectors), Water-repellent, Scratch-resistant surface



Figure 7: E1 Grade Particleboard with melamine veneer offers durability and easy maintenance.

WARRANTY AND SUPPORT

For warranty information, product support, or to report missing/damaged parts, please contact EUGAD customer service directly. Retain your proof of purchase for warranty claims. Contact information can typically be found on the EUGAD official website or through your retailer's customer service portal.

© 2023 EUGAD. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B083VV4YRL>

More documents and user manuals: <https://manuals.plus/>