

[Manuals.plus](#) /

› [Jada](#) /

› Jada Toys Marvel Spider-Man Dodge Charger Daytona 4x4 Elite R/C Instruction Manual

Jada 30761

Jada Toys Marvel Spider-Man Dodge Charger Daytona 4x4 Elite R/C Instruction Manual

Model: 30761

INTRODUCTION

This manual provides essential information for the safe and optimal operation of your Jada Toys Marvel Spider-Man Dodge Charger Daytona 4x4 Elite R/C vehicle. Please read it thoroughly before use and retain it for future reference.

SAFETY INFORMATION

- Recommended for ages 8 years and up.
- Adult supervision is recommended during operation.
- Do not operate near people, pets, or obstacles.
- Avoid operating in wet conditions or on public roads.
- Always turn off the vehicle and remote control when not in use.
- Do not attempt to modify or disassemble the vehicle or remote control.

WHAT'S IN THE BOX

- 1x Jada Toys Marvel Spider-Man Dodge Charger Daytona 4x4 Elite R/C Vehicle
- 1x Pistol Grip Remote Control
- 1x Rechargeable 12.8V Lithium Ion Battery (pre-installed or included)
- 2x AA Batteries (for remote control, included)
- 1x USB Charging Cable

SETUP

1. Battery Installation

The R/C vehicle comes with a pre-installed rechargeable 12.8V Lithium Ion battery. The remote control requires 2 AA

batteries.

Remote Control Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Open the battery compartment cover.
3. Insert 2 AA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

2. Charging the Vehicle Battery

The vehicle's 12.8V Lithium Ion battery is rechargeable via USB.

1. Ensure the vehicle's power switch is in the "OFF" position.
2. Connect the USB charging cable to the vehicle's charging port.
3. Plug the other end of the USB cable into a standard USB power source (e.g., computer USB port, USB wall adapter).
4. The charging indicator light will illuminate during charging and turn off or change color when fully charged.
5. A full charge provides approximately 25 minutes of operation.

3. Pairing the Remote Control

The vehicle and remote control are typically pre-paired. If re-pairing is necessary:

1. Turn on the R/C vehicle.
2. Turn on the remote control.
3. The remote control's indicator light should stop flashing and become solid, indicating a successful connection.

OPERATING INSTRUCTIONS

Basic Controls:

- **Pistol Grip Remote:** Hold the remote control comfortably in one hand.
- **Throttle Trigger:** Pull the trigger to move forward, push it away to reverse.
- **Steering Wheel:** Rotate the wheel left or right to steer the vehicle.

Features:

- **All-Wheel Drive (4x4):** Provides enhanced traction and control on various terrains.
- **Turbo Boost:** Engage the turbo boost function (refer to remote control for specific button) for a temporary burst of speed.
- **High Performance:** Designed for high performance on and off-road driving.

Driving Tips:

- Start in an open area free of obstacles.
- Practice gentle throttle and steering inputs to get accustomed to the vehicle's response.
- Avoid prolonged full-throttle operation to conserve battery life.
- If the vehicle loses range or responsiveness, check battery levels in both the vehicle and remote.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe down the vehicle after use. Do not use water or harsh chemicals.
- **Battery Care:**
 - Always fully charge the vehicle battery before first use.
 - Do not overcharge the battery.
 - Remove batteries from the remote control if storing for extended periods.
- **Storage:** Store the vehicle and remote control in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Vehicle does not respond to remote.	Low batteries in vehicle or remote; vehicle/remote not paired; interference.	Charge vehicle battery, replace remote batteries, re-pair vehicle and remote, move to an area with less interference.
Short operating time.	Battery not fully charged; old battery.	Ensure battery is fully charged before use. Battery life naturally decreases over time.
Vehicle moves slowly or erratically.	Low battery; debris in wheels/axles.	Charge vehicle battery, clear any obstructions from moving parts.

SPECIFICATIONS

Brand	Jada Toys
Model Number	30761
Product Dimensions	19 x 7 x 8 inches
Item Weight	5.09 pounds
Batteries Required	1x 12.8V Lithium Ion (vehicle, included), 2x AA (remote, included)
Manufacturer Recommended Age	8 years and up
Release Date	December 14, 2020

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the manufacturer's official website or contact their customer service department. Keep your proof of purchase for any warranty claims.

Visit the [Jada Store](#) for more products and information.

PRODUCT IMAGES



The Spider-Man themed Dodge Charger Daytona R/C vehicle shown alongside its pistol grip remote control.



A direct front view of the R/C vehicle, highlighting its robust bumper and large tires.



A direct rear view of the R/C vehicle, showing the "SPIDERMAN" branding and rear spoiler.



An overhead view of the R/C vehicle, showcasing the Spider-Man web design on the roof and hood.



Close-up of the pistol grip remote control, featuring the steering wheel, throttle trigger, and Spider-Man branding.



The R/C vehicle displayed within its original retail packaging, showing key features like USB charging and 4x4.

© 2023 Jada Toys. All rights reserved. Marvel and all related characters are trademarks of Marvel Entertainment, LLC.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question