

[Manuals.plus](#) /

› [Brandson](#) /

› Brandson Tower Fan Instruction Manual - Model 684634684

Brandson 684634684

Brandson Tower Fan Instruction Manual

Model: 684634684

1. IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before using the appliance and keep them for future reference. Incorrect use may result in electric shock, fire, or serious injury.

- Ensure the voltage indicated on the rating label matches your mains voltage.
- Do not immerse the appliance, plug, or cord in water or other liquids.
- Unplug from the outlet when not in use, before cleaning, or before moving.
- Keep out of reach of children. This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Avoid placing the fan near curtains or other objects that could be drawn into the fan.
- Do not insert fingers or other objects through the grille when the fan is operating.

2. PRODUCT OVERVIEW

The Brandson Tower Fan is designed to provide refreshing airflow with multiple speed settings, operating modes, and oscillation for wide air distribution. It features an intuitive LED display and can be controlled via the integrated panel or the included remote control.



Image 2.1: Overview of the Brandson Tower Fan with key features and dimensions.

Components:

- Tower Fan Unit
- Base (requires assembly)
- Remote Control
- Power Cord

Control Panel & Display:

The top of the fan features an LED display and touch-sensitive buttons for direct control. The display shows current settings such as speed, mode, timer, and ambient temperature.



Image 2.2: Detailed view of the LED display and control buttons.

3. SETUP

Base Assembly:

1. Carefully remove all components from the packaging.
2. Attach the two halves of the fan base together, ensuring they click securely.
3. Align the assembled base with the bottom of the tower fan unit.
4. Secure the base to the fan unit using the provided screws.

Placement:

- Place the fan on a firm, level surface to prevent tipping.
- Ensure there is adequate space around the fan for optimal air circulation and oscillation.
- Keep the fan away from water sources and direct sunlight.

4. OPERATING INSTRUCTIONS

The fan can be operated using the control panel on top of the unit or the remote control.

Power On/Off:

- Plug the power cord into a suitable electrical outlet.
- Press the **POWER** button on the control panel or remote to turn the fan on or off.

Speed Settings:

The fan has 3 speed levels: Low, Medium, and High.

- Press the **SPEED** button repeatedly to cycle through the speed settings.

Operating Modes:

Select from three operating modes: Normal, Natural, and Sleep.

- Press the **MODE** button repeatedly to select the desired mode.
- **Normal Mode:** Provides continuous airflow at the selected speed.
- **Natural Mode:** Simulates a natural breeze by varying the fan speed at different intervals.
- **Sleep Mode:** Gradually decreases the fan speed over time and eventually turns off, ideal for nighttime use. The display light can also be turned off in this mode.



Image 4.1: Fan operating in a bedroom, highlighting quiet operation and sleep mode.

Oscillation:

The fan features a 60° oscillation function to distribute air across a wider area.

- Press the **OSC** button to activate or deactivate the oscillation function.



Image 4.2: Fan demonstrating 60° oscillation for broad air circulation.

Timer Function:

Set the fan to automatically turn off after a specified period (1 to 12 hours).

- Press the **TIMER** button repeatedly to set the desired shutdown time in 1-hour increments. The selected time will be displayed on the LED screen.



Image 4.3: Fan with timer function set to 12 hours.

Remote Control:

The included remote control allows convenient operation from a distance (up to 10 meters).

- Ensure the remote control has working batteries.
- Point the remote control towards the fan's receiver.
- All functions available on the control panel are also accessible via the remote.



Image 4.4: Remote control and fan display, showing remote functions and storage slot.

5. MAINTENANCE

Cleaning:

- Always unplug the fan before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Use a vacuum cleaner with a brush attachment to gently remove dust from the air intake and outlet grilles.
- Do not allow water to drip into the interior of the fan.

Storage:

- If storing the fan for an extended period, clean it thoroughly.
- Store the fan in its original packaging or a suitable box in a cool, dry place.
- Keep the power cord neatly coiled to prevent damage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply.	Check if the power cord is securely plugged into a working outlet.
Weak airflow.	Fan speed is too low; grilles are blocked.	Increase the fan speed. Clean the air intake and outlet grilles.
Fan is noisy.	Fan is not on a level surface; foreign object inside.	Place the fan on a flat, stable surface. Unplug and check for any obstructions.
Remote control not working.	Batteries are dead or incorrectly inserted; remote is too far or not aimed correctly.	Replace batteries. Ensure correct polarity. Point remote directly at the fan. Reduce distance.

7. SPECIFICATIONS

- **Model Number:** 684634684
- **Dimensions (L x W x H):** 14 x 14 x 96 cm
- **Weight:** 3.35 kg
- **Power:** 45 Watts
- **Voltage:** 5 Volts (Note: This seems to be an error in the source data, typically mains voltage is 220-240V for such appliances. Please refer to the product label for accurate voltage.)
- **Number of Speeds:** 3
- **Oscillation:** 60°
- **Timer:** 1-12 hours
- **Control Type:** Remote Control, On-unit buttons
- **Special Features:** Portable, LED Display, 3 Operating Modes (Normal, Natural, Sleep)

8. WARRANTY AND SUPPORT

Brandson products are manufactured to high-quality standards. In the unlikely event of a defect or malfunction, please refer to your purchase documentation for warranty details and contact information for customer support.

For further assistance, please visit the official Brandson website or contact your retailer.