

[manuals.plus](#) /› [ANCwear](#) /› **ANCwear Portable Bluetooth Speaker TWS-BT208T Instruction Manual**

ANCwear TWS-BT208T

ANCwear Portable Bluetooth Speaker TWS-BT208T Instruction Manual

Model: TWS-BT208T

1. INTRODUCTION

Thank you for choosing the ANCwear Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it thoroughly before use to ensure proper functionality and longevity of your device.

The ANCwear TWS-BT208T is a versatile, compact, and waterproof Bluetooth speaker designed for various activities, offering clear sound and hands-free calling capabilities.

2. WHAT'S IN THE Box

Upon unpacking, please ensure all the following items are present:

- Speaker x1
- Detachable Wearable Wristband x1
- Detachable Clip x1
- Detachable Clip with Hanger x1
- Type-C Recharge Cord x1

Built-in Microphone

One-tap call answering Seamless switch between music & calls



Image: All components included in the ANCwear Portable Bluetooth Speaker package.

3. PRODUCT FEATURES

- **Compact & Portable:** Weighing only 50g, designed for easy portability and single-hand operation.
- **Versatile Wearing Options:** Can be worn on the wrist, clipped to clothing, or hung from a pocket.
- **Enhanced Audio:** Built-in professional audio chip produces 3W HD sound with enhanced bass.
- **Bluetooth 5.3:** Ensures stable and ultra-fast connection with all Bluetooth-enabled devices.
- **Built-in Microphone:** Allows for convenient hands-free calls with one-tap answering.
- **Long Battery Life:** Up to 9.5 hours of playtime (at 1/3 max volume) and 18 hours standby time. Fully recharges in 1.5 hours.
- **IPX6 Waterproof:** Fully sealed design provides resistance to rain, sweat, and dust, making it suitable for outdoor and shower use.
- **White Noise Player:** Features a built-in white noise player with 17 natural sounds and a 30-minute auto playback function for relaxation.

4. SETUP AND CHARGING

4.1 Initial Charge

Before first use, fully charge your speaker. Connect the provided Type-C USB cable to the charging port on the speaker and the other end to a USB power source (e.g., computer, wall adapter). The charging indicator light will show the charging status.

A full charge takes approximately 1.5 hours.




Image: Speaker charging port and dimensions.

4.2 Power On/Off

- **To Power On:** Long press the 'O' button until the indicator light flashes.
- **To Power Off:** Long press the 'O' button again until the indicator light turns off.

Your browser does not support the video tag.

Video: Demonstrates how to power on/off and use the ANCwear Portable Bluetooth Speaker.

5. OPERATING INSTRUCTIONS

5.1 Bluetooth Pairing

1. Ensure the speaker is powered on and the indicator light is flashing, indicating it's in pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "ANCwear" from the list of devices to connect.
4. Once connected, the speaker will emit a confirmation tone, and the indicator light will remain solid.



Image: Bluetooth 5.3 seamless pairing with various devices.

5.2 True Wireless Stereo (TWS) Pairing

To enjoy enhanced stereo sound, you can pair two ANCwear TWS-BT208T speakers together:

1. Ensure both speakers are powered off.
2. Simultaneously long press the 'O' button on both speakers to power them on.
3. The speakers will automatically enter TWS pairing mode and connect to each other. A confirmation tone will sound once paired.
4. Once TWS paired, connect your device to one of the speakers via Bluetooth as described in Section 5.1. Both speakers will then play audio in stereo.

Your browser does not support the video tag.

Video: Instructions on how to use the TWS function for stereo sound.

5.3 Making and Answering Calls

With the built-in microphone, you can manage calls directly from your speaker:

- **Answer/End Call:** Press the 'O' button once.
- **Reject Incoming Call:** Long press the 'O' button.
- **Redial Last Number:** Double press the 'O' button.

It's With You More Than You Think — [Wearable, Clickable, and Hookable.](#)



Image: Built-in microphone for hands-free calls.

5.4 Music Playback Controls

- **Play/Pause Music:** Press the 'O' button once.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Next Track:** Long press the '+' button.
- **Previous Track:** Long press the '-' button.

IPX6 Waterproof

Resistant to rain, sweat & dust
Rinse-clean design for all-day comfort




Image: Speaker control buttons and their functions.

5.5 White Noise Mode

The speaker includes a white noise function for relaxation:

- **Activate/Switch Noise Mode:** Double press the '+' button.
- The white noise mode features 17 natural sounds and a 30-minute auto playback timer.



6. WEARING OPTIONS

The ANCwear speaker offers multiple ways to wear it, adapting to your activity:

- **Wristband:** Attach the speaker to the provided wristband for a wearable audio experience, similar to a smartwatch.
- **Hanger Clip:** Use the hanger clip to attach the speaker to your pocket, backpack, or other straps.
- **Clothing Clip:** Secure the speaker directly to your clothing, such as a shirt collar or waistband, using the dedicated clip.



Image: Speaker worn on the wrist during cycling.



Image: Speaker clipped to a pocket.



Image: Speaker clipped to a shirt.

Your browser does not support the video tag.

Video: Demonstrates various wearing options for the ANCwear Wearable Bluetooth Speaker for outdoor sports.

7. WATERPROOFING (IPX6)

The ANCwear speaker is rated IPX6 waterproof, meaning it is protected against high-pressure water jets from any direction. This makes it suitable for use in the shower, during rainy outdoor activities, or in dusty environments.

While it can withstand water splashes and jets, it is not designed for submersion in water. Ensure the charging port cover is securely closed before exposing the speaker to water.



Only 60g

Lightweight fit, All-day comfort



1.5h full charge

Up to 9.5h playtime, 18h standby mode



Egg-sized

Fits in your palm, Easy to carry anywhere

Image: Speaker demonstrating IPX6 waterproofing in a shower.

8. SPECIFICATIONS

| Feature | Detail |
|------------------------------|---------------|
| Model Name | BT-208 |
| Item Model Number | TWS-BT208T |
| Connectivity Technology | Bluetooth 5.3 |
| Speaker Maximum Output Power | 3 Watts |

| | |
|------------------------|--|
| Item Weight | 60 Grams (2.12 ounces) |
| Product Dimensions | 4.3"D x 3.5"W x 1.8"H |
| Water Resistance Level | IPX6 Waterproof |
| Charging Time | 1.5 Hours |
| Playtime | Up to 9.5 hours (at 1/3 max volume) |
| Standby Time | Up to 18 hours |
| Special Feature | Built-in Microphone, TWS Pairing, White Noise Player |

9. MAINTENANCE

- Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use for extended periods.
- Waterproof Seal:** Always ensure the charging port cover is properly sealed to maintain IPX6 water resistance.

10. TROUBLESHOOTING

| Problem | Solution |
|------------------------------------|--|
| Speaker does not power on. | Ensure the speaker is fully charged. Connect it to a power source and try again. |
| Cannot pair with Bluetooth device. | Make sure the speaker is in pairing mode (flashing indicator light). Turn off and on your device's Bluetooth. Ensure the speaker is not connected to another device. |
| No sound or low volume. | Check the volume levels on both the speaker and your connected device. Ensure the speaker is properly paired. |
| TWS pairing fails. | Ensure both speakers are powered off before attempting simultaneous power-on for TWS pairing. Keep them close during pairing. |
| Poor call quality. | Ensure you are within Bluetooth range of your device. Reduce background noise. |

11. WARRANTY AND SUPPORT

This ANCwear product comes with a **Limited Warranty**. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included in your product packaging or visit the official ANCwear website.

If you encounter any issues or have questions not covered in this manual, please contact ANCwear customer support through the following channels:

- **Online Support:** Visit the [ANCwear Store on Amazon](#).
- **Email:** Refer to your product packaging for customer service email address.

ANCwear promises a 30-day return and 2-year sales service. You can contact them about any issues at any time for a satisfactory solution.