

[Manuals.plus](#) /

> [Winique](#) /

> Winique Karaoke Machine User Manual

Winique part_B083Y4136C

Winique Karaoke Machine User Manual

Model: Winique Karaoke Microphone (part_B083Y4136C)

Brand: Winique

INTRODUCTION

Thank you for choosing the Winique Karaoke Machine. This versatile Bluetooth mini karaoke machine is designed to bring joy and entertainment to users of all ages. Featuring vibrant LED lights, superior sound quality with 3-layer noise reduction, and a variety of fun voice change effects, it's perfect for singing anytime, anywhere. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure you get the most out of your device.



Image: The Winique Karaoke Machine, showcasing its blue color and integrated LED lights.

WHAT'S IN THE BOX

Upon unboxing your Winique Karaoke Machine, please ensure all the following components are present:

- Karaoke Microphone
- Micro USB cable
- Audio cable
- User Manual

PRODUCT FEATURES

- **Super Sound Quality:** Professional audio processor and 3-layer noise reduction for high-quality, crystal-clear sound with echo reverberation.
- **Widely Compatible:** Stable connection to mobile phones and tablets via Bluetooth or 3.5mm audio cable, supporting various music applications like Spotify and YouTube.
- **Extra Long Duration:** Built-in 2400mAh rechargeable battery provides 5-6 hours of continuous use.
- **Colorful LED Lights:** Lights that dance with the music to create an exciting atmosphere.
- **Multi-function & Fun Voice Change:** Can be used as a Bluetooth speaker, recorder, voice disguiser, and FM radio. Includes 5 different voice effects: baby, male, female, monster, and original voice.



Image: Illustration highlighting the high-quality sound features, including 3-layer noise reduction and powerful stereo speaker.

SETUP

1. **Charging the Device:** Before first use, fully charge the karaoke microphone using the provided Micro USB cable. Connect the USB cable to a power adapter (not included) or a computer USB port. The charging indicator light will show the charging status.
2. **Power On/Off:** Long press the power button (located on the microphone head) to turn the microphone on or off. A voice prompt will indicate the power status.

3. Bluetooth Connection:

- Turn on your mobile phone or tablet's Bluetooth function.
- Search for the device named "WS-858L" (or similar, refer to your device's display).
- Select "WS-858L" to pair. You will hear a prompt sound indicating a successful connection.
- Once connected, you can play music from any music application (e.g., Spotify, YouTube) through the microphone's speaker.

4. **Cable Connection:** For devices without Bluetooth, use the provided 3.5mm audio cable to connect the microphone to your audio source.

5. **TF Card Playback:** Insert a TF (Micro SD) card into the designated slot to play music directly from the card.



Image: Diagram illustrating the Bluetooth connection process with various devices.



Image: Detailed view of the microphone's buttons and ports, explaining their functions for setup and use.

OPERATING INSTRUCTIONS

Button Functions:

Button	Function
Power Button	Long press to turn on/off the microphone.
PREV / NEXT	Press to switch to the previous or next song.
SCAN / Play/Pause / LED Light ON/OFF	Press to play or pause music. Long press to turn LED lights on/off. In FM mode, press to scan for stations.
REC	Press to record your singing (requires TF card).
VOC+ / VOC-	Increase or decrease the music volume.
MIC VOL +/-	Increase or decrease the microphone volume (your voice).

Button	Function
REMIX	Adjust the echo/reverb effect level.
Voice Changer Button	Press to cycle through 5 voice effects: Original, Baby, Male, Female, Monster.

Voice Change Function:

The Winique Karaoke Machine offers 5 unique voice effects to enhance your singing experience. Simply press the dedicated voice changer button to switch between:

- Original Voice
- Baby Voice
- Male Voice
- Female Voice
- Monster Voice




Image: Visual representation of the different voice change effects available on the microphone.

LED Lights:

The integrated LED lights can be turned on or off by long-pressing the SCAN/Play/Pause button. These lights synchronize with the music, adding a dynamic visual element to your performance.

High Quality Sound



🔊 3-Layer Noise Reduction

📄 Up to 5 hours use

🔊 Adjustable Volume and Remix

🔊 Powerful Stereo Speaker

Image: The microphone with its colorful LED lights illuminated, creating a party atmosphere.

FM Radio Function:

To use the FM radio function, press the SCAN button to automatically search for available radio stations. Use the PREV/NEXT buttons to switch between stations.

MAINTENANCE

- **Cleaning:** Wipe the microphone with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the microphone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **Handling:** Handle the microphone with care to prevent drops or impacts that could damage internal components.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Low battery or no charge.	Charge the device fully using the provided USB cable.
Cannot connect via Bluetooth.	Bluetooth not enabled on device; microphone not in pairing mode; too far from device.	Ensure Bluetooth is on and visible on your phone/tablet. Restart the microphone. Move closer to the microphone. Forget the device in your Bluetooth settings and try pairing again.
No sound or low sound output.	Volume too low on microphone or connected device; incorrect connection.	Increase MIC VOL and VOC volume on the microphone. Increase volume on your connected device. Ensure cables are securely connected if using wired mode.
Echo/Reverb effect is too strong or too weak.	REMIX level is not adjusted correctly.	Adjust the REMIX button to your desired level.
LED lights are not working.	LED lights are turned off.	Long press the SCAN/Play/Pause button to turn the LED lights on.

SPECIFICATIONS

Feature	Detail
Brand	Winique
Model Name	Winique Karaoke Microphone
Item Model Number	part_B083Y4136C
Connectivity Technology	Bluetooth, 3.5 mm Jack, TF Card
Power Source	Battery Powered (1 Lithium Polymer battery included)
Battery Capacity	2400mAh (approx. 5-6 hours use)
Audio Sensitivity	115 dB
Frequency Range	0.1 kHz - 10 kHz
Item Dimensions (L x W x H)	2 x 2 x 2 inches
Item Weight	14.1 ounces
Material	Plastic, Metal

Feature	Detail
Special Features	Bluetooth Speaker, Recorder, Voice Disguiser, FM Radio, Multiple Sound Modes, LED Lights

WARRANTY AND SUPPORT

Winique stands behind the quality of its products. For any warranty claims, technical support, or inquiries regarding your Winique Karaoke Machine, please contact the manufacturer directly through their official channels or the retailer from whom you purchased the product.

Please retain your proof of purchase for warranty purposes.