Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CalExotics SE4410393

CalExotics Naughty Bits W.I.L.F. Wand Instruction Manual

Model: SE4410393

Introduction

Thank you for choosing the CalExotics Naughty Bits W.I.L.F. Wand. This instruction manual provides essential information for the safe and effective use, care, and maintenance of your product. Please read this manual thoroughly before first use and retain it for future reference.

CalExotics is dedicated to creating inspiring intimate products designed to enhance pleasure. We are committed to quality, and each product is backed by a one-year manufacturer warranty.

Product Overview

The CalExotics Naughty Bits W.I.L.F. Wand is a high-intensity silicone massager designed for enhanced pleasure. It features a unique texture and multiple functions for a customizable experience.




Image: Front view of the CalExotics Naughty Bits W.I.L.F. Wand, showcasing its ergonomic design and patterned surface.

Key Features:

- **High-intensity Silicone Massager:** Crafted from body-safe silicone for comfort and durability.
- **10 Functions:** Offers a variety of intense vibration, pulsation, and escalation patterns.
- **Unique Texture:** Designed for maximum pleasure.
- **Memory Chip:** Resumes on the last function used for convenience.
- **Security Travel Lock:** Prevents accidental activation during travel.
- **USB Rechargeable:** Easy and convenient charging.
- **Waterproof Design:** Suitable for use in wet environments.
- **1-Year Manufacturer Warranty:** Ensures product quality and customer satisfaction.



Image: Detailed view of the wand with measurements (8.5" / 21.5 cm length, 1.75" / 4.5 cm width) and callouts highlighting the 10 powerful functions and easy-to-use single button control.



Image: Icons representing key features: 10 intense functions, silicone material, travel lock, memory chip, waterproof, USB rechargeable, and 1-year warranty.

Setup

1. Initial Cleaning

Before first use, clean the product thoroughly with warm water and a toy cleaner or mild soap. Rinse well and allow to air dry completely.

2. Charging the Device

The W.I.L.F. Wand is USB rechargeable. A charging cord is included with your product.

1. Locate the charging port on the device. This is typically a small, self-sealing port.
2. Insert the small end of the USB charging cable into the device's charging port.
3. Plug the larger end of the USB cable into a compatible USB power source (e.g., computer, USB wall adapter).
4. The indicator light will illuminate during charging. A complete charge takes approximately 2.5 hours.
5. Once fully charged, the device will run for approximately 90 minutes on high speed and 180 minutes on low speed.
6. Disconnect the charging cable once charging is complete.



Image: The CalExotics W.I.L.F. Wand connected to its USB charging cable, illustrating the charging process.

Operating Instructions

Power On/Off and Travel Lock:

- To turn the device **ON** or **OFF**, press and hold the top button for 3 seconds.
- The device features a security travel lock. Holding the button for 3 seconds also activates/deactivates this lock, preventing accidental power-on during transport.

Function Control:

- Once powered on, press the bottom button repeatedly to cycle through the 10 intense functions of vibration, pulsation, and escalation.
- The integrated memory chip will recall the last function used when the device is powered on again.

Waterproof Feature:

The W.I.L.F. Wand is waterproof, allowing for use in the bath or shower. Ensure the charging port is completely dry before connecting the charging cable.

Your browser does not support the video tag.

Video: Demonstration of the CalExotics Naughty Bits W.I.L.F. Wand's functions and waterproof capabilities. This video illustrates how to cycle through the 10 vibration patterns and highlights its suitability for use in water.

Maintenance

Cleaning:

- Always clean your W.I.L.F. Wand before and after each use.

- Use warm water and a specialized toy cleaner or mild, antibacterial soap.
- Rinse thoroughly to remove all soap residue.
- Pat dry with a lint-free cloth or allow to air dry completely before storing.
- Avoid using cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone material.

Storage:

- Store the device in a clean, dry, and cool place, away from direct sunlight and extreme temperatures.
- Keep it separate from other toys made of different materials to prevent material degradation.
- Ensure the device is fully charged before long-term storage to maintain battery health.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted or travel lock is active.	Charge the device fully. Press and hold the top button for 3 seconds to deactivate the travel lock or power on.
Device does not charge.	Charging cable not properly connected or power source issue.	Ensure the USB cable is securely connected to both the device and the power source. Try a different USB port or adapter.
Functions are not changing.	Incorrect button press.	Ensure you are pressing the **bottom button** to cycle through functions.
Reduced vibration intensity.	Low battery.	Recharge the device.

Specifications

Feature	Detail
Product Dimensions	2 x 4.5 x 11.25 inches; 12.5 ounces
Item Model Number	SE4410393
Batteries	1 Lithium Ion battery (included)
Material	Silicone, ABS Plastic
Color	Clear (referring to the product's base color, though pattern is prominent)
Functions	10 (vibration, pulsation, escalation)
Charge Time	Approx. 2.5 hours
Run Time	90 minutes (high speed), 180 minutes (low speed)

Warranty and Support

Manufacturer Warranty:

The CalExotics Naughty Bits W.I.L.F. Wand is covered by a **one-year manufacturer warranty** from the date of purchase.

This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

For detailed warranty terms and conditions, or to initiate a warranty claim, please visit the official CalExotics website or contact their customer support.

Customer Support:

If you have any questions, concerns, or require assistance with your product, please visit the CalExotics website for support resources and contact information:

www.calexotics.com

© 2024 CalExotics. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B083YHBRLN

More documents and user manuals: **https://manuals.plus/**