

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [CalExotics](#) /

› [CalExotics French Kiss Sweet Talker User Manual](#)

**CalExotics 060805**

# CalExotics French Kiss Sweet Talker User Manual

Model: 060805 | Brand: CalExotics

## 1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your CalExotics French Kiss Sweet Talker. Please read this manual thoroughly before first use and retain it for future reference.



Image 1.1: The CalExotics French Kiss Sweet Talker, shown with its retail packaging.

## 2. PRODUCT FEATURES

The CalExotics French Kiss Sweet Talker is designed with the following key features:

- Sensual flickering silicone teaser for targeted stimulation.
- 12 distinct vibration functions.
- Compact, handheld design for ease of use.
- Memory chip function that resumes on the last used setting.
- Security travel lock feature.
- USB rechargeable.
- Waterproof construction.




Image 2.1: Product dimensions (1.5" / 3.75 cm width, 2.25" / 5.75 cm height) and visual callouts for the flickering teaser, 12 vibration functions, and push-button control.

### 3. PACKAGE CONTENTS

Your package should contain the following items:

- 1 x CalExotics French Kiss Sweet Talker device
- 1 x USB Charging Cord

*You've never been kissed like this.*



**SWEET TALKER**

**PUSH-BUTTON CONTROL - HOLD FOR 3 SECONDS TO TURN ON OR OFF**

**12 TANTALIZING FUNCTIONS OF IRRESISTIBLE VIBRATION**




**SENSUAL FLICKERING TEASER FOR PASSIONATE STIMULATION**



**USB RECHARGEABLE CHARGING CORD INCLUDED**

**AROUSER: 2.25" X 1.5"/5.75 CM X 3.75 CM**  
**OVERALL: 2.75" X 1.75"/7 CM X 4.5 CM**

**COMPACT HANDHELD DESIGN**



**MASSAGER WILL RUN FOR:**  
35 MINUTES ON HIGH SPEED  
50 MINUTES ON LOW SPEED  
COMPLETE CHARGE IN 1.25 HOURS

**••INSTRUCTIONS INCLUDED••**

DE	FR	ES	RU
<ul style="list-style-type: none"><li>• Hochwertiges silikon</li><li>• 12 wahnsinnige funktionen</li><li>• Weiche, züngelnde zunge</li><li>• Speicher chip, der die zuletzt benutzte funktion speichert</li><li>• USB nachladbar</li><li>• 100% wasserfest</li><li>• Für das an- oder ausschalten 3 sekunden gedrückt halten</li><li>• Sicherheitsschloß für die reise</li><li>• Voll aufladbar innerhalb von 75 minuten</li><li>• Bei maximaler geschwindigkeitsstufe beträgt die betriebsdauer des massagegeräts 35 minuten, bei geringster geschwindigkeitsstufe 50 minuten</li><li>• Ein jahres garantie</li></ul>	<ul style="list-style-type: none"><li>• Silicone de haute qualité</li><li>• 12 fonctions incroyables</li><li>• Langue douce oscillante</li><li>• Puce mémorisant les fonctions de la dernière utilisation</li><li>• Rechargeable sur un port USB</li><li>• 100% étanche</li><li>• Maintenir enfoncé pendant 3 secondes pour le mettre en marche ou l'arrêter</li><li>• Fermoir de sécurité pour le voyage</li><li>• Charge complète en 75 minutes</li><li>• Le masseur fonctionne à plein régime pendant 35 minutes, et au plus bas régime, pendant 50 minutes</li><li>• Garantie d'un an</li></ul>	<ul style="list-style-type: none"><li>• Silicona de alta calidad</li><li>• 12 funciones increíbles</li><li>• Lengua suave y vacilante</li><li>• Chip de memoria se continua en última función utilizada</li><li>• USB dispositivo recargable</li><li>• 100% impermeable</li><li>• Mantenga presionado durante 3 segundos para encender o apagar</li><li>• Bloqueo de seguro de viaje</li><li>• Carga completa en 75 minutos</li><li>• Masajeador ejecutará la velocidad máxima por 35 minutos y de menor velocidad por 50 minutos</li><li>• Un año de garantía</li></ul>	<ul style="list-style-type: none"><li>• Силикон высшего качества</li><li>• 12 функций интенсивной</li><li>• мягкий стимулирующий язычок</li><li>• Запоминает последнюю использованную функцию</li><li>• Заряжается от USB</li><li>• 100% водонепроницаемый</li><li>• Задержите кнопку на 3 секунды, чтобы выключить</li><li>• Предохранительный замок для транспортировки</li><li>• Полная зарядка в 75 минут</li><li>• Полная зарядка длится 35 минут на высокой скорости и 50 минут на низкой</li><li>• Гарантия один год</li></ul>

**calexotics.com**

Image 3.1: The device connected to its USB charging cord, highlighting its premium, silky smooth, and body-safe silicone material.

### 4. SETUP AND CHARGING

## 4.1 Initial Charge

Before first use, fully charge the device. The device requires approximately 1.25 hours for a complete charge.

1. Locate the charging port on the device. This is typically found on the base or side of the unit.
2. Insert the small end of the provided USB charging cord into the device's charging port.
3. Connect the larger USB end of the cord to a compatible USB power source (e.g., computer USB port, USB wall adapter).
4. The indicator light on the device will illuminate during charging and turn off or change color when fully charged.



Image 4.1: Bottom view of the device, illustrating the location of the charging port.

## 5. OPERATION

### 5.1 Power On/Off

To power the device on or off, press and hold the power button for approximately 3 seconds. The power button is typically located on the back or side of the device.



Image 5.1: Back view of the device, indicating the position of the power button.

## 5.2 Changing Functions

Once powered on, short presses of the power button will cycle through the 12 available vibration functions. The device features a memory chip that will recall the last used function when powered on again.

## 5.3 Travel Lock

The device includes a security travel lock feature to prevent accidental activation. Consult the packaging or manufacturer's website for specific instructions on engaging and disengaging the travel lock, as this may vary.

---

# 6. MAINTENANCE

## 6.1 Cleaning

To ensure hygiene and prolong the life of your device:

- Clean the device thoroughly before and after each use.

- Use warm water and a mild, toy-safe soap or a specialized toy cleaner.
- Rinse thoroughly with clean water.
- Pat dry with a lint-free cloth or allow to air dry completely before storage.

## 6.2 Storage

Store the device in a clean, dry place, away from direct sunlight and extreme temperatures. Avoid storing with other materials that may react with silicone.

---

## 7. TROUBLESHOOTING

If you encounter issues with your device, please refer to the following common solutions:

- **Device not turning on:** Ensure the device is fully charged. Press and hold the power button for 3 seconds to activate. Check if the travel lock is engaged.
- **Device not charging:** Verify that the USB cable is securely connected to both the device and the power source. Try a different USB port or power adapter.
- **Weak vibrations:** The battery may be low. Recharge the device.

If problems persist after attempting these steps, please contact customer support as detailed in the Warranty and Support section.

---

## 8. SPECIFICATIONS

Feature	Detail
Product Dimensions	2.5 x 5.25 x 7.25 inches; 9.1 ounces
Item Model Number	060805
Batteries	1 Lithium Polymer battery (included)
Material	Silicone
Water Resistance Level	Waterproof
Charge Time	Approx. 1.25 hours
Run Time (High Speed)	Approx. 35 minutes
Run Time (Low Speed)	Approx. 50 minutes

---

## 9. SAFETY INFORMATION

Please observe the following safety guidelines:

- This product is intended for adult use only.
- Discontinue use immediately if you experience any discomfort or irritation.
- Do not use if the product appears damaged or defective.

- Keep out of reach of children.

## 9.1 Legal Disclaimer

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

# 10. WARRANTY AND SUPPORT

## 10.1 Manufacturer Warranty

The CalExotics French Kiss Sweet Talker is backed by a 1-year manufacturer warranty. Please retain your proof of purchase for warranty claims.

## 10.2 Customer Support

For further assistance, troubleshooting, or warranty inquiries, please visit the official CalExotics website or contact their customer service department directly. Contact information can typically be found on the product packaging or the brand's official website.

© 2023 CalExotics. All rights reserved.

## Related Documents - 060805

 <p><b>Cashmere Velvet Curve SE-4364-05-3 User Guide and Instructions</b></p> <p>Comprehensive user guide for the Cashmere Velvet Curve SE-4364-05-3 adult pleasure product, covering usage instructions, battery care, safety warnings, and environmental disposal.</p>	
 <p><b>CalExotics Connect Venus Butterfly SE-0001-12-3 User Guide and Instructions</b></p> <p>Comprehensive user guide for the CalExotics Connect Venus Butterfly (SE-0001-12-3), covering features, usage instructions, app control, warnings, and care. Learn how to use vibration modes, music sync, interactive features, and manage product settings.</p>	
 <p><b>Calexotics Silicone Remote Rechargeable Egg™ - Product Information and Instructions</b></p> <p>Detailed information about the Calexotics Silicone Remote Rechargeable Egg™, including features, materials, measurements, charging instructions, and operating guide. Model SE-0077-30-3.</p>	