

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Hasbro Gaming](#) /
- › [Monopoly Super Electronic Banking Board Game Instruction Manual](#)

Hasbro Gaming E8978

Monopoly Super Electronic Banking Board Game Instruction Manual

Model: E8978 | Brand: Hasbro Gaming

1. INTRODUCTION

Welcome to the world of Monopoly Super Electronic Banking! This modern twist on the classic board game introduces an all-in-one electronic banking unit and unique reward systems, making gameplay faster and more dynamic. Players use bank cards to track their finances, earn rewards, and navigate the board with new features like Flight Spaces and Forced Trade spaces. This manual provides comprehensive instructions to help you set up, play, and maintain your game.



Figure 1: The Monopoly Super Electronic Banking game box, showcasing the electronic banking unit and bank cards.

2. WHAT'S IN THE BOX

Before you begin, ensure all components are present:

- Gameboard
- Electronic Banking Unit
- 4 Plastic Tokens
- 4 Bank Cards
- 16 Title Deed Cards
- 20 Chance Cards
- 4 Reference Cards
- 1 Die
- Game Guide



Figure 2: All game components, including the board, banking unit, tokens, cards, and die.

3. SETUP

1. **Place the Gameboard:** Unfold the gameboard and place it on a flat surface.
2. **Electronic Banking Unit Setup:**
 - Insert 2 AA batteries (not included) into the electronic banking unit. Ensure correct polarity.
 - Place the banking unit next to the gameboard within easy reach of all players.
3. **Distribute Components:**
 - Each player chooses a plastic token and places it on the "GO" space.
 - Each player takes one Bank Card. This card is linked to their chosen token and will track their money.
 - Shuffle the Title Deed cards and place them face down on their designated spaces on the board.
 - Shuffle the Chance cards and place them face down on the "Chance" space on the board.
 - Place the Reference Cards near the banking unit for easy access.

4. **Starting Money:** The electronic banking unit automatically assigns starting money to each player when their bank card is first tapped. No paper money is used in this game.



Figure 3: Players setting up the game, including placing the board and preparing the banking unit.

4. OPERATING INSTRUCTIONS

4.1 Game Objective

The objective of Monopoly Super Electronic Banking is to be the player with the most money at the end of the game. This is achieved by buying properties, collecting rent, and earning rewards through various in-game actions.

4.2 Gameplay Overview

Players take turns rolling the die and moving their token around the board. Actions are determined by the space landed on. All financial transactions are handled by the electronic banking unit using the bank cards.

4.3 Using the Electronic Banking Unit

The banking unit is central to all transactions. To perform an action:

- **To Pay/Receive Money:** Tap your bank card on the banking unit. The unit will display your current balance.
- **To Buy Property:** When you land on an unowned property, tap your bank card, then tap the Title Deed card on the unit to purchase it. The unit will deduct the cost from your balance.
- **To Collect Rent:** When another player lands on your property, they tap their bank card, then you tap your Title Deed card. The unit will transfer the rent from their account to yours.
- **To Activate Rewards:** Certain actions or spaces trigger rewards. Follow the instructions on the Reference Cards or Chance Cards, which will often involve tapping your bank card or a specific card on the unit to receive a bonus.



Figure 4: Demonstrating the tap technology of the electronic banking unit with a player's bank card.



Figure 5: A player checking their balance on the electronic banking unit after tapping their bank card.



Figure 6: A player tapping a Title Deed card on the banking unit, likely for a transaction such as buying property or collecting rent.

4.4 Special Spaces and Actions

- **Flight Spaces:** Instead of purchasing railroads, players can choose to take a flight to any property on the gameboard. This offers strategic movement options.
- **Forced Trade Space:** If you land on a Forced Trade space, you can choose any property you own and immediately trade it for any property owned by another player. This can significantly alter game dynamics.
- **Chance Cards:** Draw a Chance card when you land on a Chance space. Follow the instructions on the card, which may involve receiving money, paying money, moving to a different space, or triggering a reward.
- **Reward System:** Each of the 4 plastic tokens has a unique bank card that offers a specific reward for performing certain actions in the game. For example, rolling a specific number, landing on a particular space, or purchasing a certain property type. Consult your Reference Card for details on your token's unique reward.



Figure 7: A selection of bank cards and Chance cards, illustrating the unique rewards and actions available in the game.

5. MAINTENANCE

- **Cleaning:** Wipe the gameboard, plastic tokens, and electronic banking unit with a soft, dry cloth. Do not use abrasive cleaners or immerse any electronic components in water.
- **Storage:** Store all game components in their original box in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries from the electronic banking unit if the game will not be used for an extended period to prevent leakage.

6. TROUBLESHOOTING

Problem	Solution
---------	----------

Problem	Solution
Electronic Banking Unit not turning on.	<ul style="list-style-type: none"> • Ensure 2 AA batteries are correctly inserted with proper polarity. • Replace old batteries with new ones.
Bank card not registering with the unit.	<ul style="list-style-type: none"> • Ensure the card is placed flat against the tapping area of the unit. • Try tapping the card again firmly. • Check if the unit is powered on.
Incorrect balance displayed.	<ul style="list-style-type: none"> • Verify that all transactions were correctly processed by tapping the appropriate cards. • If an error occurred, the game may need to be reset.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	1.61 x 15.75 x 10.51 inches
Item Weight	1.7 pounds
Model Number	E8978
Manufacturer Recommended Age	8 years and up
Batteries Required	2 AA batteries (not included)
Release Date	August 1, 2020
Manufacturer	Hasbro

8. SAFETY INFORMATION

- **Choking Hazard:** Small parts. Not for children under 3 years.
- **Battery Safety:**
 - Do not mix old and new batteries.
 - Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
 - Insert batteries with correct polarity.
 - Remove exhausted batteries promptly.
 - Do not short-circuit the supply terminals.
 - Dispose of batteries properly.

9. WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact Hasbro Gaming customer service. Refer to the contact information provided on the product packaging or visit the official Hasbro Gaming website for

the most up-to-date support details.

Official Hasbro Gaming Website: [Hasbro Gaming Store](#)

© 2020 Hasbro. All rights reserved. Monopoly and all related characters are trademarks of Hasbro.