

ILVE 40 Inch Majestic II Series Freestanding Electric Double Oven Range User Manual

Model: UMDI10NS3SSG

1. INTRODUCTION

Welcome to the user manual for your new ILVE 40 Inch Majestic II Series Freestanding Electric Double Oven Range. This appliance is designed to offer exceptional performance and sophisticated style for your kitchen. Please read this manual thoroughly before using the appliance to ensure safe and efficient operation, and to familiarize yourself with its features and functions.



Figure 1: ILVE 40 Inch Majestic II Series Freestanding Electric Double Oven Range.

Majestic: quality in detail



Figure 2: Detailed features of the Majestic II Series Range.

2. SAFETY INFORMATION

Your safety and the safety of others are very important. Please read all instructions before using the appliance to reduce the risk of fire, electric shock, injury to persons, or damage when using the range.

- Always ensure proper ventilation when operating the cooktop and ovens.
- Do not store flammable materials in or near the appliance.
- Keep children and pets away from the appliance during operation. The triple glass cool door helps reduce surface temperature, but caution is still advised.
- Use oven mitts when handling hot items from the oven.
- Ensure the appliance is properly grounded before use.

3. SETUP & INSTALLATION

The ILVE Majestic II Series Range is designed for freestanding installation. Proper installation is crucial for optimal performance and safety. It is recommended that installation be performed by a qualified technician.

3.1. Unpacking

Carefully remove all packaging materials and inspect the range for any damage. Report any damage to your dealer immediately.

3.2. Location and Clearance

Ensure the installation area meets all local codes and regulations. Provide adequate clearance from combustible surfaces. Refer to the technical diagram for precise dimensions.



Figure 3: Product dimensions and installation clearances.

3.3. Electrical Connection

This electric range requires a 220 Volts electrical supply. Ensure the electrical connection is performed by a licensed electrician in accordance with all local and national electrical codes.

4. OPERATING INSTRUCTIONS

Your ILVE Majestic II Series Range features a sophisticated TFT oven control display and six radiant electric elements for versatile cooking.

4.1. Cooktop Operation

The cooktop features six radiant electric elements. Each element is controlled by a dedicated knob on the front panel. Turn the knob to the desired heat setting. The power levels range from low to high, providing precise control for various cooking needs.




Figure 4: Cooktop element layout and wattage.




Figure 5: Cooktop element power levels (Kilowatts).

4.2. Oven Operation (Double Oven)

This range is equipped with a double oven, offering ample cooking capacity. Both ovens feature convection cooking mode for even heat distribution and faster cooking times. The main oven has a capacity of 3.82 Cubic Feet.

4.2.1. TFT Oven Control Display

The 4.3-inch TFT full touch screen display provides intuitive control over oven functions, temperature, and timers. You can easily select cooking modes, set precise temperatures, and program cooking start and finish times.




Figure 6: TFT Oven Control Display.

4.2.2. Convection Cooking

To activate convection cooking, select the convection mode via the TFT display. The fan circulates hot air, ensuring uniform cooking and browning. This is ideal for baking, roasting, and multi-rack cooking.

4.2.3. Special Functions

- **Pizza Function:** Optimized settings for baking perfect pizzas.
- **Child Lock:** Engages the child lock feature through the TFT display to prevent accidental operation.

5. MAINTENANCE & CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your ILVE range.

5.1. Self-Clean Mode

The oven features a self-clean mode for convenient cleaning of the oven interior. Follow the instructions on the TFT display to initiate the self-cleaning cycle. Ensure all oven racks and accessories are removed before starting the self-clean cycle.

5.2. General Cleaning

- Clean the cooktop surface with a soft cloth and mild detergent after each use.
- For stainless steel surfaces, use a non-abrasive stainless steel cleaner.
- The triple glass cool door is designed for easy cleaning; refer to the manual for instructions on removing the glass panes for thorough cleaning.

6. TROUBLESHOOTING

If you encounter any issues with your ILVE range, refer to the following common troubleshooting tips. For more complex problems, contact a qualified service technician.

Problem	Possible Cause	Solution
Oven not heating	Power supply issue, incorrect settings	Check circuit breaker. Verify oven settings on TFT display.
Cooktop element not turning on	Element knob not fully engaged, power issue	Ensure knob is turned to a heat setting. Check power supply.
TFT display unresponsive	Temporary software glitch	Turn off power to the range at the circuit breaker for 5 minutes, then restore power.

7. SPECIFICATIONS

Detailed technical specifications for the ILVE 40 Inch Majestic II Series Freestanding Electric Double Oven Range.

Brand Name: Ilve

Product Dimensions: 32 x 44 x 40 inches

Efficiency: High Efficiency

Capacity (Main Oven): 3.82 Cubic Feet

Installation Type: Freestanding

Part Number: UMDI10NS3SSG

Form Factor: Freestanding

Special Features: Self-Cleaning, Child Lock

Oven Cooking Mode: Convection

Burner Type: Radiant (6 Elements)

Drawer Type: Warming

Color: Stainless Steel

Control Console: Touch Screen (TFT Display)

Voltage: 220 Volts

Fuel Type: Induction

Material Type: Stainless Steel


8. WARRANTY & SUPPORT

For warranty information and customer support, please refer to the documentation provided with your appliance at the time of purchase or visit the official ILVE website. Keep your proof of purchase for warranty claims.

For technical assistance or service requests, please contact ILVE customer service or an authorized service provider.

© 2023 Ilve. All rights reserved.

Related Documents - UMDI10NS3SSG

	<p>How to Replace the TFT Display on ILVE Majestic Ranges</p> <p>A comprehensive guide for ILVE Majestic Range owners and technicians on safely and properly replacing the TFT display, including necessary tools and step-by-step instructions.</p>
	<p>ILVE Range Cooker User Manual</p> <p>Comprehensive user manual for ILVE Professional, Proline, Serie K, and Majestic range cookers, covering safety, usage instructions, cleaning, maintenance, and troubleshooting.</p>

 <p>How to Unbox and Install ILVE Majestic II Range Legs: 14 Easy Steps</p> <p>A comprehensive guide detailing the 14 easy steps to unbox and install the legs on your ILVE Majestic II Range, ensuring a safe and efficient setup for optimal cooking performance.</p>	
 <p>How to Install or Replace Handles on Your ILVE Majestic Range</p> <p>A comprehensive, step-by-step guide from ILVE detailing the process of installing or replacing handles on your Majestic Range. Includes required tools and detailed instructions for a safe and proper installation.</p>	
 <p>ILVE Majestic Range Quick Start Guide</p> <p>A quick start guide for the ILVE Majestic Range, covering installation, clock and timer controls, cooking modes, panel lights, oven cooling, and cleaning instructions.</p>	
 <p>How to Replace the Power Board on ILVE Majestic Ranges - Repair Guide</p> <p>A comprehensive, step-by-step guide for replacing the power board on ILVE Majestic Ranges. Includes tools required, detailed instructions, and final recommendations for safe and effective repair.</p>	