Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- White Shark /
- > White Shark Cyrus GM-3001 Gaming Mouse User Manual

White Shark GM-3001

White Shark Cyrus GM-3001 Gaming Mouse User Manual

INTRODUCTION

This manual provides essential instructions for the White Shark Cyrus GM-3001 Gaming Mouse. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device. Please read this manual thoroughly before using the product.

PACKAGE CONTENTS

Verify that all items are present in the package:

• White Shark Cyrus GM-3001 Gaming Mouse (USB ICSB-GM3001)



Image: The White Shark Cyrus GM-3001 Gaming Mouse, featuring its ergonomic design and illuminated scroll wheel and logo.

SETUP

- 1. **Connect the Mouse:** Locate an available USB port on your computer. Insert the USB connector of the White Shark Cyrus GM-3001 Gaming Mouse into the USB port.
- 2. **Driver Installation:** The mouse is plug-and-play. Your operating system (Windows 7/8/10 or Mac OS) should automatically detect and install the necessary drivers. No additional software installation is typically required for basic functionality.
- 3. **Verification:** Once connected, the mouse's LED lighting should activate, indicating it is powered on. Move the mouse to confirm cursor movement on your screen.

OPERATING INSTRUCTIONS

The White Shark Cyrus GM-3001 Gaming Mouse is designed with 6 buttons for enhanced control and an optical sensor for precise tracking.





Image: Top-down view of the mouse, highlighting the scroll wheel, left/right click buttons, and the DPI adjustment button.

Button Functions

- Left Click Button: Standard primary click function.
- Right Click Button: Standard secondary click function.
- Scroll Wheel (Middle Button): Scrolls content up or down. Pressing it acts as a middle click button.
- DPI Adjustment Button: Located behind the scroll wheel, this button cycles through DPI settings.

• Side Buttons (Forward/Backward): Typically used for navigation (e.g., web browser forward/backward). These can often be customized in game or system settings.

DPI Adjustment

The mouse features an adjustable DPI (Dots Per Inch) button, allowing you to change cursor sensitivity on the fly. Press the DPI button to cycle through the following resolution settings:

- 1200 DPI
- 1600 DPI
- 2400 DPI
- 3200 DPI

Each DPI setting may be indicated by a change in the LED lighting color, providing visual feedback for the current sensitivity level.

LED Lighting

The mouse incorporates 4-color LED lighting. This lighting provides aesthetic enhancement and may also serve as an indicator for the selected DPI setting. The colors cycle automatically or change with DPI adjustments.



Image: Side view of the mouse, highlighting the textured rubber coating for improved grip and the illuminated side strip.

MAINTENANCE

To maintain the performance and appearance of your White Shark Cyrus GM-3001 Gaming Mouse, follow these guidelines:

- Cleaning: Use a soft, dry cloth to wipe the surface of the mouse. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, solvents, or abrasive cleaners.
- Sensor Care: Keep the optical sensor on the underside of the mouse clean and free from dust or debris. Use a cotton swab or compressed air if necessary.
- **Storage:** When not in use, store the mouse in a clean, dry environment away from extreme temperatures.
- Cable Management: Avoid sharply bending or twisting the USB cable to prevent internal damage.

TROUBLESHOOTING

If you encounter issues with your gaming mouse, refer to the following common solutions:

| Problem | Possible Cause | Solution |
|-------------------------------------|---|---|
| Mouse not responding | Loose USB connection, faulty USB port, driver issue. | Ensure USB cable is securely plugged in. Try a different USB port. Restart your computer. |
| Cursor movement is erratic or jumpy | Dirty optical sensor, unsuitable mouse pad surface. | Clean the optical sensor. Use a clean, uniform mouse pad or surface. |
| DPI button not changing sensitivity | Button malfunction, system conflict. | Ensure no other software is overriding mouse settings. Try restarting the computer. |
| LED lighting not working | Power issue, internal fault. | Check USB connection. If the mouse functions otherwise, the lighting issue may not affect core functionality. |

SPECIFICATIONS

| Brand | White Shark |
|--------------------------------|--|
| Model | Cyrus GM-3001 |
| Color | Black |
| Connectivity Technology | USB 2.0 |
| Motion Detection Technology | Optical (Instant A704 Chipset) |
| Number of Buttons | 6 (6D design) |
| DPI Resolution | 1200 / 1600 / 2400 / 3200 DPI (Adjustable) |
| Acceleration | 60 IPS |
| LED Lighting | 4-color LED |
| Lifespan | 5 million clicks |
| Coating | Rubber coating for enhanced grip |
| Compatible Operating Systems | Windows 7 / 8 / 10, Mac OS |
| Dimensions (L x W x H) | 133 mm x 68 mm x 40 mm |
| Item Weight | 119 Grams |
| Recommended Use | Gaming |

WARRANTY AND SUPPORT

Information regarding specific warranty terms and spare parts availability for the White Shark Cyrus GM-3001 Gaming Mouse is not explicitly provided in the product details. For support or warranty inquiries, please contact your retailer or the manufacturer directly.

Guaranteed software updates information is not available.

© 2023 White Shark. All rights reserved.

Related Documents - GM-3001



White Shark USB Gaming Mouse Quick Start Guide

This guide provides simple instructions for connecting and using your White Shark USB Gaming Mouse. Learn how to plug in your mouse and ensure automatic driver installation for a seamless gaming experience.



White Shark GH-2044 WOLF Headphones User Manual

User manual for the White Shark GH-2044 WOLF headphones, providing setup instructions and usage information in English and Macedonian.

amount of the state of the stat

White Shark GSP-968 MOOD Gaming Speaker User Manual

User manual for the White Shark GSP-968 MOOD Gaming Speaker, detailing product functions, specifications, package contents, usage instructions, tips, and troubleshooting.



White Shark SPARTAN GK-1925 Keyboard Manual and Warranty

Comprehensive user manual and warranty information for the White Shark SPARTAN GK-1925 AZERTY mechanical keyboard, detailing setup, features, usage, and troubleshooting.



White Shark GH-2140 OX Gaming Headset User Manual

User manual for the White Shark GH-2140 OX Gaming Headset, providing setup and connection instructions for PC and audio devices.

All those forming SAB

The Same of the American Same of the Same o

Whiteshark AL Maus Gaming USB - Setup and Specifications

Instructions for connecting and setting up the Whiteshark AL Maus Gaming USB. Includes product specifications and support information.