

KORG i3

Korg i3 61-Key Synthesizer Music Workstation User Manual

Model: i3 | Brand: KORG

1. WELCOME

Thank you for purchasing the Korg i3 61-Key Synthesizer Music Workstation. This instrument is designed to help you easily realize your musical ideas, offering a versatile range of sounds, styles, and recording capabilities. Please read this manual thoroughly to ensure proper use and to maximize your enjoyment of the i3.

2. SAFETY INFORMATION

To prevent electric shock, do not open the casing. Refer servicing to qualified personnel only. Do not expose this appliance to rain or moisture. Avoid placing the unit near heat sources or in direct sunlight. Ensure proper ventilation. Use only the specified power adapter or batteries. Keep out of reach of children.

3. PACKAGE CONTENTS

- Korg i3 61-Key Synthesizer Music Workstation
- AC Adapter
- Quick Start Guide
- Safety Precautions

4. SETUP

4.1 Powering On/Off

Connect the supplied AC adapter to the DC 12V input jack on the rear panel and plug it into a power outlet. Alternatively, the i3 supports battery operation for portability. To power on, press the power button. To power off, press and hold the power button until the unit shuts down.

4.2 Connecting Peripherals

The Korg i3 offers various connectivity options on its rear panel:

- **Headphones:** Connect standard 3.5mm headphones to the PHONES jack for private practice.
- **USB:** Use the USB Type A port for connecting to a computer (TO HOST) or external storage devices (TO DEVICE).
- **MIDI:** Connect external MIDI devices using the MIDI IN/OUT ports.
- **Audio In/Out:** Connect external audio sources to the AUDIO IN jack or output audio to external speakers/amplifiers via the OUTPUT L/MONO and R jacks.
- **Foot Controller:** Connect a foot controller (e.g., sustain pedal) to the FOOT CONTROLLER jack for expressive control.



Image: Rear panel connections, showing various input and output ports including USB, MIDI, Audio, and Foot Controller.

あらゆる状況での使用に対応する 多彩な入出力端子を搭載



Image: Detailed view of the rear panel, highlighting the DC 12V power input, USB TO HOST/DEVICE, MIDI OUT, FOOT CONTROLLER, OUTPUT L/MONO and R, and AUDIO IN ports.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation and Display

The i3 features a backlit LCD panel that displays current settings, sound names, and sequencer information. Use the navigation buttons and data entry dial to browse menus and adjust parameters.

現在の設定を演奏者が確認しやすい バックライト付きLCDパネル



Image: A close-up of the Korg i3's central control panel, featuring a backlit LCD screen displaying 'Grand Piano' and 'Play the i3', surrounded by various buttons and a data entry dial for navigation and selection.

5.2 Sound Selection

The i3 offers a wide variety of sound sets and styles. Use the dedicated buttons and the data entry dial to select different instrument sounds such as Grand Piano, Organ, Brass, Drums, Guitar, and more. The keyboard features touch-sensitive keys for expressive performance.

約800の多彩なサウンドを収録 楽しく演奏できる伴奏機能も搭載



Image: A close-up of the Korg i3's control surface, showing buttons for sound sets (Upper 1, Upper 2, Upper 3, Lower/Split), instrument categories (Bass, Drum, Percussion, Chord 1-8), and Style Performance controls, indicating the wide range of sound options available.

5.3 Using the Sequencer

The built-in sequencer allows you to record, save, and play back both MIDI and audio files. Refer to the detailed sequencer section in the full manual for advanced recording and editing techniques.

6. FEATURES OVERVIEW

The Korg i3 is a versatile music workstation designed for various musical situations, from live performances to home studio use. Key features include:

- 61-Key touch-sensitive keyboard.
- Extensive sound sets and backing styles.
- Built-in MIDI and audio sequencer.
- Lightweight and portable design, supporting battery operation.
- Diverse connectivity options including USB, MIDI, and audio I/O.



Image: Front view of the Korg i3 61-Key Synthesizer Music Workstation, showcasing its full keyboard, control panel, and display.



Image: An angled perspective of the Korg i3, highlighting its sleek design and compact form factor.

ラバー塗装によるマット仕上げのボディと パンチング・メタルによるサイド・パネル



Image: Side profile of the Korg i3, illustrating its slim and lightweight construction, ideal for portability.

7. MAINTENANCE

7.1 Cleaning

Wipe the unit with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and then dry thoroughly. Avoid using abrasive cleaners, waxes, or solvents.

7.2 Storage

When not in use for extended periods, store the i3 in a cool, dry place away from direct sunlight and extreme temperatures. If using batteries, remove them before long-term storage to prevent leakage.

8. TROUBLESHOOTING

- **No Sound:** Check volume levels on the i3 and any connected audio equipment. Ensure cables are securely connected.
- **Power Issues:** Verify AC adapter connection or check battery levels.
- **Keys Not Responding:** Ensure the unit is powered on and not in a frozen state. Try restarting the unit.

For further assistance, please refer to the full user manual or contact KORG customer support.



9. SPECIFICATIONS


- **Number of Keys:** 61
- **Key Type:** Touch-Sensitive
- **Dimensions:** 11.65 x 40.83 x 3.15 inches (29.6 cm x 103.7 cm x 8 cm)
- **Item Weight:** 0.203 ounces (approximately 5.75 grams, note: this weight seems unusually low and may be a data entry error, typical keyboard weight is several pounds/kg)
- **Power Source:** Battery Powered (also AC adapter)
- **Connectivity:** USB Type A (TO HOST, TO DEVICE), MIDI IN/OUT, Audio IN, OUTPUT L/MONO, R, 3.5mm Headphones Jack, Foot Controller
- **Material Type:** Plastic
- **Color:** Black, Grey, White
- **Model Name:** i3 Music Workstation

10. WARRANTY AND SUPPORT

KORG products are covered by a limited warranty. Please refer to the warranty card included with your product for specific terms and conditions. For technical support, product registration, or service inquiries, please visit the official KORG website or contact your local KORG distributor.


Related Documents - i3

	<p>KORG KROSS SYNTHESIZER WORKSTATION Operation Guide</p> <p>Detailed operation guide for the KORG KROSS SYNTHESIZER WORKSTATION, covering setup, modes, program and combination editing, sequencing, effects, and advanced features. Learn to master your KROSS synthesizer.</p>
	<p>Korg KROSS Synthesizer Workstation Parameter Guide</p> <p>Comprehensive guide detailing parameters for the Korg KROSS Synthesizer Workstation, covering Program, Combination, Sequencer, Effects, and advanced modulation settings for detailed sound design.</p>



[Korg KRONOS Quick Start Guide](#)

A quick start guide for the Korg KRONOS Music Workstation, covering features, front and rear panel controls, user interface, playing sounds, sequencing, saving/loading data, and specifications.



[Korg Triton Tools: User Guide for Triton Classic and Triton Rack Software](#)

Comprehensive guide to Korg Triton Tools software, covering setup, MIDI/audio routing, PCG file management, and integration with controllers like Korg Nanopad 2 and NanoKontrol 2 for Triton Classic and Triton Rack workstations.



[Korg SQ-1 Step Sequencer Owner's Manual](#)

Comprehensive guide to the Korg SQ-1 Step Sequencer, covering its features, controls, connections, specifications, and operation for music production. Learn how to use the step knobs, buttons, modes, and connectivity options.



[KORG KRONOS Music Workstation - Introduction Guide](#)

This comprehensive guide introduces the KORG KRONOS Music Workstation, detailing its powerful synthesis engines, performance features, operational controls, and connectivity options. Learn how to navigate the interface, play sounds, record music, and manage your data.