

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [RockJam](#) /

› [RockJam 61 Key Keyboard Piano Super Kit - Instruction Manual](#)

RockJam RJ5061

RockJam 61 Key Keyboard Piano Super Kit - Instruction Manual

Model: RJ5061 | Brand: RockJam

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your RockJam 61 Key Keyboard Piano Super Kit. This comprehensive kit includes a 61-key digital keyboard, a sturdy keyboard stand, a comfortable piano bench, and high-quality over-ear headphones. The keyboard features advanced functionality with 200 tones, 200 rhythms, and 40 demo songs, delivered through integrated stereo speakers. It also offers USB and AUX inputs for versatile connectivity, making it suitable for both beginners and experienced players.

WHAT'S INCLUDED

Your RockJam 61 Key Keyboard Piano Super Kit package contains the following components:

- 61 Key Keyboard Piano
- Piano Bench
- Keyboard Stand
- Keynote Stickers
- Sheet Music Stand



Image: The complete RockJam 61 Key Keyboard Piano Super Kit, showing the keyboard, stand, bench, and headphones.

SETUP GUIDE

1. Keyboard Stand Assembly

The keyboard stand is designed for stability and adjustability.

1. Unfold the X-style keyboard stand.
2. Adjust the height using the quick-release mechanism to a comfortable playing position. Ensure the grips for stability are securely in place.
3. Verify that the rubber feet are firmly on the ground for secure grip.



Image: Detailed view of the keyboard stand's features, including grips for stability, quick release mechanism, and rubber feet.

2. Piano Bench Setup

The piano bench provides comfortable seating.

1. Unfold the piano bench.
2. Ensure the legs are fully extended and stable. The bench features extra padding for comfort and rubber feet for secure placement.




Image: The piano bench, highlighting its 18-inch height, 15.5-inch width, extra padding, and rubber feet.

3. Keyboard Placement and Power

1. Carefully place the 61-key keyboard onto the assembled stand, ensuring it is centered and stable.
2. Connect the included mains power adapter to the keyboard's power input and a suitable wall outlet. Alternatively, for portable use, insert 6 x 1.5V Size D batteries (not included) into the battery compartment.
3. Attach the sheet music stand to the designated slot on the keyboard.



200 Tones




200 Rhythms



30 Demos



Record



Pitch Bend




Image: Overhead view of the RockJam keyboard, illustrating its control panel, speakers, and key layout.

4. Headphone Connection

For private practice, connect the included over-ear headphones to the 3.5mm headphone jack on the keyboard.



Image: A pair of black RockJam over-ear headphones.

OPERATING INSTRUCTIONS

Basic Functions

- **Power On/Off:** Use the power button to turn the keyboard on or off.
- **Volume Control:** Adjust the main volume using the dedicated volume buttons or knob.
- **Tones and Rhythms:** Select from 200 tones and 200 rhythms using the numerical keypad and the LED display. Refer to the keyboard's panel for tone and rhythm categories.
- **Demo Songs:** Play one of the 40 built-in demo songs to experience the keyboard's capabilities.



Image: A close-up of the keyboard's control panel, displaying the tone and rhythm selection options.

Advanced Features

- **Record and Playback:** Utilize the record function to capture your performances (up to 46 notes memory) and the playback function to listen to them.
- **Teaching Modes:** Engage the three teaching modes to assist with learning.
- **Metronome:** Use the built-in metronome for timing practice.
- **Split Keyboard Mode:** Divide the keyboard into two sections for different instrument sounds or for duet playing.
- **Sustain:** Apply sustain effect to notes for a prolonged sound.
- **Transpose:** Change the key of the keyboard without altering finger positions.
- **Pitch Bend:** Use the pitch bend wheel to smoothly vary the pitch of notes.



Image: A detailed view of the pitch bend wheel located on the left side of the keyboard.

Connectivity

- **USB Input:** Connect a USB stick (MP3) to play along with your favorite songs.
- **AUX Input:** Connect mobile devices via the AUX input to stream audio through the keyboard's speakers.

Learning Resources

Your kit includes access to exclusive content within the Simply Piano application (iOS & Android) and TakeLessons for face-to-face and group lessons.

Keynote stickers are provided to assist with learning note identification on the keys.




Image: Close-up of piano keys with keynote stickers applied, indicating notes like Middle C, D, E, and F.

MAINTENANCE

To ensure the longevity and optimal performance of your RockJam Keyboard Piano Super Kit, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the keyboard and accessories. Avoid abrasive cleaners or solvents.
- **Storage:** When not in use, store the keyboard in a dry, cool place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the keyboard and its components with care to prevent damage. Avoid dropping or subjecting them to strong impacts.
- **Power:** Disconnect the power adapter when the keyboard will not be used for extended periods. If using batteries, remove them to prevent leakage.

TROUBLESHOOTING

If you encounter any issues with your RockJam Keyboard Piano Super Kit, please refer to the following common troubleshooting tips:

- **No Sound:**
 - Ensure the power adapter is securely connected or batteries are correctly inserted and charged.
 - Check the volume level on the keyboard and any connected headphones.
 - Verify that headphones are fully plugged into the correct jack.
- **Distorted Sound:**
 - Reduce the volume.
 - Check for loose connections.
 - Ensure no foreign objects are obstructing the speakers.
- **Keys Not Responding:**
 - Ensure the keyboard is powered on.
 - Check for any debris under the keys.
- **Display Not Working:**
 - Confirm the keyboard is powered on.
 - If the issue persists, contact customer support.

For more complex issues, please consult the official RockJam support resources.

SPECIFICATIONS

Feature	Detail
Model Name	Keyboard Piano Superkit with Pitch Bend
Item Model Number	RJ5061
Brand	RockJam
Number of Keys	61
Tones	200
Rhythms	200
Demo Songs	40
Connectivity Technology	Auxiliary, Headphone Jack, USB
Power Source	Battery Powered (6 x 1.5V Size D), Mains Power Adapter
Product Dimensions	11.2"D x 36.8"W x 3.1"H
Item Weight	3.3 Kilograms (7.26 pounds)
Output Wattage	10 Watts

Voltage	120 Volts
Manufacturer	PDT Limited
Country of Origin	China

OFFICIAL PRODUCT VIDEOS

Currently, there are no official product videos from the seller available for embedding in this manual. Please refer to the product page for any available video content.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official RockJam website or the contact details provided with your purchase.

A digital version of this user manual is available for download: [User Manual \(PDF\)](#)