

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [GUESS](#) /
- › [GUESS 30MM Watch GW0022L2 Instruction Manual](#)

GUESS GW0022L2

GUESS 30MM Watch GW0022L2 Instruction Manual

Model: GW0022L2

INTRODUCTION

This instruction manual provides essential information for the proper use, setup, and maintenance of your GUESS 30MM Watch, model GW0022L2. Please read this manual thoroughly before using your watch to ensure optimal performance and longevity.

PRODUCT OVERVIEW

The GUESS 30MM Watch GW0022L2 is an elegant timepiece featuring an analog display and reliable Quartz movement. It is crafted with a stainless steel case and band, accented with crystal embellishments. The watch is designed for daily wear and offers water resistance up to 30 meters.



Image: The GUESS 30MM Watch GW0022L2 in Gold Tone/Gold Tone/Champagne, showcasing its elegant design and crystal accents.

Key Components:

- **Case:** 30mm diameter, Stainless Steel.
- **Dial:** Analog display, Gold color, Gilt face style.
- **Movement:** Quartz.
- **Crystal:** Mineral.
- **Band:** Stainless Steel bracelet, 16mm width, adjustable.
- **Clasp:** Deployment Clasp.
- **Crown:** Used for setting time.
- **Water Resistance:** Up to 30 meters (100 feet).



Image: The GUESS watch packaging box, indicating the product's presentation.


SETUP INSTRUCTIONS

1. Setting the Time:

1. Pull the crown (the small knob on the side of the watch case) gently outwards to the time-setting position.
2. Turn the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. Once the correct time is set, push the crown back into its original position to engage the movement and start the watch.

2. Adjusting the Bracelet:

The stainless steel bracelet is adjustable to ensure a comfortable fit. If the bracelet is too loose or too tight, it may require professional adjustment by a jeweler to remove or add links. Do not attempt to force or bend the links yourself, as this may damage the watch.



Video: This video illustrates various watch case sizes on different wrist sizes, providing a visual guide for how different millimeter cases appear on 6-inch and 7-inch wrists. This can help in understanding watch fit and potential bracelet adjustment needs.

OPERATING INSTRUCTIONS

Timekeeping:

Your GUESS watch uses a Quartz movement, known for its accuracy and reliability. Once the time is set, the watch will keep accurate time as long as the battery is functional.

Water Resistance:

This watch is water resistant up to 30 meters (100 feet). This means it is suitable for everyday use and can withstand splashes or brief immersion in water. However, it is **not** recommended for swimming, diving, or prolonged water activities. Do not operate the crown while the watch is wet or submerged.

- **30 Meters (3 ATM/3 BAR):** Suitable for everyday use. Splash/rain resistant. Not suitable for showering, bathing, swimming, snorkeling, water-related work, or fishing.

MAINTENANCE

Cleaning:

To maintain the appearance of your watch, wipe the case and bracelet regularly with a soft, dry cloth. For stainless steel, a slightly damp cloth can be used, followed by a dry cloth. Avoid using chemical cleaners, as they may damage the watch's finish or seals.

Battery Replacement:

The watch is powered by one Lithium Metal battery (included). When the watch stops or the time becomes inaccurate, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance seal is properly maintained.

Storage:

When not wearing your watch, store it in a cool, dry place, away from direct sunlight and extreme temperatures. The original packaging box can be used for storage.

TROUBLESHOOTING

- **Watch not running:**

- Check if the crown is pushed all the way in.
- The battery may need replacement.

- **Time is inaccurate:**

- Reset the time as per the "Setting the Time" instructions.
- If inaccuracy persists, the battery may be low, or the movement may require servicing.

- **Condensation under the crystal:**

- This indicates a breach in the water resistance seal. Avoid further contact with water and seek professional service immediately.

For issues not listed here, please contact GUESS customer support or a certified watch repair center.

SPECIFICATIONS

Model Number	GW0022L2
Brand	GUESS
Case Diameter	30 Millimeters
Case Material	Stainless Steel
Band Material	Stainless Steel
Band Width	16 Millimeters
Movement	Quartz
Display Type	Analog
Crystal Type	Mineral
Water Resistance Depth	30 Meters

Power Source	Battery Powered (1 Lithium Metal battery included)
Item Weight	53.2 Grams
Product Dimensions	4.72 x 4.72 x 4.72 inches

WARRANTY AND SUPPORT

Your GUESS watch is covered by a manufacturer's warranty. For specific details regarding the warranty period and coverage, please refer to the warranty card included with your purchase or visit the official GUESS website.

For technical support, service, or inquiries about your watch, please contact GUESS customer service. Contact information can typically be found on the official GUESS website or in the documentation provided with your watch.

Manufacturer: GUESS