Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JVC LT-43MAW595

JVC LT-43MAW595 4K LED Roku Smart TV

User Manual

Introduction

This user manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your JVC LT-43MAW595 43-Inch-Class 4K LED Roku Smart TV. Please read this manual thoroughly before operating your TV and retain it for future reference.

The JVC LT-43MAW595 offers a superior viewing experience with its 4K UHD resolution and HDR capabilities. Featuring the intuitive Roku TV operating system, it provides seamless access to a wide array of streaming services and smart functionalities. Its built-in Wi-Fi and Ethernet connectivity ensure easy integration into your home network.



Figure 1: Front view of the JVC LT-43MAW595 4K LED Roku Smart TV.

Safety Information

Always observe the following safety precautions to prevent fire, electric shock, or injury:

- Do not expose the TV to rain or moisture.
- Do not block ventilation openings. Ensure adequate space around the TV for proper airflow.
- Do not place the TV on an unstable cart, stand, tripod, bracket, or table.
- Protect the power cord from being walked on or pinched.
- Unplug the TV during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

What's in the Box

Upon unpacking, please verify that all items listed below are included:

- JVC LT-43MAW595 4K LED Roku Smart TV
- Remote Control
- TV Stand Legs (2)
- Screws for Stand Installation
- Power Cord
- User Manual (this document)

Setup

1. Unpacking

Carefully remove the TV from its packaging. It is recommended to retain the original packaging materials for future transport or servicing needs.

2. Stand Installation

If you are not wall-mounting the TV, attach the stand legs:

1. Place the TV face-down on a soft, clean surface to prevent screen damage.
2. Align each stand leg with the corresponding screw holes on the bottom of the TV.
3. Secure each leg with the provided screws. Ensure they are tightened firmly.



Figure 2: JVC TV with stand installed, positioned on a media console.

3. Wall Mounting (Optional)

The TV is compatible with VESA standard wall mounts. Refer to the wall mount manufacturer's instructions for proper installation. Ensure the wall mount can support the weight of the TV (approximately 21.6 pounds).

4. Connecting Devices

The TV features multiple input ports for connecting external devices. Refer to the rear view image for port locations.



Figure 3: Rear view of the JVC LT-43MAW595 TV, highlighting connectivity ports.

- **HDMI Ports (3):** Connect Blu-ray players, game consoles, cable/satellite boxes, and other HDMI-enabled devices.
- **USB Port:** For multimedia playback from a compatible USB drive.
- **Composite Video Input:** For connecting older devices like VCRs or DVD players.
- **Ethernet/LAN Port:** For a wired internet connection.
- **Antenna/Cable Input:** For connecting an antenna or cable TV feed.

5. Power Connection

Once all devices are connected, plug the power cord into the TV's power input, then into a wall outlet.

6. Initial Setup (Roku TV)

Upon first power-on, the TV will guide you through the Roku TV setup process:

1. Select your language.
2. Connect to your network (Wi-Fi or Ethernet).
3. Activate your Roku account (or create a new one).
4. Scan for channels (if using an antenna).
5. Add streaming channels.

Operating the TV

Remote Control

The included remote control allows you to navigate the Roku TV interface and control TV functions. Familiarize yourself with the buttons:

- **Power Button:** Turns the TV on or off.

- **Directional Pad (D-Pad):** Navigates menus and selects items.
- **OK/Select Button:** Confirms selections.
- **Home Button:** Returns to the Roku TV home screen.
- **Back Button:** Returns to the previous screen.
- **Volume Up/Down:** Adjusts audio volume.
- **Mute Button:** Mutes or unmutes audio.
- **Channel Up/Down:** Changes channels (for antenna/cable).
- **Input Button:** Selects input sources (HDMI, AV, TV).
- **Streaming Service Buttons:** Dedicated buttons for popular streaming apps.

Power On/Off

Press the **Power** button on the remote control or on the TV itself to turn the TV on or off.

Input Selection

From the Roku TV home screen, select the desired input tile (e.g., HDMI 1, AV) to switch to a connected device. Alternatively, press the **Input** button on the remote to cycle through available inputs.

Roku TV Interface

The Roku TV home screen provides access to all your entertainment options. You can:

- Browse and add streaming channels.
- Access connected devices (HDMI, AV).
- Adjust TV settings.
- Search for movies, TV shows, and actors across various streaming services.

Picture and Sound Settings

While watching content, press the **Star (*)** button on the remote to access quick settings for picture mode, sound mode, and other options. For more detailed adjustments, navigate to **Settings > TV inputs** or **Settings > Audio** from the home screen.

Maintenance

Cleaning the TV

- **Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, use a screen cleaner specifically designed for TVs, applied to the cloth, not directly to the screen.
- **Cabinet:** Wipe the TV cabinet with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents.
- Always unplug the TV before cleaning.

Troubleshooting

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
No Power	Ensure the power cord is securely plugged into the TV and the wall outlet. Check if the wall outlet is working by plugging in another device. Try a different power outlet.

Problem	Possible Cause / Solution
No Picture / No Sound	Verify the correct input source is selected (e.g., HDMI 1, AV). Check all cable connections between the TV and external devices. Ensure the volume is not muted or set to minimum. Restart the TV and any connected devices.
Remote Control Not Working	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor. Point the remote directly at the TV.
Network Connection Issues	Check your router and modem to ensure they are powered on and functioning. Restart your router and modem. Go to **Settings > Network > Check connection** on your TV. If using Wi-Fi, try moving the TV closer to the router or using a wired Ethernet connection.

Specifications

The following table outlines the key technical specifications for the JVC LT-43MAW595 TV:

Feature	Specification
Model Number	LT-43MAW595
Screen Size (Diagonal)	43 Inches (42.5 in. diagonal screen)
Resolution	4K UHD (3840 x 2160)
Display Technology	LED
Refresh Rate	60 Hz (Native), 120 (Effective)
HDR Support	Yes
Operating System	Roku TV OS
Connectivity	Built-in Wi-Fi, Ethernet/LAN
HDMI Inputs	3
USB Ports	1
Product Dimensions (W x D x H)	38" x 8.7" x 24.4" (with stand)
Item Weight	21.6 pounds
Color	Black



Figure 4: Dimensions of the JVC LT-43MAW595 TV.

Warranty and Support

For warranty information and technical support, please refer to the documentation included with your product or visit the official JVC support website. The warranty period and terms may vary by region and purchase date.

For further assistance, you may contact JVC customer support. Contact details are typically available on the manufacturer's website or in the product's packaging.

JVC LT-43MAW595 User Manual © 2024 JVC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08428QFCT

More documents and user manuals: **https://manuals.plus/**