

ONN ONA19DS007

User Manual

ONN ONA19DS007 USB 2.0 FLASH DRIVE (64 GB)

Model: ONA19DS007 | Brand: ONN

Introduction

This manual provides essential information for the proper use and maintenance of your ONN ONA19DS007 USB 2.0 Flash Drive. This device is designed for reliable data storage and transfer, offering 64 GB of capacity for your important files, photos, and videos. Its compact and lightweight design ensures portability, and the protective slider mechanism allows for easy connection.

Product Overview



Figure 1: The ONN ONA19DS007 USB 2.0 Flash Drive. This image shows the black flash drive with its protective slider mechanism extended, revealing the USB connector. The 'onn' logo is visible on the top surface of the drive.

The ONN ONA19DS007 is a 64 GB USB 2.0 flash drive featuring a durable, lightweight design. It includes a protective slider that retracts the USB connector when not in use, safeguarding it from damage. The drive is compatible with any USB-enabled device, providing a convenient solution for portable data storage.

Setup

1. **Unpack the Device:** Carefully remove the flash drive from its packaging.
2. **Extend the USB Connector:** Slide the protective cover to expose the USB connector.
3. **Connect to a USB Port:** Insert the flash drive into an available USB 2.0 or USB 3.0 port on your computer or compatible device. The operating system should automatically detect and install the necessary drivers.
4. **Access the Drive:** Once detected, the flash drive will appear as a removable disk drive in your computer's file explorer (e.g., "This PC" on Windows, "Finder" on macOS).

Operating Instructions

The ONN ONA19DS007 flash drive operates as a standard removable storage device. Follow these steps to transfer files:

1. **Open the Drive:** Double-click on the flash drive icon in your file explorer to open its contents.
2. **Transfer Files:**
 - To copy files *to* the flash drive: Drag and drop files or folders from your computer to the flash drive window. Alternatively, right-click on the desired files, select "Copy," then navigate to the flash drive window, right-click, and select "Paste."
 - To copy files *from* the flash drive: Drag and drop files or folders from the flash drive window to a location on your computer. Alternatively, right-click on the desired files on the flash drive, select "Copy," then navigate to your desired computer location, right-click, and select "Paste."
3. **Safely Remove Hardware:** Before disconnecting the flash drive, always safely eject it to prevent data corruption.
 - **Windows:** Click the "Safely Remove Hardware and Eject Media" icon in the system tray (bottom-right corner), then select the ONN flash drive. Wait for the "Safe to Remove Hardware" message.
 - **macOS:** Drag the flash drive icon from the desktop or Finder sidebar to the Trash icon, or right-click the drive icon and select "Eject."
4. **Disconnect:** Once safely ejected, you can physically remove the flash drive from the USB port. Retract the protective slider to cover the connector.

Maintenance

- **Physical Care:** Keep the flash drive clean and dry. Avoid exposing it to extreme temperatures, direct sunlight, or high humidity.
- **Protect the Connector:** Always retract the protective slider when the drive is not in use to prevent dust, dirt, or physical damage to the USB connector.
- **Avoid Drops and Impacts:** While durable, excessive force or dropping the drive can cause internal damage.
- **Data Backup:** Regularly back up important data stored on the flash drive to another storage medium to prevent data loss in case of device malfunction or loss.

Troubleshooting

Drive Not Detected:

- Ensure the flash drive is fully inserted into the USB port.
- Try a different USB port on your computer.
- Restart your computer and try again.
- Check "Disk Management" (Windows) or "Disk Utility" (macOS) to see if the drive is recognized but not assigned a drive letter or mounted.

Slow Transfer Speeds:

- Ensure you are using a USB 2.0 or higher port. While compatible with USB 3.0, the drive operates at USB 2.0 speeds.
- Avoid transferring many small files simultaneously, as this can be slower than transferring a few large files.
- Close other applications that might be using system resources.

Cannot Write Files to Drive:

- Check if the drive is full. Delete unnecessary files or transfer them to another location.
- The drive might be formatted with a file system (e.g., NTFS) that is read-only on certain operating systems (e.g., macOS without third-party software). Consider reformatting to exFAT or FAT32 if cross-platform compatibility is needed (note: reformatting will erase all data).
- Ensure you have appropriate permissions to write to the drive on your operating system.

Specifications

Brand	ONN
Model Name	ONA19DS007
Memory Storage Capacity	64 GB
Hardware Interface	USB 2.0
Connectivity Technology	USB
Write Speed	30 MB/s
Compatible Devices	USB-enabled devices
Product Dimensions	3 x 1 x 1 inches
Item Weight	0.81 ounces
UPC	681131283052

Warranty and Support

Specific warranty information for the ONN ONA19DS007 USB 2.0 Flash Drive is not provided within this manual. For warranty claims, technical support, or further assistance, please refer to the contact information provided with your purchase or visit the official ONN brand website.

Note: This product may be a refurbished item. Refurbished products are tested and certified to look and work like new. The refurbishing process includes functionality testing, basic cleaning, inspection, and repackaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question