onn 100004118

onn 32-inch 2.1 Soundbar with Wireless Subwoofer User Manual

Model: 100004118
Brand: onn

1. Introduction

This user manual provides detailed instructions for the setup, operation, and maintenance of your onn 32-inch 2.1 Soundbar with Wireless Subwoofer. Please read this manual thoroughly before using the product to ensure proper functionality and safety.

2. Safety Information

Always follow basic safety precautions when using this product to reduce the risk of fire, electric shock, and injury.

- Do not expose this appliance to rain or moisture.
- Do not block any ventilation openings.
- Ensure proper power supply and grounding.
- Do not open the casing; refer all servicing to qualified personnel.
- Keep away from heat sources and direct sunlight.

3. Package Contents

Verify that all items are present in the package:

- onn 32-inch Soundbar
- Wireless Subwoofer
- Remote Control
- Power Cable(s)
- HDMI Cable (if included)
- Optical Cable (if included)
- Auxiliary Cable (3.5mm, if included)
- User Manual (this document)

4. Product Overview

Familiarize yourself with the components of your onn soundbar system.

4.1 Soundbar and Subwoofer



Image 1: onn 32-inch Soundbar and Wireless Subwoofer. This image shows the soundbar, the wireless subwoofer, and the remote control, providing a complete view of the system components.



Image 2: Front view of onn 32-inch Soundbar with Subwoofer. This image provides a direct front view of the soundbar and subwoofer,

highlighting their sleek design.



Image 3: Close-up of onn Soundbar control panel. This image focuses on the top-mounted control buttons and LED indicators on the soundbar, showing power, volume, and input selection controls.

4.2 Soundbar Controls and Indicators

- **Power Button:** Turns the soundbar on or off.
- **Input/Source Button:** Cycles through available input sources (HDMI ARC, Optical, Aux, Bluetooth).
- **Volume Up/Down Buttons:** Adjusts the master volume.
- **Bluetooth Pairing Button:** Initiates Bluetooth pairing mode.
- **LED Indicators:** Display the current input source and status.

4.3 Rear Panel Connections

- **HDMI ARC Port:** For connecting to a TV with HDMI ARC support.
- **Optical Input:** For connecting to devices via optical cable.
- **AUX Input (3.5mm):** For connecting to devices via a 3.5mm audio cable.
- **Power Input:** For connecting the power cable.

5. Setup

Follow these steps to set up your soundbar system.

5.1 Placement

- Place the soundbar on a flat, stable surface directly in front of your TV, or mount it on the wall below your TV.
- Position the wireless subwoofer in a convenient location within the room, ideally near the soundbar for optimal bass response. Ensure it is within range for wireless connection.

5.2 Connecting to Power

1. Connect the power cable to the Power Input on the soundbar.
2. Plug the other end of the power cable into a wall outlet.
3. Connect the power cable to the wireless subwoofer.
4. Plug the other end of the subwoofer's power cable into a wall outlet. The subwoofer should automatically pair with the soundbar once both are powered on.

5.3 Audio Connections

Choose one of the following connection methods based on your TV or audio source.

5.3.1 HDMI ARC Connection (Recommended)

1. Connect one end of an HDMI cable (not always included) to the HDMI ARC port on your soundbar.
2. Connect the other end of the HDMI cable to the HDMI ARC port on your TV.
3. Ensure your TV's HDMI ARC function is enabled in its audio settings.

5.3.2 Optical Connection

1. Connect one end of an optical cable (not always included) to the Optical Input on your soundbar.
2. Connect the other end of the optical cable to the Optical Digital Audio Out port on your TV or audio source.
3. Ensure your TV's audio output is set to "Optical" or "PCM" in its audio settings.

5.3.3 AUX Connection

1. Connect one end of a 3.5mm auxiliary cable (not always included) to the AUX Input on your soundbar.
2. Connect the other end of the auxiliary cable to the 3.5mm Audio Out (headphone jack) on your TV or audio source.

6. Operating Instructions

6.1 Power On/Off

Press the **Power** button on the soundbar or remote control to turn the unit on or off.

6.2 Selecting Input Source

Press the **Input/Source** button on the soundbar or remote control repeatedly to cycle through the available input sources: HDMI ARC, Optical, AUX, and Bluetooth. The LED indicators on the soundbar will change to reflect the selected input.

6.3 Adjusting Volume

Use the **Volume Up (+)** and **Volume Down (-)** buttons on the soundbar or remote control to adjust the overall volume level.

6.4 Bluetooth Pairing

1. Turn on the soundbar.
2. Press the **Bluetooth** button on the soundbar or remote control to enter Bluetooth pairing mode. The Bluetooth

indicator will flash.

3. Enable Bluetooth on your mobile device (smartphone, tablet, etc.) and search for available devices.
4. Select "onn Soundbar" (or similar name) from the list of devices.
5. Once paired, the Bluetooth indicator will stop flashing and remain solid. You can now stream audio from your device to the soundbar.
6. To disconnect, press and hold the Bluetooth button on the soundbar or disconnect from your device's Bluetooth settings.

Note: This soundbar also features integrated Apple AirPlay 2 for seamless streaming from Apple devices. Refer to Apple's AirPlay 2 instructions for setup.

7. Maintenance

Proper care ensures the longevity of your soundbar system.

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the soundbar and subwoofer. Do not use liquid cleaners or aerosols.
- **Ventilation:** Ensure that the ventilation openings are not blocked to prevent overheating.
- **Storage:** If storing the unit for an extended period, disconnect it from power and store it in a cool, dry place.

8. Troubleshooting

If you encounter issues, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
No power	Power cable not connected; outlet not working.	Check power connections; try a different outlet.
No sound	Incorrect input selected; volume too low; cables loose.	Select correct input; increase volume; check audio cables. Ensure TV audio output is set correctly (e.g., PCM for Optical).
Subwoofer not pairing	Subwoofer not powered; out of range.	Ensure subwoofer is plugged in and powered on. Move subwoofer closer to the soundbar.
Bluetooth connection issues	Device too far; not in pairing mode; interference.	Ensure soundbar is in Bluetooth pairing mode. Move device closer. Disconnect other Bluetooth devices.

9. Specifications

Feature	Detail
Model Number	100004118
Sound Channel Configuration	2.1 Channel
Total Output Power	80 Watts (Max)
Connectivity Technology	Bluetooth, HDMI ARC, Optical, Aux (3.5mm)
Wireless Technology	Bluetooth, Wireless Subwoofer

Feature	Detail
Special Features	Bluetooth, Integrated Apple AirPlay 2
Product Dimensions (Soundbar)	63.5 x 17.78 x 15.24 cm (approx. 25 x 7 x 6 inches)
Product Weight	3.72 kg (approx. 8.2 lbs)
Power Source	Corded Electric

10. Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the time of purchase or visit the official onn website. Keep your proof of purchase for warranty claims.
Note: This product is listed as "Reacondicionado" (Refurbished). Warranty terms for refurbished products may vary. Please consult your retailer or the manufacturer for specific details regarding refurbished product warranties.

© 2024 onn. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

I bought an onn 32-inch 2.1 Channel Soundbar System (Model 100004118) but did not receive the remote or the manual. Where can I find them?

If you are missing the physical manual for your onn 32-inch 2.1 Soundbar (Model 100004118), you can access the

digital version directly on this page. It includes setup instructions, Bluetooth pairing steps, and troubleshooting...

Read full answer