

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Westinghouse](#) /
- › [Westinghouse Casanova Supreme Indoor Ceiling Fan User Manual](#)

Westinghouse 7231200

Westinghouse Casanova Supreme Indoor Ceiling Fan User Manual

Model: 7231200

PRODUCT OVERVIEW

The Westinghouse Casanova Supreme indoor flush mount ceiling fan offers traditional style and year-round comfort. This 42-inch fan features a versatile white finish and reversible blades, providing options for white or white washed pine aesthetics. It includes an opal schoolhouse light kit with an energy-efficient LED bulb, making it suitable for small to medium-sized rooms with low ceilings.



Image: The Westinghouse Casanova Supreme 42-inch ceiling fan in white, featuring four blades and an opal schoolhouse light fixture.

SAFETY INFORMATION

Always follow basic safety precautions when installing and operating electrical appliances. Ensure power is disconnected at the circuit breaker before installation or maintenance. Consult a qualified electrician if you are unsure about any part of the installation process. This fan is designed for indoor use only and is not water resistant.

- Read all instructions carefully before beginning installation.
- Ensure the installation site can support the fan's weight (approximately 11 pounds).
- Do not connect the fan to a dimmer switch unless specifically designed for ceiling fans.
- Keep hands and objects clear of the fan blades during operation.

INCLUDED COMPONENTS

The package for your Westinghouse Casanova Supreme Ceiling Fan includes the following items:

- Ceiling Fan Unit
- Mounting Hardware
- Instruction Manual (this document)
- One medium base 5.5 watt omni A15 LED bulb for the light kit.

SETUP AND INSTALLATION

Installation of the Westinghouse Casanova Supreme ceiling fan requires assembly. It is designed for flush mount installation. For detailed step-by-step instructions, please refer to the dedicated Installation Manual provided with your product or available online.

1. **Prepare the Installation Site:** Ensure the electrical box is securely mounted and capable of supporting the fan's weight. Turn off power at the main circuit breaker.
2. **Mount the Bracket:** Attach the mounting bracket to the electrical box.
3. **Wire the Fan:** Connect the fan's electrical wires to the household wiring according to local electrical codes.
4. **Assemble the Fan Body:** Secure the fan motor assembly to the mounting bracket.
5. **Attach Blades:** The fan comes with reversible blades (white and white washed pine). Choose your desired finish and attach the blades to the motor housing.
6. **Install Light Kit:** Connect and secure the opal schoolhouse glass light kit, then install the provided LED bulb.



Image: The Westinghouse Casanova Supreme ceiling fan showcasing its reversible blades with the white washed pine finish visible.

For a comprehensive guide, please refer to the [Installation Manual \(PDF\)](#).

OPERATING INSTRUCTIONS

The Westinghouse Casanova Supreme ceiling fan is operated via pull chains for both fan speed and light control.

Fan Operation

- **Fan Speed Control:** Locate the pull chain for the fan. Each pull will cycle through the fan speeds (High, Medium, Low, Off).
- **Reverse Function:** This fan features a reverse switch for summer/winter operation. Locate the small switch on the motor housing.
 - **Summer Mode (Counter-clockwise):** Blades rotate counter-clockwise, creating a downdraft that produces a cooling breeze.
 - **Winter Mode (Clockwise):** Blades rotate clockwise, creating an updraft that circulates warm air near the ceiling.

Note: Ensure the fan is completely stopped before changing the direction of rotation.

Light Operation

- **Light Control:** Locate the pull chain for the light. Each pull will cycle through light settings (On, Off).



Image: A close-up view of the Westinghouse ceiling fan's motor housing, showing the brand logo and the area where the reverse switch is typically located.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents as they may damage the finish.
- **Blade Cleaning:** Dust the fan blades regularly to prevent dust buildup, which can affect balance and airflow.
- **Tighten Screws:** Periodically check and tighten all screws on the fan and mounting hardware to ensure secure

operation.

- **Light Bulb Replacement:** When replacing the LED bulb, ensure the power is off. Use an E26 medium base A15 LED bulb, 5.5 watts, 120 volts, 600 lumens, 2700 Kelvin.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not start	No power to the fan. Loose wire connections. Motor issue.	Check circuit breaker and wall switch. Verify all wire connections are secure (ensure power is off first). Contact customer support if motor is defective.
Fan wobbles	Loose blade screws. Unbalanced blades. Loose mounting bracket.	Tighten all blade screws. Ensure blades are installed correctly and are not warped. Check and tighten mounting bracket screws.
Light does not work	Bulb is loose or burned out. Loose wire connection in light kit.	Tighten or replace the bulb. Check light kit wiring (ensure power is off first).
Fan makes noise	Loose screws. Motor hum. Blades hitting an obstruction.	Check and tighten all screws. Some motor hum is normal; excessive noise may indicate an issue. Ensure nothing is obstructing the blades.

SPECIFICATIONS

Model Name	Casanova Supreme
Part Number	7231200
Brand	Westinghouse
Size	42 Inch
Color	White
Material	MDF (Blades), Glass (Shade)
Indoor/Outdoor Usage	Indoor
Installation Type	Flush Mount
Power Source	AC
Control Method	Pull Chain (Fan & Light)
Light Source Type	LED
Bulb Base	E26 Medium
Wattage	5.5 watts

Voltage	120 Volts
Brightness	600 Lumens
Color Temperature	2700 Kelvin (Cool White)
Airflow	2812 CFM (on High Speed)
Airflow Efficiency	60 CFM/W
Item Weight	11 Pounds
UPC	024034723124

WARRANTY INFORMATION

Westinghouse provides a comprehensive warranty for the Casanova Supreme Ceiling Fan:

- **Motor:** Limited Lifetime Warranty
- **All Other Parts:** Two-Year Warranty

This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For full warranty terms and conditions, refer to the documentation included with your product or visit the official Westinghouse website.

SUPPORT AND CONTACT

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Westinghouse customer support.

- **Online Resources:** Additional manuals and FAQs may be available on the [Westinghouse Store on Amazon](#) or the official Westinghouse Lighting website.
- **Documents:**
 - [Instructions for Use \(PDF\)](#)
 - [Installation Manual \(PDF\)](#)

Please note that contact information such as phone numbers or direct email addresses are not provided in this manual. Refer to the official brand website for the most current support details.

