Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Anker A2724

Anker PowerDrive III Duo 40W 2-Port USB-C Car Charger

Instruction Manual - Model A2724

1. Introduction

This manual provides essential information for the safe and efficient use of your Anker PowerDrive III Duo 40W 2-Port USB-C Car Charger. This device is designed to provide high-speed charging for compatible USB-C devices in your vehicle. Please read these instructions thoroughly before use and retain them for future reference.



Image 1.1: Anker PowerDrive III Duo 40W 2-Port USB-C Car Charger. This image shows the compact, black car charger with two USB-C ports and a blue LED indicator.

2. Package Contents

Verify that all items are present in your package:

- Anker PowerDrive III Duo Car Charger

- Welcome Guide

3. Product Features

- **Universal High-Speed Charging:** Equipped with PowerIQ 3.0 technology, this charger delivers rapid charging for a wide range of USB-C compatible phones, tablets, and other devices.
- **Dual Port Output:** Features two USB-C ports, each capable of delivering up to 20W, allowing for simultaneous charging of two devices.
- **Advanced Safety Features:** Anker's MultiProtect technology integrates multiple safety systems, including fireproof construction, overload protection, and temperature control, to ensure safe charging.
- **Compact Design:** The ultra-compact build ensures the charger fits seamlessly into your vehicle's accessory socket, providing easy access to other dashboard functionalities.
- **Wide Device Compatibility:** Supports various USB-C devices, enhancing the charging experience across different gadgets.



Image 3.1: Diagram illustrating the MultiProtect Safety System. This image highlights the internal components responsible for overload protection, temperature control, and fireproof construction within the charger.



Image 3.2: Chart displaying universal compatibility with various devices. This image shows examples of devices compatible with the charger, including iPhones (14/13/12 series with USB-C to Lightning, 15 series with USB-C to USB-C), AirPods, Apple Watch, iPads, and Samsung Galaxy phones (S23/S22/S21 series, A73/A23/A13).

4. Setup

1. **Locate Vehicle Accessory Socket:** Identify the 12V accessory power socket (often labeled as a cigarette lighter socket) in your vehicle.

2. **Insert Charger:** Firmly insert the Anker PowerDrive III Duo car charger into the vehicle's 12V accessory socket. Ensure it is securely seated.
3. **Verify Power:** The blue LED indicator on the charger will illuminate when it is properly connected and receiving power.



Image 4.1: The compact design of the car charger fitting perfectly into a vehicle's console. This image demonstrates how the charger sits flush, allowing access to other car features.

5. Operating Instructions

1. **Connect Devices:** Use appropriate USB-C charging cables (not included) to connect your devices to the USB-C ports on the car charger.
2. **Initiate Charging:** Once connected, your devices will begin charging automatically. The charger's PowerIQ 3.0 technology will optimize the charging speed for each connected device.
3. **Monitor Charging:** The blue LED indicator on the charger confirms that power is being supplied. Your device's screen will typically show a charging icon or battery percentage increase.



Image 5.1: Two mobile devices being charged simultaneously at high speed within a vehicle. One phone is mounted on the dashboard, and another is placed in the center console, both connected to the Anker car charger.




Image 5.2: An iPhone connected to the Anker car charger, illustrating its fast charging capability. The image shows the phone's screen indicating a high charge level and the charger connected via a USB-C cable.



Image 5.3: Close-up of the car charger showing the illuminated blue LED power status indicator. This light confirms the charger is active and ready to charge devices.

6. Maintenance

- **Cleaning:** Disconnect the charger from the power source before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.

- **Storage:** Store the charger in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Handling:** Avoid dropping or subjecting the charger to strong impacts, as this may damage internal components.

7. Troubleshooting

- **Charger Not Working / No LED Light:**
  - Ensure the charger is fully inserted into the vehicle's 12V accessory socket.
  - Check if the vehicle's accessory socket is receiving power (e.g., by testing with another device).
  - Verify that the vehicle's ignition is on, if required for the accessory socket to function.
- **Device Not Charging / Charging Slowly:**
  - Confirm that your charging cable is not damaged and is properly connected to both the charger and your device.
  - Ensure your device supports USB-C charging and Power Delivery (PD) for optimal speed.
  - Try using a different USB-C cable to rule out cable issues.
  - If charging two devices, note that the total 40W output is shared, meaning each port delivers up to 20W.

8. Specifications

Feature	Detail
Model Number	A2724
Input Voltage	12 Volts
Total USB Ports	2 (USB Type C)
Total Output	40W (20W per port)
Connectivity Technology	USB
Special Features	Fast Charging, Fireproof Construction, Overload Protection, Temperature Control
Product Dimensions	2.7 x 1.41 x 1.41 inches
Item Weight	1.12 ounces
Color	Black

9. Warranty and Customer Support

Anker provides an 18-month warranty for this product, ensuring peace of mind regarding its quality and performance. For any inquiries, technical assistance, or warranty claims, please contact Anker customer service. Details for contacting support can typically be found in the included Welcome Guide or on the official Anker website.

For further assistance, please visit the official Anker support page:www.anker.com/support

© 2025 Anker Innovations Limited. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0843SCLYH

More documents and user manuals: **https://manuals.plus/**