

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [FurReal](#) /

› [FurReal FRR PEEALOTS Big Wags Dog Instruction Manual - Model E8948](#)

FurReal E8948

FurReal FRR PEEALOTS Big Wags Dog Instruction Manual

Brand: FurReal | **Model:** E8948

INTRODUCTION

Welcome to the world of FurReal pets! This manual provides essential information for the setup, operation, and care of your FurReal FRR PEEALOTS Big Wags Dog, Model E8948. This interactive plush pet is designed to provide engaging play and companionship. Please read all instructions carefully before use to ensure a safe and enjoyable experience.

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

WHAT'S IN THE BOX

Your FurReal FRR PEEALOTS Big Wags Dog package should contain the following items:

- 1 x FurReal FRR PEEALOTS Big Wags Dog Plush Pet
- 1 x Detachable Leash (multi-part assembly)
- 1 x Feeding Bottle
- 9 x Play Treats (small, brown kibble-like pieces)



Image: The FurReal FRR PEEALOTS Big Wags Dog, leash, and feeding bottle as they appear in the product packaging.

SETUP

1. Battery Installation

The FurReal FRR PEEALOTS Big Wags Dog requires 3 x AAA batteries (not included) for its interactive features. To install:

1. Locate the battery compartment on the underside of the pet.
2. Using a Phillips head screwdriver, open the battery compartment cover.
3. Insert 3 new AAA batteries, ensuring correct polarity (+/-).
4. Replace the cover and tighten the screw.

2. Assembling and Attaching the Leash

The detachable leash comes in multiple segments for adjustable length. To assemble and attach:

1. Connect the leash segments by pushing them firmly together until they click. You can use fewer segments for a shorter leash.
2. Attach the leash handle to the top of the leash pole.

3. Locate the attachment point on the pet's collar.
4. Securely clip the end of the leash to the pet's collar attachment point.

3. Filling the Feeding Bottle

The feeding bottle allows your pet to 'pee'.

1. Unscrew the cap of the feeding bottle.
2. Fill the bottle with clean tap water.
3. Securely screw the cap back on.



Image: A child feeding the FurReal Big Wags Dog with the included bottle.

OPERATING INSTRUCTIONS

1. Walking Your Pet

To make your FurReal Big Wags Dog walk:

- Ensure the leash is securely attached.
- Gently push the leash forward to make the pet roll along the floor. The pet's legs are designed

to move as it rolls.

- The pet may make happy sounds as it walks.



Image: A child demonstrating how to walk the FurReal Big Wags Dog using its leash.

2. Feeding Your Pet

To feed your pet the play treats:

- Place one of the small play treats into the pet's mouth.
- The pet will 'eat' the treat, storing it internally.

3. Making Your Pet 'Pee'

To make your pet 'pee' (release water):

- Ensure the feeding bottle is filled with water.
- Place the nozzle of the feeding bottle into the pet's mouth and gently squeeze to fill its internal reservoir.
- While walking the pet, lift its tail. This action will cause the pet to release water from its rear, simulating 'peeing'.
- Always use the pet on a surface that can get wet or use a small mat underneath.



Image: The FurReal Big Wags Dog demonstrating its 'peeing' feature when its tail is lifted.

4. Making Your Pet 'Poop'

To make your pet 'poop' (release play treats):

- After feeding your pet the play treats, continue to walk it.
- As the pet walks, it will gradually release the play treats from its rear, simulating 'pooping'.
- Collect the treats to reuse them.

MAINTENANCE

Cleaning Instructions

To keep your FurReal Big Wags Dog clean:

- **Surface Clean Only:** Do not immerse the pet in water. This can damage the electronic components.
- Use a soft, damp cloth to wipe away any dirt or spills.
- For stubborn spots, use a mild soap solution on the cloth, then wipe with a clean, damp cloth.

- Allow the pet to air dry completely before further play.
- Empty any remaining water from the internal reservoir and feeding bottle after each play session to prevent mildew.

Battery Replacement

When the pet's sounds become faint or it stops moving, it's time to replace the batteries. Follow the battery installation steps in the Setup section.

TROUBLESHOOTING

- **Pet is not moving or making sounds:**
 - Check if the batteries are correctly installed and not depleted. Replace with fresh AAA batteries if necessary.
 - Ensure the pet's power switch (if present, usually on the underside) is in the 'ON' position.
- **Pet is not 'peeing':**
 - Verify that the feeding bottle is filled with water and the pet's internal reservoir has been filled.
 - Ensure the pet's tail is lifted during the walking motion to activate the 'peeing' function.
- **Leash detaches easily:**
 - Ensure all leash segments are firmly clicked into place.
 - Check that the leash clip is securely fastened to the pet's collar attachment point.

SPECIFICATIONS

Product Dimensions	5.25 x 9 x 9 inches
Item Weight	14.1 ounces
Model Number	E8948
Recommended Age	4 years and up
Manufacturer	Hasbro

IMPORTANT SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

- Always supervise young children during play.

- Keep play treats and small parts away from children under 3 years of age to prevent choking.
- Do not use any liquids other than clean tap water in the feeding bottle.
- Ensure battery compartment is securely closed to prevent access to batteries.

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included with your purchase or visit the official Hasbro website. You may also contact Hasbro customer service directly for assistance with your FurReal FRR PEEALOTS Big Wags Dog.

© 2026 FurReal. All rights reserved. FurReal and all related properties are trademarks of Hasbro.