

KEMEI KM-5015

Kemei KM-5015 Professional Hair Clipper User Manual

Model: KM-5015 | Brand: KEMEI

1. INTRODUCTION

This manual provides essential instructions for the safe and effective operation, maintenance, and care of your Kemei KM-5015 Professional Hair Clipper. Please read this manual thoroughly before first use and retain it for future reference.

Product Overview

The Kemei KM-5015 is a professional hair clipper designed for precise and consistent hair cutting. It features durable stainless steel blades, an ergonomic design for comfortable handling, and a powerful motor. The clipper is equipped with a rechargeable battery and can be used cordlessly or while connected to the power adapter. It is suitable for various hair cutting styles and can also be used for beard trimming.





Image 1.1: Front view of the Kemei KM-5015 Professional Hair Clipper, highlighting its washable design.

What's Included

The Kemei KM-5015 Professional Hair Clipper package typically includes:

- Kemei KM-5015 Hair Clipper
- Charging Base / Power Adapter
- Four Guide Combs (3mm, 6mm, 9mm, 12mm)
- Cleaning Brush
- Lubricating Oil Bottle
- Scissors (may vary by package)
- Comb (may vary by package)



Image 1.2: Contents of the Kemei KM-5015 package, including the clipper, charging adapter, guide combs, oil, and cleaning brush.

2. SAFETY INFORMATION

To reduce the risk of electric shock, injury, or damage, always follow these basic safety precautions:

- Read all instructions before using this appliance.
- Keep the appliance dry. Do not use it near water or in wet conditions.
- Do not immerse the appliance in water while charging or if it is not explicitly stated as fully waterproof. While the clipper is washable, ensure the charging port is dry before connecting to power.

- Unplug the appliance from the power outlet immediately after charging and before cleaning.
- Do not use the appliance with a damaged cord or plug.
- Keep the cord away from heated surfaces.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Use this appliance only for its intended use as described in this manual.
- Never drop or insert any object into any opening.
- Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- Always check the blades for damage before use. Do not use if blades are damaged.

3. SETUP

Charging the Clipper

1. Ensure the clipper is switched off.
2. Connect the charging adapter to the charging port on the clipper or place the clipper onto the charging base.
3. Plug the adapter into a suitable electrical outlet (230Vac / 50Hz).
4. The charging indicator light will illuminate, indicating that the clipper is charging.
5. Allow approximately 10 hours for a full charge before initial use. Subsequent charges may take less time.
6. Once fully charged, disconnect the adapter from the power outlet and the clipper.





Image 3.1: Back view of the Kemei KM-5015 clipper, showing model number and charging specifications.

Attaching Guide Combs

The clipper comes with four guide combs (3mm, 6mm, 9mm, 12mm) to achieve different cutting lengths.

1. Ensure the clipper is switched off.
2. Select the desired guide comb.
3. Align the comb with the clipper blade and push it firmly until it clicks into place.
4. To remove, gently pull the comb away from the blade.



Image 3.2: Included guide combs (3mm, 6mm, 9mm, 12mm), lubricating oil, and cleaning brush.

4. OPERATING INSTRUCTIONS

Basic Operation

1. Ensure the clipper is fully charged or connected to the power adapter.
2. Attach the desired guide comb for your preferred cutting length. For very short cuts or detailing, the clipper can be used without a guide comb, offering a cutting length of 0.8mm to 2mm. With guide combs, the length can be adjusted up to 14mm.
3. Press the power switch button to turn the clipper ON.
4. Hold the clipper with the blades pointing downwards and move it against the direction of hair growth.
5. Use smooth, even strokes. Do not apply excessive pressure.
6. After use, press the power switch button to turn the clipper OFF.



Image 4.1: Illustration of the clipper's dimensions and the location of the power switch button.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure optimal performance and extend the life of your Kemei KM-5015 Hair Clipper.

Cleaning the Blades

The Kemei KM-5015 is designed to be washable, allowing for easy cleaning under running water.

1. Ensure the clipper is switched OFF and disconnected from the power adapter.
2. Remove any attached guide comb.
3. Use the provided cleaning brush to remove loose hairs from the blades and the clipper body.
4. For a more thorough clean, the blade head can be detached. Gently push the blade assembly forward to release it from the clipper body.
5. Rinse the blade head under running water. You may also rinse the main body of the clipper, ensuring the charging port is sealed or kept dry if not designed for full immersion.
6. Allow all parts to air dry completely before reattaching the blade head and storing.

Kemei®

PROFESSIONAL HAIR CLIPPER

Professional high quality advanced shaving system
Model: KM-5015



- 

Is simple, easy for a variety of styles, Use for any ages
- 

Adopted the design, low noise during operation, very slim, but the baby to sleep for a haircut.
- 

Clever structural design and technology can be trimmed 3, 6 and 9, 12 millimetres style.
- 

Titanium steel blade made in Germany, professional barheaded machine, not hurting scalp with hair residue of 0.2mm.

PK Ordinary hair clipper easily hurts scalp with unclean haircut and hair residue of 1 mm.
- 

The exclusive patent technology I-shaped cutting, not hurting skin and without residue.

PK Our hair clipper can clip neatly and evenly, but the ordinary one cannot.



WHOLE BODY WASHABLE
You can completely immerse the appliance in water for cleaning

Image 5.1: The Kemei KM-5015 clipper is designed for whole-body washing, simplifying cleaning.

Lubricating the Blades

To maintain optimal cutting performance and blade longevity, it is recommended to oil the blades regularly, especially after cleaning or every few uses.

1. Ensure the clipper is switched OFF.
2. Apply 1-2 drops of the provided lubricating oil (or a suitable clipper oil) evenly across the top of the blades.
3. Turn the clipper ON for a few seconds to allow the oil to distribute.
4. Wipe off any excess oil with a soft cloth.

6. TROUBLESHOOTING

If you encounter issues with your Kemei KM-5015 Hair Clipper, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is depleted.	Charge the clipper for at least 10 hours.
Clipper does not turn on.	Power adapter or outlet issue.	Ensure the adapter is securely plugged in and the outlet is functional. Try a different outlet.
Poor cutting performance or pulling hair.	Blades are dull or dirty.	Clean the blades thoroughly and apply lubricating oil. If blades are dull, consider replacement.
Poor cutting performance or pulling hair.	Hair buildup in the blade mechanism.	Remove the blade head and clean out any trapped hair.
Clipper makes unusual noise.	Blades require lubrication.	Apply lubricating oil to the blades.

If the problem persists after attempting these solutions, please contact customer support.

7. SPECIFICATIONS

- **Model:** KM-5015
- **Brand:** KEMEI
- **Power Source:** Electric & Battery (Rechargeable)
- **Input Voltage:** 230Vac / 50Hz
- **Charging Time:** Approximately 10 hours
- **Blade Material:** Stainless Steel
- **Cutting Length (without comb):** 0.8mm - 2mm
- **Cutting Length (with combs):** 3mm, 6mm, 9mm, 12mm (up to 14mm with adjustable settings)
- **Special Features:** Washable, Multigroomer
- **Item Weight:** 0.5 Kilograms
- **Dimensions:** Approximately 16 cm (Length)
- **Country of Origin:** China

8. WARRANTY AND SUPPORT

KEMEI products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your product or contact your retailer. Keep your purchase receipt as proof of purchase.

For technical support or service inquiries, please contact the authorized KEMEI service center or your point of purchase.