

[Manuals.plus](#) /

› [Fossil](#) /

› Fossil FS5693 Men's Minimalist Watch User Manual

Fossil FS5693

Fossil FS5693 Men's Minimalist Watch User Manual

Model: FS5693

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the Fossil FS5693 Men's Minimalist Watch. This timepiece features a 44mm case, a 3-hand quartz movement, a dark blue sunray dial, and a black stainless steel bracelet. Designed for durability and style, this watch is water-resistant up to 5 ATM. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your watch.





Figure 1: Front view of the Fossil FS5693 watch.

2. SETUP INSTRUCTIONS

2.1 Setting the Time

1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch case) to the outermost position. You might feel a slight click.
2. **Adjust the time:** Rotate the crown clockwise or counter-clockwise to move the hour and minute hands to the desired time.
3. **Push in the crown:** Once the correct time is set, push the crown back into its original position against the watch case. This will start the watch movement.



Figure 2: Side view of the watch, highlighting the crown for time adjustment.

2.2 Adjusting the Bracelet

The stainless steel bracelet features a deployant clasp with a double push-button safety. To adjust the length, it may be necessary to remove or add links. This procedure typically requires specialized tools and is best performed by a professional jeweler or watch repair service to avoid damage to the bracelet or clasp.



Figure 3: Back view of the watch, showing the bracelet and clasp mechanism.

3. OPERATING INSTRUCTIONS

3.1 Timekeeping

Your Fossil FS5693 watch is powered by a reliable quartz movement, ensuring accurate timekeeping. Once the time is set, the watch will continuously display the current time. No further daily adjustments are typically needed unless the battery runs low or the time zone changes.

3.2 Water Resistance

This watch has a water resistance rating of 5 ATM (50 meters). This means it is suitable for short periods of recreational swimming in shallow water. It is **not** suitable for diving, snorkeling, or high-impact water sports.

- Do not operate the crown or push-buttons while the watch is wet or submerged.
- Avoid exposing the watch to hot water, steam, or extreme temperature changes, as this can compromise the water seals.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.



Figure 4: The Fossil FS5693 watch worn on a wrist.

4. MAINTENANCE

4.1 Cleaning Your Watch

To maintain the appearance of your watch, regularly wipe the case and bracelet with a soft, dry cloth. For the stainless steel bracelet, a slightly damp cloth can be used, followed by a dry cloth. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the watch's finish.

4.2 Battery Replacement

The watch is powered by one lithium metal battery. When the watch stops running or the time becomes inconsistent, it is likely that the battery needs replacement. Battery replacement should be performed by a qualified watch technician to ensure the proper sealing and functionality of the watch, especially its water resistance.

4.3 Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. The original Fossil gift box can be used for safe storage.

5. TROUBLESHOOTING

- Watch not running:**

Ensure the crown is fully pushed in. If it is, the battery may need replacement. Consult a professional watch technician.
- Time is incorrect or inconsistent:**

Re-set the time as described in Section 2.1. If the issue persists, the battery may be low, or the movement might require servicing. Seek professional assistance.
- Condensation under the crystal:**

This indicates a breach in the watch's water resistance. Avoid further contact with water and have the watch inspected by a professional immediately to prevent internal damage.

6. SPECIFICATIONS

Feature	Detail
Model Number	FS5693
Case Size	44 mm
Case Thickness	8 mm
Band Width	22 mm
Band Circumference	200 +/- 5 mm
Movement Type	Quartz (3-hand)
Dial Color	Dark Blue Sunray
Case Material	Stainless Steel
Band Material	Stainless Steel
Clasp Type	Deployant Buckle (Double Push-Button Safety)
Water Resistance	5 ATM (50 meters)
Crystal Material	Mineral
Battery Type	1 Lithium Metal (included)
Item Weight	98 Grams
Dimensions (L x W x H)	7 x 9 x 9 cm

7. WARRANTY INFORMATION

Fossil watches are manufactured to the highest quality standards. Your Fossil FS5693 watch comes with a limited warranty covering manufacturing defects. Please refer to the warranty card included with your purchase or visit the official Fossil website for detailed warranty terms and conditions, including coverage period and service procedures. Keep your proof of purchase for warranty claims.

8. SUPPORT

For further assistance, service, or inquiries regarding your Fossil FS5693 watch, please contact Fossil customer support. You can find contact information and frequently asked questions on the official Fossil website.

Official Fossil Website: www.fossil.com

Fossil Brand Store on Amazon: [Visit the Fossil Store](#)

