

[manuals.plus](#) /› [Garmin](#) /› [Garmin Approach S62 Premium GPS Golf Watch User Manual](#)**Garmin S62**

# Garmin Approach S62 Premium GPS Golf Watch User Manual

Model: S62

## 1. INTRODUCTION

Welcome to your Garmin Approach S62 Premium GPS Golf Watch. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your device. Please read this manual thoroughly to ensure optimal performance and longevity of your watch.

## 2. WHAT'S IN THE Box

- Garmin Approach S62 Premium GPS Golf Watch
- Charging/Data Cable
- Documentation
- Wearable4U Power Bank (E-Bank)
- Wearable4U Wall Charger
- Wearable4U Car Charger



Image: Contents of the Wearable4U bundle, including the Garmin Approach S62 watch, power bank, wall charger, and car charger.

### 3. DEVICE OVERVIEW

The Garmin Approach S62 is a premium GPS golf watch designed to provide essential golf course information and smart features directly on your wrist. It features a large, easy-to-read color touchscreen display.



Large, 1.3" easy-to-read color touchscreen display  
that's 17% larger than Approach® S60.

Image: The Garmin Approach S62 watch displaying the time, steps count, and current date.



Image: The Garmin Approach S62 watch displaying detailed golf course information for a specific hole, including distances to the green.

## 4. SETUP

---

### 4.1. Charging the Device

Before first use, fully charge your Approach S62. Connect the charging clip to the watch and plug the USB cable into a power source. A full charge typically takes approximately 2 hours.

### 4.2. Powering On/Off

- **To Power On:** Press and hold the power button (usually the top right button) until the Garmin logo appears.
- **To Power Off:** Press and hold the power button until the power options menu appears, then select 'Power Off'.

### 4.3. Initial Setup and Pairing

Upon first power-on, the watch will guide you through initial setup steps, including language selection and personal data input. To unlock full smart features, pair your watch with the Garmin Golf app on your smartphone via Bluetooth. Follow the on-screen instructions on both the watch and the app.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Golf Features

The Approach S62 is preloaded with over 41,000 golf courses worldwide. Once you start a round, the watch automatically detects your location and displays course information.

#### 5.1.1. Virtual Caddie

The Virtual Caddie feature suggests a club based on your typical hitting distance for each club, considering wind speed and direction. It also indicates where to aim on the course map.



Virtual Caddie suggests club and aim based on typical distance as well as wind speed and direction.

Image: The Garmin Approach S62 watch showing the Virtual Caddie feature, suggesting a club and aim point for a shot.

### 5.1.2. Hazard View

Quickly scroll through each hazard on the map to view distances to the front and back of bunkers, water hazards, and other obstacles.



Hazard View allows you to quickly scroll through each hazard and layup target on the map.

Image: The Garmin Approach S62 watch displaying the Hazard View, showing distances to the front and back of a bunker.

#### **5.1.3. PlaysLike Distance**

This feature adjusts yardage measurements to account for uphill and downhill shots, providing a more accurate distance to the target.

#### **5.1.4. Green View**

The Green View feature allows you to manually position the pin for the day, providing precise distances to the front, middle, and back of the green, as well as to hazards and doglegs.



Image: The Garmin Approach S62 watch displaying the Green View, showing the green layout and allowing for manual pin positioning.

#### 5.1.5. Course Selection and Scoring

The watch automatically detects nearby courses. Select your course and begin your round. The watch can track your score, shots, and other statistics, which can be reviewed on the watch or in the Garmin Golf app.

## 5.2. Smart Features

### 5.2.1. Garmin Pay

Garmin Pay is a contactless payment solution that allows you to make convenient payments directly from your watch. Set up your cards in the Garmin Connect app.

### 5.2.2. Notifications

Receive smart notifications for calls, texts, and app alerts directly on your watch when paired with your smartphone.

## 5.3. Customizing Your Watch

You can customize watch faces, widgets, and settings through the watch menu or the Garmin Connect app to suit your preferences.

## 6. MAINTENANCE

---

### 6.1. Cleaning the Device

Regularly clean your watch with a soft, damp cloth. Avoid harsh chemicals or abrasive materials. Ensure the charging contacts are clean and dry before charging.

### 6.2. Battery Care

To maximize battery life, avoid exposing the watch to extreme temperatures. Charge the device regularly, but avoid leaving it fully discharged for extended periods. The battery life is approximately 20 hours in GPS mode.

### 6.3. Software Updates

Keep your watch's software updated to ensure optimal performance and access to the latest features. Updates can be performed via the Garmin Connect app or Garmin Express on a computer.

## 7. TROUBLESHOOTING

---

### 7.1. Common Issues

- **Watch not powering on:** Ensure the watch is fully charged. Try connecting it to a power source.
- **GPS not acquiring signal:** Ensure you are in an open area with a clear view of the sky. Allow several minutes for the watch to acquire satellites.
- **Bluetooth connectivity issues:** Ensure Bluetooth is enabled on both your watch and smartphone. Try restarting both devices and re-pairing them through the Garmin Connect app.
- **Inaccurate distances:** Ensure the course map is up-to-date. Perform a software update if available.
- **Touchscreen unresponsive:** Try restarting the device. If the issue persists, contact Garmin support.

## 8. SPECIFICATIONS

---

Feature	Detail
Item Weight	1.25 pounds
Product Dimensions	1.85 x 0.58 x 1.85 inches

Item Model Number	wa001
Batteries	2 Lithium Ion batteries required
Display Size	3 Inches
Battery Life (GPS Mode)	20 Hours
Voice Command	Touchscreen
Connectivity Technology	Bluetooth Smart and ANT+
Map Type	North America
Mounting Type	Wrist Mount
Display Type	Sunlight-visible, transflective memory-in-pixel (MIP)

## 9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your product or visit the official Garmin website. For technical support, product registration, and additional resources, please visit [garmin.com/support](http://garmin.com/support).

## 10. OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: Official product video demonstrating key features and benefits of the Garmin Approach S62 Premium GPS Golf Watch.

© 2024 Garmin Ltd. or its subsidiaries. All rights reserved.