

MEDION MD 19407

MEDION MD 19407 Cyclonic Vacuum Cleaner User Manual

Model: MD 19407 | Brand: MEDION

Introduction	Safety Instructions Maintenance	Package Contents Troubleshooting	Product Overview Specifications	Setup Support	Operation
--------------	---------------------------------------	--	---------------------------------------	------------------	-----------

1. INTRODUCTION

Thank you for choosing the MEDION MD 19407 Cyclonic Vacuum Cleaner. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before first use and keep them for future reference.

The MEDION MD 19407 is a powerful and compact bagless cyclonic vacuum cleaner designed for thorough cleaning. Its 800 Watt motor and advanced cyclonic technology ensure consistent suction power, while the EPA12 filter helps to retain fine dust, making it suitable for allergy sufferers.

2. SAFETY INSTRUCTIONS

Always observe the following safety precautions to reduce the risk of fire, electric shock, or injury.

- Ensure the power supply voltage matches the rating label on the appliance.
- Do not use the vacuum cleaner on wet surfaces or to pick up liquids.
- Do not pick up flammable or combustible materials, hot ashes, or sharp objects.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Unplug the appliance from the power outlet before cleaning or performing maintenance.
- Do not operate the vacuum cleaner with a damaged cord or plug.
- This appliance is for household use only.
- Children should be supervised to ensure they do not play with the appliance.
- Always ensure the dust container and filters are correctly installed before use.

3. PACKAGE CONTENTS

Carefully unpack all items and check against the list below. If any items are missing or damaged, contact customer

support.



Image: The MEDION MD 19407 Cyclonic Vacuum Cleaner with its included accessories, including the main unit, flexible hose, telescopic tube, floor nozzle, and crevice/brush tool.

- MEDION MD 19407 Bagless Cyclonic Vacuum Cleaner Unit
- Flexible Suction Hose
- Telescopic Suction Tube (Metal)
- Universal Floor Nozzle
- Crevice/Brush Attachment (2-in-1 tool)
- User Manual (this document)

4. PRODUCT OVERVIEW

Familiarize yourself with the main components of your MEDION MD 19407 vacuum cleaner.



Image: Side view of the MEDION MD 19407 vacuum cleaner illustrating its compact dimensions: 31 cm length, 25 cm width, and 35 cm height.

Key Features:

- **Bagless Cyclonic Technology:** Provides consistent and powerful suction without the need for disposable dust bags.
- **800 Watt Motor:** Ensures strong cleaning performance.
- **2 Liter Dust Reservoir:** Large capacity dust container reduces the frequency of emptying.
- **EPA12 Filter:** Captures up to 99.5% of fine dust particles, beneficial for allergy sufferers.
- **Compact and Lightweight Design:** Easy to maneuver and transport, ideal for stairs.
- **Telescopic Suction Tube:** Adjustable length for comfortable cleaning and reaching difficult areas.
- **5-meter Power Cable:** Provides a wide working range.
- **Automatic Cable Rewind:** For convenient storage of the power cable.

Ultrakrachtig 18 kPA zuigvermogen

Innovatieve cycloontechnologie voor constante zuigkracht



Image: Illustration of the vacuum cleaner's powerful 18 kPa suction, demonstrating the airflow and cyclonic technology for constant suction power.

Perfect voor mensen met een allergie

EPA12-filter houdt tot 99,5% van het stof tegen



Image: A child and a dog sleeping peacefully, with an inset showing the EPA12 filter, highlighting its effectiveness in trapping up to 99.5% of dust for allergy relief.

Extra groot stofreservoir van 2 l

Voortdurend leegmaken niet meer nodig



Image: Close-up of the vacuum cleaner's dust container, clearly showing "2L" indicating its extra-large 2-liter capacity, reducing the need for frequent emptying.

5. SETUP AND ASSEMBLY

Follow these steps to assemble your vacuum cleaner before first use.

1. **Attach the Flexible Hose:** Insert the larger end of the flexible hose into the suction inlet on the main unit until it clicks securely into place.
2. **Assemble the Telescopic Tube:** Connect the smaller end of the flexible hose to the telescopic suction tube. Extend the telescopic tube to your desired length by pressing the release button and pulling.
3. **Attach the Floor Nozzle:** Connect the universal floor nozzle to the end of the telescopic tube. Ensure it is firmly attached.
4. **Attach Accessories:** For specific cleaning tasks, attach the crevice/brush attachment directly to the end of the flexible hose or the telescopic tube.
5. **Power Connection:** Extend the power cable from the main unit and plug it into a suitable electrical outlet.

Extra lange & uitschuifbare metalen telescoopbuis

Voor bijzonder moeilijk bereikbare plaatsen



Image: Close-up of the extendable metal telescopic tube, shown in a living room setting, emphasizing its utility for reaching difficult areas.

6. OPERATING INSTRUCTIONS

6.1 Starting the Vacuum Cleaner

1. Ensure the vacuum cleaner is properly assembled and plugged into a power outlet.
2. Press the power button (usually located on the main unit) to turn on the appliance.
3. Begin vacuuming. The universal floor nozzle is suitable for various floor types.

6.2 Using Attachments

The MEDION MD 19407 comes with versatile attachments for different cleaning needs.

- **Universal Floor Nozzle:** For general cleaning of hard floors and carpets.
- **Crevice/Brush Attachment:**
 - Use the *crevice tool* for narrow gaps, corners, and edges (e.g., between sofa cushions, along skirting boards).

- Slide the *brush attachment* over the crevice tool for dusting delicate surfaces, upholstery, or car interiors.

Verschillende toepassingsgebieden

3 mondstukken voor verschillende soorten vuil



Image: A collage showing different cleaning scenarios: sofa cushions, a keyboard, car interior, and a high shelf, demonstrating the versatility of the vacuum's attachments for various surfaces and hard-to-reach areas.

6.3 Stopping the Vacuum Cleaner

1. Press the power button to turn off the appliance.
2. Unplug the power cable from the wall outlet.
3. Press the cable rewind button (if available) to retract the power cable.

Extra lange kabel

Maakt eenvoudige reiniging mogelijk overal in huis



Image: The MEDION MD 19407 vacuum cleaner with its 5-meter long power cable extended, illustrating the extensive reach it provides for cleaning throughout the home.

7. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner. Always unplug the appliance before cleaning.

7.1 Emptying the Dust Reservoir

Empty the dust reservoir when the MAX fill line is reached or when suction power decreases.

1. Press the release button to detach the dust reservoir from the main unit.
2. Hold the reservoir over a waste bin and open the bottom flap to empty the contents.
3. Close the flap securely and reattach the dust reservoir to the vacuum cleaner.

Geen stofzak nodig

Eenvoudig en hygiënisch leegmaken



Image: Close-up of the vacuum cleaner's dust container, with an inset showing a discarded dust bag with collected debris crossed out, illustrating that no dust bags are needed for this model, promoting easy and hygienic emptying.

7.2 Cleaning the EPA12 Filter

The EPA12 filter is washable. Clean it regularly to maintain optimal filtration and suction.

1. Remove the dust reservoir as described above.
2. Locate and carefully remove the EPA12 filter from the reservoir.
3. Rinse the filter under cold running water until the water runs clear. Do not use detergents.
4. Allow the filter to air dry completely for at least 24 hours before reinserting it. Do not use a hairdryer or other heating devices.
5. Once dry, reinsert the filter into the dust reservoir and reattach the reservoir to the vacuum cleaner.

7.3 Cleaning Other Parts

- Wipe the exterior of the vacuum cleaner with a soft, damp cloth. Do not use abrasive cleaners.

- Check the floor nozzle and other attachments for blockages or tangled hair and remove them.

8. TROUBLESHOOTING

If you encounter problems with your vacuum cleaner, refer to the table below for common issues and solutions.

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	Not plugged in; no power at outlet; power button not pressed.	Check power cord connection; test outlet with another appliance; press power button firmly.
Low suction power.	Dust reservoir full; filter clogged; hose/nozzle blocked.	Empty dust reservoir; clean/wash EPA12 filter; check hose and nozzles for blockages and remove them.
Unusual noise during operation.	Blockage in hose/nozzle; foreign object in fan; motor issue.	Turn off and unplug. Check for and remove blockages. If noise persists, contact support.
Dust escaping from the vacuum.	Dust reservoir not properly closed; filter not installed correctly or damaged.	Ensure dust reservoir is securely closed; check filter installation; replace damaged filter.

If the problem persists after trying these solutions, please contact MEDION customer support.

9. TECHNICAL SPECIFICATIONS

Feature	Detail
Brand	MEDION
Model Number	MD 19407
Color	Black
Product Dimensions	31 x 35 x 25 cm
Item Weight	4.5 kg
Dust Reservoir Capacity	2 Liters
Power/Wattage	800 Watts
Voltage	800 Volt (Note: This value is as provided in source data and may refer to internal component rating rather than operating voltage.)
Annual Energy Consumption	800 Watt-hour (Note: This value is as provided in source data and is unusually low for annual consumption.)
Noise Level	50 dB
Runtime	5 minutes (Note: This value is as provided in source data and is unusual for a corded vacuum cleaner.)
Special Features	Cable rewind mechanism, Telescopic handle
Filter Type	EPA12
Power Source	Electric with cord

Feature	Detail
Cordless	No

10. WARRANTY AND CUSTOMER SUPPORT

MEDION is committed to providing high-quality products and excellent customer service.

Customer Support:

Should you have any questions, require assistance, or experience issues with your MEDION MD 19407 Cyclonic Vacuum Cleaner, our competent customer advisory team is available 365 days a year. Please refer to the official MEDION website or your purchase documentation for contact details.

Repair Service:

If a problem cannot be resolved through direct communication with customer support, MEDION's repair service will handle it quickly and efficiently. Information regarding warranty terms and repair procedures can be found on the official MEDION website or by contacting customer support.

© 2025 MEDION. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0845WZZX7>

More documents and user manuals: <https://manuals.plus/>