



Manuals.plus /

› BaBylissPRO /

› BaBylissPRO VIBEFX 2-Speed Cord/Cordless Massager User Manual

## BaBylissPRO FXSSM1

# BaBylissPRO VIBEFX 2-Speed Cord/Cordless Massager User Manual

Model: FXSSM1

## INTRODUCTION

---

The BaBylissPRO VIBEFX 2-Speed Cord/Cordless Massager (Model FXSSM1) is a professional-grade device designed to provide a precise and relaxing massage experience. This manual provides essential information for the safe and effective use, maintenance, and care of your massager.

## IMPORTANT SAFETY INSTRUCTIONS

---

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- Always unplug the appliance immediately after use and before cleaning.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- This appliance should never be left unattended when plugged in.
- Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water.
- Keep the cord away from heated surfaces.
- Never use while sleeping.
- Never drop or insert any object into any opening.

- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use on or near eyes or other highly sensitive areas.
- Do not operate under a blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
- Do not carry this appliance by supply cord or use cord as a handle.
- To disconnect, turn all controls to the OFF position, then remove plug from outlet.
- This appliance is for household use only.

## PRODUCT OVERVIEW

---

The BaBylissPRO VIBEFX Massager features a durable stainless steel housing and a long-life brushless motor. It is designed for comfortable handheld use, combining the precision of a hand massage with relaxing pulses.



Figure 1: Angled view of the BaBylissPRO VIBEFX Massager, showcasing its sleek silver and black design with the BaBylissPRO logo.

## Components:

- **Stainless Steel Housing:** Provides durability and a professional aesthetic.
- **Brushless Motor:** Offers enhanced efficiency and longevity.
- **Dual Offset Weights:** Contribute to the unique massage sensation.
- **2-Speed Control:** Allows selection between two intensity levels.
- **Lithium-Ion Battery:** Enables cordless operation.
- **Charging Port:** For recharging the internal battery.





Figure 2: Front view of the massager, highlighting the ergonomic shape and BaBylissPRO branding.



Figure 3: Back view of the massager, showing the power switch and charging port area.

## SETUP

---

### Initial Charging:

1. Before first use, fully charge the massager. Connect the charging cable to the massager's charging port and plug the adapter into a suitable electrical outlet.

2. Allow the unit to charge for the recommended duration (typically indicated by an LED indicator changing color or turning off when fully charged).
3. The massager can be used corded or cordless once charged.



Figure 4: The "World Wide Usage Dual Voltage" logo, indicating the massager's compatibility with various international power standards.

## OPERATING INSTRUCTIONS

---

### Using the Massager:

1. Ensure the massager is adequately charged or connected to a power source.
2. Hold the massager comfortably in your hand. The ergonomic design allows for a natural grip.
3. Locate the power/speed switch, typically on the back or side of the unit.
4. Slide the switch to the desired speed setting (Low or High). The massager will begin to vibrate.
5. Gently apply the vibrating surface of the massager to the area you wish to massage. Common areas include the neck, back, head, and face.
6. Move the massager slowly and steadily over the skin or clothing. Avoid applying excessive pressure.

7. After use, slide the power/speed switch to the OFF position.

**Note:** For optimal results and to prevent discomfort, do not use the massager on bony areas or directly on joints. Consult a healthcare professional if you have any medical conditions or concerns.



Figure 5: Example of a BaBylissPRO grooming tool being used for neck detailing, illustrating the professional application context for similar handheld devices.

## MAINTENANCE

---

### Cleaning:

- Always ensure the massager is turned off and unplugged before cleaning.
- Wipe the exterior of the massager with a soft, damp cloth.
- Do not use abrasive cleaners or immerse the unit in water.
- Ensure the massager is completely dry before storing or recharging.

### Storage:

- Store the massager in a cool, dry place, away from direct sunlight and moisture.
- Keep out of reach of children.
- Do not wrap the power cord around the appliance, as this can damage the cord.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Massager does not turn on.	Battery is depleted. Power switch is off.	Charge the massager fully. Ensure the power switch is in the ON position.
Weak vibration.	Low battery charge. Incorrect speed setting.	Recharge the massager. Select the higher speed setting.
Unit gets warm during use.	Normal operation. Prolonged use.	This is normal. If it becomes excessively hot, turn off and allow to cool. Avoid continuous use for extended periods.

If you experience issues not listed here, or if the problem persists, please contact customer support.

## SPECIFICATIONS

---

- **Model Number:** FXSSM1
- **Power Source:** Battery Powered (1 Lithium Ion battery included)
- **Material:** Stainless Steel
- **Item Weight:** 1.09 Pounds (approx. 0.49 kg)
- **Product Dimensions:** 6.5 x 3.5 x 3.75 inches (approx. 16.5 x 8.9 x 9.5 cm)
- **UPC:** 074108364678
- **Brand:** BaBylissPRO
- **Manufacturer:** BaBylissPRO

## WARRANTY AND SUPPORT

---

BaBylissPRO products are manufactured to the highest standards and undergo rigorous quality control. For information regarding warranty coverage, service, or technical support, please refer to the warranty card included with your product or visit the official BaBylissPRO website.

**Online Support:** [www.babylisspro.com](http://www.babylisspro.com)

