

[manuals.plus](#) /› [Disney](#) /› [Disney Frozen 2 Olaf Interactive Figure User Manual](#)**Disney 75023**

Disney Frozen 2 Olaf Interactive Figure User Manual

Model: 75023

INTRODUCTION

Welcome to the world of Disney's Frozen 2 with your new Olaf Interactive Figure. This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your interactive toy. Designed to bring the magic of Arendelle to life, Olaf interacts with you and other compatible Frozen 2 Interactive Adventure figures (sold separately), offering a unique and engaging play experience.

IMPORTANT SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years.

- Always supervise children during play.
- Do not attempt to disassemble or modify the figure.
- Keep batteries away from small children. If swallowed, seek immediate medical attention.
- Dispose of batteries properly according to local regulations.

WHAT'S IN THE BOX

- 1 x Disney Frozen 2 Olaf Interactive Figure
- 2 x AAA Batteries (pre-installed or included)

SETUP

Battery Installation

Your Olaf Interactive Figure requires 2 AAA batteries. These may be pre-installed. If not, or if replacement is needed:

1. Locate the battery compartment on the back or bottom of the figure.
2. Using a small Phillips head screwdriver, unscrew the battery compartment cover.
3. Insert 2 new AAA batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Replace the cover and secure it with the screw.



Image: The Disney Frozen 2 Olaf Interactive Figure. Olaf is a white snowman with stick arms, three black buttons, and a carrot nose. He has a wide, happy smile showing his two front teeth, and expressive eyes.

Powering On/Off

Locate the ON/OFF switch, usually on the back or bottom of the figure. Slide the switch to the 'ON' position to activate Olaf. Slide to 'OFF' when not in use to conserve battery life.

OPERATING INSTRUCTIONS

Interacting with Olaf

Olaf is designed to respond to various actions and interact with other figures:

- **Activate Phrases:** Gently press Olaf's stomach or raise one of his arms to hear him speak various phrases from Frozen 2. His eyes and mouth will move, and his head will turn as he talks.
- **Singing:** Raise Olaf's other arm to hear him sing his song, "When I'm Older."
- **Interactive Play with Other Figures:** For the full interactive experience, place Olaf near other Disney Frozen 2 Interactive Adventure figures (Anna and Elsa, sold separately). The figures will recognize each other using IR technology and engage in conversations, play charades, and even sing "Some Things Never Change" together. Ensure figures are facing each other for optimal interaction.

If Olaf falls over, he may utter different phrases and will continue talking until he is picked up and placed upright.

MAINTENANCE

- **Cleaning:** Wipe the figure with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners. Do not immerse in water.
- **Storage:** Store the figure in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries if the figure will not be used for an extended period to prevent leakage.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Olaf is not responding.	<ul style="list-style-type: none">• Ensure the ON/OFF switch is in the 'ON' position.• Check battery installation and replace batteries if necessary.• Ensure the battery compartment cover is securely closed.
Olaf is not interacting with other figures.	<ul style="list-style-type: none">• Ensure all figures are turned 'ON'.• Make sure figures are placed close enough and facing each other.• Check batteries in all figures.• Ensure there are no obstructions between the figures.
Sound is distorted or low.	<ul style="list-style-type: none">• Replace batteries.• Ensure the speaker is not obstructed.
Olaf falls over easily.	<ul style="list-style-type: none">• Use the included stand (if applicable) to stabilize the figure.• Ensure the figure is placed on a flat, stable surface.

SPECIFICATIONS

Feature	Detail
Product Dimensions	2.5 x 2.5 x 6.75 inches
Item Weight	8.6 ounces
Model Number	75023
Manufacturer Recommended Age	36 months - 12 years

Feature	Detail
Batteries	2 AAA batteries required (included)
Manufacturer	Playmates Toys
Release Date	February 11, 2020


WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the packaging or contact Playmates Toys customer service directly. Contact details are typically available on the product packaging or their official website.

For additional product information or to explore other Disney products, visit the [Disney Store on Amazon](#).

© 2024 Disney. All rights reserved. This manual is for informational purposes only.

Related Documents - 75023

	<p>Interactive Olaf Toy: How to Use, Modes, and Features</p> <p>Official instruction sheet for the Disney Interactive Olaf toy. Discover how to activate Try Me Mode, RF Mode for talking to other Olafs, and Interactive Mode with voice commands. Learn about shoulder placement and battery replacement. Includes key phrases and FCC compliance information.</p>
	<p>Olaf Remote Control Duck Instruction Manual</p> <p>Instruction manual for the Disney Frozen Olaf Remote Control Duck (Model ET-0903-OLAF), detailing setup, operation, and safety guidelines.</p>
	<p>6V Frozen 2 Quad Ride On - User Manual and Safety Guidelines</p> <p>This document provides essential safety guidelines, vehicle care instructions, battery information, and assembly steps for the Disney Frozen 6V Quad Ride On toy, model KL-40052.</p>
	<p>Setting Up a Disney MagicMobile Pass for iPhone, Apple Watch, and Android Devices</p> <p>Learn how to set up and use your Disney MagicMobile Pass on iPhone, Apple Watch, and Android smartphones with Google Wallet for seamless access to theme parks, Lightning Lane entrances, and more.</p>



NINTENDO DS.

[High School Musical: Makin' the Cut! Nintendo DS Instruction Booklet](#)

Official instruction booklet for Disney's High School Musical: Makin' the Cut! video game on Nintendo DS. Learn how to play, understand game modes, and view safety information.



[Toy Story Sega Genesis Instruction Manual](#)

Official instruction manual for the Disney Pixar Toy Story video game on the Sega Genesis system. Learn gameplay, controls, characters, game levels, and game mechanics.