



Manuals.plus /

› Kinetic Sand /

› Kinetic Sand 3.25lbs Beach Play Sand Instruction Manual

Kinetic Sand 6059502

Kinetic Sand 3.25lbs Beach Play Sand Instruction Manual

MODEL: 6059502

This manual provides essential information for the safe and effective use of your Kinetic Sand 3.25lbs Beach Play Sand. Please read thoroughly before use.

1. Setup

1. **Unpack:** Carefully open the resealable bag containing the Kinetic Sand.
2. **Prepare Play Area:** Pour the Kinetic Sand into a clean, dry play area or a designated container. Ensure the play surface is suitable for sand play and easy to clean.



Image: Kinetic Sand 3.25lbs Beach Play Sand in its original resealable packaging, alongside a small pile of the sand.

2. Operating Instructions

Kinetic Sand offers a unique tactile experience, allowing for endless creative possibilities. Its special formula means it sticks to itself, not to you, making it easy to mold and clean.

- **Molding and Shaping:** Use your hands to sculpt and mold the sand into various shapes. You can also use sand tools, cookie cutters, or other creative accessories to enhance your creations.
- **Sensory Play:** Explore the unique, flowing texture of Kinetic Sand. It's designed to be satisfying to squish, stretch, and cut, providing a calming sensory experience.
- **Unique Properties:** Kinetic Sand never dries out, ensuring long-lasting play. It also magically sticks to itself, simplifying cleanup.



Magical moving sand Never dries out

Image: A hand gently squishing a clump of Kinetic Sand, highlighting its soft and moldable texture.

3.25
LBS



**Shape & mold to create
incredible sand art**

Image: A detailed sandcastle molded from Kinetic Sand, showcasing its ability to hold intricate shapes.

**MADE WITH
NATURAL SAND**



**Sticks to itself
for easy cleanup**

Image: A close-up view of the Kinetic Sand, revealing its granular texture similar to natural beach sand.

3. Maintenance

- **Cleanup:** To clean up scattered Kinetic Sand, simply press a larger piece of sand onto the smaller pieces. They will adhere to each other, making cleanup quick and easy.
- **Storage:** Store your Kinetic Sand in its original resealable bag or an airtight container to protect it from dust and debris. This helps maintain its unique texture and ensures it remains ready for play.
- **Avoid Water:** Kinetic Sand is designed for dry play. Exposure to water may alter its texture and properties.



Image: The Kinetic Sand 3.25lbs Beach Play Sand in its resealable bag, illustrating proper storage for longevity.

4. Troubleshooting

- **Sticky Texture:** If your Kinetic Sand becomes sticky, it may have been exposed to moisture. To restore its original texture, spread the sand out on a dry surface in a well-ventilated area and allow it to air dry completely, away from direct sunlight. Do not attempt to add water to fix it.

5. Specifications

- **Brand:** Kinetic Sand
- **Model Number:** 6059502
- **Item Weight:** 3.26 pounds
- **Product Dimensions:** 8.07 x 3.15 x 11.81 inches
- **Material:** Natural Sand
- **Age Range (Description):** 36 months - 12 years
- **Included Components:** 3.25lbs Kinetic Sand

6. Warranty and Support

-
- **Warranty:** This product is covered by the Spin Master Care Commitment. For full details regarding warranty coverage and terms, please refer to the official Spin Master website or contact their customer support directly.
 - **Customer Support:** For any further questions, concerns, or assistance with your Kinetic Sand product, please contact Kinetic Sand customer service. Refer to the product packaging or the official brand website for contact information.