

[Manuals.plus](#) /

› [Ikea](#) /

› Ikea Kungsfors Dish Drainer 403.712.25 User Manual

Ikea 403.712.25

Ikea Kungsfors Dish Drainer 403.712.25 User Manual

Model: 403.712.25

1. INTRODUCTION

This manual provides instructions for the assembly, use, and maintenance of the Ikea Kungsfors Dish Drainer, model 403.712.25. This product is designed to provide a convenient solution for air-drying dishes and utensils in your kitchen. It can be used on a countertop or mounted on a wall.



Figure 1: The Ikea Kungsfors Dish Drainer, model 403.712.25, shown from an angled perspective, highlighting its stainless steel construction and design for holding various dishes.

2. PACKAGE CONTENTS

Ensure all components are present before proceeding with assembly or installation:

- Dish Drainer unit (Stainless steel wire and frame)
- Removable Tray (Stainless steel)
- Mounting Brackets (Stainless steel, if wall mounting)
- Soft Plastic Feet (Pre-attached or included for countertop use)

Note: Fasteners for wall mounting are not included and must be selected based on your wall material.

3. SETUP AND INSTALLATION

The Kungsfors Dish Drainer offers flexible installation options:

3.1 Countertop Placement

For countertop use, simply place the dish drainer on a flat, stable surface. The integrated soft plastic feet provide stability and protect the countertop from scratches. Ensure the removable tray is correctly positioned underneath to collect water.



Figure 2: The dish drainer positioned on a kitchen countertop, holding plates, bowls, and glasses, with a brush and soap dispenser nearby.

3.2 Wall Mounting

The dish drainer can be mounted directly to a wall or integrated into the KUNGSFORS suspension rail system. Consider the following:

- **Space Requirements:** Ensure sufficient vertical space above the drainer for your dishes.
- **Fasteners:** Different wall materials require specific types of fasteners. Fasteners are not included. Consult a local hardware store if you are unsure which fasteners are suitable for your home's walls.

- **Load Bearing:** Wall materials vary in their ability to support weight. Drywall, for example, supports less weight than wood, concrete, or brick.



Figure 3: The dish drainer mounted on a kitchen wall, positioned below a shelf, holding various dishes and cups.



Figure 4: A close-up view of the stainless steel mounting bracket securely attached to a tiled wall, demonstrating the method for wall installation.

4. OPERATING INSTRUCTIONS (USAGE)

To use your Kungsfors Dish Drainer:

1. Place washed dishes, glasses, and utensils onto the spikes of the drainer for air drying.
2. Ensure the removable tray is in place underneath to collect any dripping water.
3. The spikes can be folded down to convert the unit into a flat shelf, providing additional storage space when not used for drying dishes.

5. MAINTENANCE AND CARE

The Kungsfors Dish Drainer is designed for durability and can be used in high humidity areas. To maintain its appearance and functionality:

- Regularly empty and clean the removable tray to prevent water buildup and mineral deposits.
- Wipe the stainless steel surfaces with a soft, damp cloth and a mild detergent.
- Avoid abrasive cleaners or scouring pads, which can scratch the stainless steel finish.
- Dry thoroughly after cleaning to maintain shine and prevent water spots.

6. TROUBLESHOOTING

This product is a passive dish drainer and typically does not require troubleshooting. If you encounter any issues, please ensure the product is correctly assembled and installed according to the instructions.

7. SPECIFICATIONS

Brand	Ikea
Model Number	IK.403.712.25
Product Dimensions	Approx. 23.5" (Width) x 11.75" (Depth) x 4" (Height)
Material	Stainless Steel
Special Features	Automatic Drainage (via removable tray), Rust Resistant, Foldable Spikes
Item Weight	4.15 kg
Recommended Use	Indoor
Mounting Type	Countertop Mount, Wall Mount

Note: Product dimensions are based on the descriptive text. The specification list also includes metric dimensions of 20 x 4 x 10 cm, which may refer to packaging or a different measurement.

8. WARRANTY AND SUPPORT

Specific warranty information for the Ikea Kungsfors Dish Drainer is not provided in this document. For details regarding warranty coverage, product support, or replacement parts, please contact Ikea customer service directly or visit the official Ikea website.

You may also find additional information and support resources on the [Ikea official website](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B084BW5YXR>

More documents and user manuals: <https://manuals.plus/>