

KOVE KA98359-0200

KOVE Commuter 2 Bluetooth Split Speaker User Manual

Model: KA98359-0200

INTRODUCTION

Thank you for choosing the KOVE Commuter 2 Bluetooth Split Speaker. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read it thoroughly to ensure optimal performance and longevity of your speaker.

PACKAGE CONTENTS

Ensure all items are present in your package:

- KOVE Commuter 2 Bluetooth Split Speaker
- USB Split Charging Cable
- User Manual (this document)

PRODUCT OVERVIEW

The KOVE Commuter 2 is a versatile Bluetooth speaker designed for both indoor and outdoor use. Its unique split design allows for 360-degree surround sound when combined, or optimal left and right stereo separation when split. Key features include:

- **Dual Speaker Design:** Can be used as a single unit or split into two for stereo sound.
- **Bluetooth 5.0 Connectivity:** Provides stable wireless connection up to 33 feet.
- **IPX7 Water Resistance:** Protected against water immersion up to 1 meter for 30 minutes.
- **Built-in Microphone:** For hands-free calling.
- **Two Equalizer Modes:** For customized audio experience.
- **Deep Bass Subwoofer:** Delivers rich audio with clarity.

IPX7 Water Resistant Rating

Meaning it can handle being submerged up to 1 meter underwater for up to 30 minutes.



Image: The KOVE Commuter 2 speaker demonstrating its ability to be used as a single unit or split into two for stereo sound.

SETUP INSTRUCTIONS

1. Charging the Speaker

Before first use, fully charge your KOVE Commuter 2 speaker. Use the provided USB split charging cable. Connect the cable to a USB power adapter (not included) and plug it into a power outlet. The speaker's indicator lights will show charging status.

2. Powering On/Off

- **To Power On:** Press and hold the power button on the speaker until the indicator lights illuminate.
- **To Power Off:** Press and hold the power button again until the indicator lights turn off.

3. Bluetooth Pairing

To connect your speaker to a Bluetooth-enabled device:

1. Ensure the speaker is powered on and in pairing mode (indicator light will flash).
2. On your device (smartphone, tablet, etc.), go to Bluetooth settings and enable Bluetooth.
3. Select "KOVE Commuter 2" from the list of available devices.
4. Once connected, the indicator light will become solid.



LIVE LIFE LOUDER

Inspired by travel, Kove is designed with your active lifestyle in mind. Whether you're using our split-speaker sets to share music with friends or getting away from it all with our noise-cancelling headphones, Kove is making it easier than ever to let the good times roll.

KOVE

Image: The KOVE Commuter 2 speaker illustrating its Bluetooth 5.0 capabilities, including a connection range of up to 33 feet and up to 7 hours of battery life.

4. Splitting and Combining Speakers

The KOVE Commuter 2 can be used as a single unit or split into two for a stereo experience:

- **To Split:** Gently twist the two halves of the speaker in opposite directions until they separate.
- **To Combine:** Align the two halves and twist them together until they securely lock into place.



Image: The KOVE Commuter 2 speaker separated into two units, with one half shown in water, demonstrating its split functionality and water resistance.

OPERATING INSTRUCTIONS

1. Basic Controls

The speaker features touch controls for various functions:

- **Play/Pause:** Tap the center button.
- **Volume Up:** Tap the right arrow button.
- **Volume Down:** Tap the left arrow button.
- **Next Track:** Press and hold the right arrow button.
- **Previous Track:** Press and hold the left arrow button.

2. Hands-Free Calling

When connected to a smartphone, the built-in microphone allows for hands-free calls:

- **Answer Call:** Tap the center button.

- **End Call:** Tap the center button during a call.
- **Reject Call:** Press and hold the center button.



Bluetooth 5.0

- Connect from up to 33 feet away.
- Operates for up to 7 hours on a single battery charge.



KOVE

Image: The KOVE Commuter 2 speaker, shown with a microphone icon, highlighting its integrated microphone for hands-free communication when paired with a smartphone.

3. Equalizer Modes

The speaker offers two equalizer modes to optimize sound for different environments. Refer to the specific product documentation for instructions on how to switch between these modes, as the method may vary.

MAINTENANCE

1. Water Resistance (IPX7)

The KOVE Commuter 2 is IPX7 water-resistant, meaning it can withstand immersion in water up to 1 meter for 30 minutes. This makes it suitable for use near water, but it is not designed for prolonged underwater use. Ensure the

charging port cover is securely closed before exposure to water.



Paired with a smartphone, the speaker's built-in mic lets you get back to business.



KOVE

Image: Two individuals holding KOVE Commuter 2 speakers in an outdoor setting, emphasizing the product's IPX7 water-resistant rating, which allows it to withstand splashes and brief submersion.

2. Cleaning

To clean your speaker, use a soft, damp cloth. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the speaker's finish or internal components.

3. Battery Care

To prolong battery life:

- Avoid fully discharging the battery frequently.
- Store the speaker in a cool, dry place when not in use for extended periods.
- Charge the speaker regularly, even if not in use, to maintain battery health.

TROUBLESHOOTING

If you encounter issues with your KOVE Commuter 2 speaker, refer to the following common solutions:

Problem	Possible Cause	Solution
Speaker does not power on	Low battery	Charge the speaker using the provided USB cable.
Cannot pair via Bluetooth	Speaker not in pairing mode; device Bluetooth off; interference	Ensure speaker is in pairing mode. Turn device Bluetooth off and on. Move closer to the speaker.
Only one speaker plays when split	Incorrect pairing sequence for split mode	Ensure only the top speaker (with strap) is initially paired via Bluetooth. Then, power on the second speaker, and it should automatically sync with the first for stereo playback. Avoid attempting to pair both speakers individually to your device simultaneously.
Poor sound quality or distortion	Low battery; device volume too high; speaker too far from device	Charge the speaker. Adjust volume on both speaker and device. Move device closer to speaker.
Speaker not responding to controls	Temporary software glitch	Power off the speaker, then power it back on.

SPECIFICATIONS

Feature	Detail
Model Name	Commuter 2
Item Model Number	KA98359-0200
Speaker Type	Dual Speaker
Connectivity Technology	Bluetooth 5.0, USB
Wireless Communication Technology	Bluetooth
Bluetooth Range	Up to 33 Feet (10 meters)
Water Resistance Level	IPX7 (Water Resistant)
Power Source	Battery Powered (2 Lithium Ion batteries included)
Battery Life	Up to 7 hours on a single charge
Speaker Maximum Output Power	100 Watts

Feature	Detail
Audio Output Mode	Stereo, Surround
Control Method	Touch
Product Dimensions	3"D x 8"W x 3"H
Item Weight	2 Pounds
UPC	812485027379




Image: A diagram showing the dimensions of the KOVE Commuter 2 speaker, measuring 3 inches in depth, 8 inches in width, and 3 inches in height.

WARRANTY INFORMATION

The KOVE Commuter 2 Bluetooth Split Speaker comes with a **one-year warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

SUPPORT

For further assistance, technical support, or warranty inquiries, please visit the official KOVE website or contact their customer service department. Refer to the product packaging or the KOVE website for the most current contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question