

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Forte](#) /
- › [Forte TEZAUR Computer Desk Instruction Manual - Model TZRB212-C913](#)

### Forte TZRB212-C913

## Forte TEZAUR Computer Desk Instruction Manual

Model: TZRB212-C913 | Brand: Forte

### 1. INTRODUCTION

---

Thank you for choosing the Fortte TEZAUR Computer Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.

The Fortte TEZAUR desk is designed for daily use in a home office or gaming setup, offering a functional and ergonomic workspace. It features a rectangular design with a black matte finish combined with orange accents, and includes a single drawer for storage.



Figure 1: Fortte TEZAUR Computer Desk in a typical setup.

## 2. PACKAGE CONTENTS

---

Your Fortte TEZAUR Computer Desk is typically shipped in multiple packages. Please ensure all packages are received and inspect them for any signs of damage before opening. If any parts are missing or damaged, please contact customer support immediately.




Figure 2: Product may be shipped in multiple packages.

The packages should contain all necessary components for assembly, including:

- Desk panels (tabletop, side panels, back panel, drawer components)
- Monitor stand/raised platform components
- Hardware pack (screws, dowels, cam locks, drawer slides, etc.)
- Assembly instructions (this manual)

### 3. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the Fortte TEZAUR Computer Desk requires basic household tools and can typically be completed by one or two adults. Please follow the step-by-step diagrams provided in the separate assembly guide included with your product. Ensure you have sufficient space for assembly and protect your floor surface.

#### 3.1 Required Tools (Not Included)

- Phillips head screwdriver
- Hammer (for dowels)
- Measuring tape (optional, for placement)

#### 3.2 Assembly Tips

- Identify all parts and hardware before starting.
- Do not overtighten screws to avoid damaging the wood-based material.
- Assemble on a soft, clean surface to prevent scratches.
- Ensure all connections are secure before using the desk.




Figure 3: Desk dimensions for planning your space.

### 4. OPERATING INSTRUCTIONS

The Fortte TEZAUR Computer Desk is designed for optimal functionality and comfort. Here are some key features and usage guidelines:

- **Ergonomic Design:** The desk features a raised platform, ideal for placing a monitor at an ergonomic viewing height, reducing neck and eye strain.
- **Storage:** An open compartment provides ample storage space, and a single drawer offers concealed storage for personal items or office supplies.
- **Cable Management:** A cable grommet is integrated into the compartment for easy and organized cable routing, keeping your workspace tidy.

- **Weight Capacity:** The maximum load on the tabletop is 40 kg. The monitor stand can support up to 10 kg, and the compartment can hold up to 5 kg. Do not exceed these limits to ensure stability and longevity of the desk.

**Ce produit sera expédié en plusieurs colis.**  
**Ils peuvent être livrés à des moments différents.**



(Exemple graphique: La quantité et/ou la forme réelles des colis peuvent différer.)

Figure 4: Detail of the monitor stand and storage compartment.

## 5. MAINTENANCE

To ensure the longevity and appearance of your Fortte TEZAUR Computer Desk, follow these maintenance guidelines:

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood-based material.
- **Heat and Moisture:** Avoid placing hot items directly on the surface. Use coasters or protective pads. Keep the desk away from excessive moisture or direct sunlight to prevent warping or fading.
- **Inspections:** Periodically check all screws and fittings to ensure they remain tight. Retighten if necessary.

## 6. TROUBLESHOOTING

If you encounter any issues with your Fortte TEZAUR Computer Desk, refer to the following common troubleshooting tips:

- **Desk is wobbly:** Ensure all screws and fittings are securely tightened. Check that the desk is placed on a level surface. Adjust any leveling feet if present.
- **Drawer does not slide smoothly:** Verify that the drawer slides are correctly installed and aligned. Ensure no obstructions are in the drawer tracks. Lubricate slides with a silicone-based spray if needed.
- **Missing parts:** Double-check all packaging materials. If parts are genuinely missing, contact customer support with your purchase details and the specific part numbers from the assembly guide.
- **Surface damage during assembly:** If minor scratches or chips occur, furniture repair pens or touch-up kits can be used. For significant damage, contact customer support.

## 7. SPECIFICATIONS

---



Figure 5: Fortte TEZAUR Computer Desk, alternative view.

Feature	Detail
Brand	Forte
Model Number	TZRB212-C913
Color	Black matte combined with orange
Product Dimensions (W x H x D)	160 x 93.8 x 69 cm
Material	Engineered wood, Metal, Wood-based materials, Melamine
Special Features	Ergonomic, Cable management grommet, Damage-resistant ABS edge
Number of Drawers	1
Recommended Use	Work, Gaming
Tabletop Load Capacity	40 kg
Monitor Stand Load Capacity	10 kg
Compartment Load Capacity	5 kg

## 8. WARRANTY AND SUPPORT

---

For information regarding warranty coverage, claims, or technical support, please refer to the warranty card included with your product or contact Forte customer service directly. Keep your proof of purchase for any warranty-related inquiries. Contact information for Forte customer support can typically be found on the manufacturer's website or on the product packaging.