

Tristar VE-5865

Tristar Tower Fan VE-5865 User Manual

Model: VE-5865

1. IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before using the appliance and keep them for future reference. Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- This appliance is intended for household use only.
- Do not use the appliance outdoors or in damp areas.
- Ensure the voltage indicated on the appliance matches your local mains voltage before connecting.
- Always unplug the fan before cleaning, moving, or when not in use.
- Do not insert fingers or other objects through the grille when the fan is operating.
- Keep the fan away from curtains, drapes, or any objects that may be drawn into the fan.
- Do not operate the fan with a damaged cord or plug. Contact qualified service personnel for repair.
- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

2. PRODUCT OVERVIEW

The Tristar Tower Fan VE-5865 is designed to provide efficient air circulation and cooling for your living spaces. It features multiple speed settings, oscillation, and a timer function for enhanced comfort.






Image 1: Front view of the Tristar Tower Fan VE-5865.





Image 2: Side view of the Tristar Tower Fan VE-5865, showing the integrated handle for portability.

3. SETUP AND ASSEMBLY

Follow these steps to set up your Tristar Tower Fan:

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging materials for future storage or transport.
2. **Base Assembly:** Place the fan body upright. Align the two halves of the base and snap them together around the bottom of the fan. Ensure they are securely fastened.
3. **Power Connection:** Place the fan on a stable, flat surface. Plug the power cord into a suitable electrical outlet.

4. OPERATING INSTRUCTIONS

4.1 Control Panel Overview

The control panel is located on the top of the fan. It features touch-sensitive buttons and an LED display.





Image 3: Close-up of the Tristar Tower Fan control panel with LED display.

- **Power Button ():** Turns the fan on or off.
- **Speed Button (≈):** Cycles through low, medium, and high-speed settings.
- **Mode Button (*):** Selects between Normal, Natural, and Sleep modes.
- **Oscillation Button (↺):** Activates or deactivates the oscillation function.
- **Timer Button ():** Sets the operating timer from 1 to 12 hours.

4.2 Remote Control Functions

The fan can also be operated using the included remote control.



Image 4: The remote control for the Tristar Tower Fan.

- The remote control duplicates all functions available on the main control panel.
- Ensure the remote control is pointed towards the fan's receiver for optimal operation.
- Requires 1 'A' battery (not included).

4.3 Basic Operation

1. **Power On/Off:** Press the Power button () on the control panel or remote control to turn the fan on or off.
2. **Adjusting Speed:** Press the Speed button (≈) repeatedly to cycle through Low, Medium, and High-speed settings.
3. **Selecting Mode:** Press the Mode button (*) to choose between Normal (constant airflow), Natural (simulates

natural breeze), and Sleep (quieter operation with dimming display) modes.

- 4. **Oscillation:** Press the Oscillation button (↶) to start or stop the fan's side-to-side oscillation.
- 5. **Setting the Timer:** Press the Timer button (⏸) repeatedly to set the desired operating time from 1 to 12 hours. The fan will automatically turn off after the set time.

5. MAINTENANCE

5.1 Cleaning

Regular cleaning helps maintain the fan's performance and extends its lifespan.

- Always unplug the fan from the power outlet before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents.
- Use a vacuum cleaner with a brush attachment to remove dust from the air inlet and outlet grilles.
- Do not immerse the fan in water or allow water to drip into the motor housing.
- Ensure the fan is completely dry before plugging it back in.

5.2 Storage

When not in use for extended periods, store the fan properly:

- Unplug the fan and clean it thoroughly.
- Coil the power cord neatly.
- Store the fan in its original packaging or cover it to protect it from dust.
- Keep the fan in a cool, dry place.

6. TROUBLESHOOTING

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply.	Check if the power cord is securely plugged into a working outlet.
Fan operates but no air movement.	Air inlets/outlets are blocked.	Ensure grilles are clear of obstructions. Clean if necessary.
Remote control not working.	Batteries are dead or incorrectly inserted.	Replace batteries or ensure they are inserted with correct polarity. Point remote directly at the fan.
Fan makes unusual noise.	Fan is not on a stable surface or internal obstruction.	Place the fan on a flat, stable surface. Unplug and check for any foreign objects inside the grilles.

7. TECHNICAL SPECIFICATIONS

Feature	Specification
---------	---------------




Feature	Specification
Brand	Tristar
Model Number	VE-5865
Electric Fan Design	Floor Fan
Power Source	Corded Electric
Wattage	30 watts
Voltage	240 Volts
Blade Length	76 Centimeters
Item Weight	2.4 Kilograms (5.28 pounds)
Product Dimensions	8.66 x 8.66 x 29.92 inches
Noise Level	59.21 Decibels
Special Feature	Oscillating
Control Method	Remote
Included Components	Cord




8. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in the product packaging or contact Tristar customer support.

For technical assistance, spare parts, or service inquiries, please visit the official Tristar website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

Related Documents - VE-5865

	<p>Tristar VE-5865 Tower Fan - Instruction Manual</p> <p>Comprehensive instruction manual for the Tristar VE-5865 Tower Fan, covering safety, parts description, assembly, operation, and environmental disposal guidelines.</p>
	<p>Tristar VE-5893/VE-5894 Pedestal Fan - Instruction Manual and Specifications</p> <p>Comprehensive instruction manual for the Tristar VE-5893 and VE-5894 pedestal fans, covering safety, assembly, operation, maintenance, and technical specifications. Learn how to safely operate and care for your Tristar fan.</p>
	<p>Tristar VE-5900 Tower Fan: Instruction Manual and Safety Guide</p> <p>Comprehensive guide for the Tristar VE-5900 tower fan, covering safety instructions, setup, operation, cleaning, maintenance, and environmental disposal. Learn how to use your Tristar fan safely and effectively.</p>

	<p><u>Tristar VE-5898/VE-5899 Pedestal Fan User Manual</u></p> <p>Comprehensive instruction manual for the Tristar VE-5898 and VE-5899 pedestal fans, covering safety, parts description, assembly, usage, cleaning, maintenance, and environmental disposal.</p>
	<p><u>Tristar VE-5804/VE-5805 Stand Fan Instruction Manual</u></p> <p>Comprehensive instruction manual for the Tristar VE-5804 and VE-5805 stand fans, covering safety, assembly, operation, maintenance, and environmental disposal.</p>
	<p><u>Tristar VE 5898/VE 5899 Stand Fan: User Manual, Safety, and Operation Guide</u></p> <p>Comprehensive user manual for the Tristar VE 5898 and VE 5899 stand fans. Includes safety precautions, parts description, assembly instructions, operating guide, cleaning and maintenance tips, and environmental disposal information.</p>